

### **3. AXLE**

#### **1) GENERAL INSTRUCTIONS**

##### **(1) SHIMS**

All adjustments shall be carried out after all adjustment shims have been selected measuring them one by one with a micrometer gauge and, then, summing up all values measured; don't trust incorrect measurement of pack as a unit or sum of nominal value printed on each shim.

##### **(2) SEALS FOR REVOLVING SHAFTS**

Proceed as follows for proper fitting of captioned seals:

Prior assembly, seals should be kept, for at least half an hour, in a bath with the same oil to be sealed;

Clean thoroughly shaft and make that working surface be not damaged;

Position sealing lip against the fluid to be sealed; in case of hydrodynamic lip lines should be oriented so as that, considering direction of revolving shaft, they lead fluid inside of sealing means;

Smear sealing lip with a film of lubricant(oil is better than grease) and fill up with grease the space between sealing lip and dust shield lip, if using double sealing lip type seals;

Press seal in relevant seat or use a proper fitter with flat contact surface; never use hammer or mallet to mount seal;

When press fitting seal make sure that it be correctly driven in relevant seat, i.e., perpendicular with respect to its seat, as fitting is completed make sure, if required, that seal itself be in contact with relevant shoulder;

To prevent damage of seal lip when inserting shaft, duly protect component during assembly.

##### **(3) O-RING SEALS**

Lubricate O-RING seals at assembly to prevent twisting that would impair correct sealing.

Clean matching surface as follows prior, smearing compound:

Remove old deposits using a metal brush;

Degrease surfaces by one the following cleaners: trichloroethylene, kerosene or a warm water and soda solution.

##### **(4) BEARINGS**

When assembling them it is advisable to proceed as follows:

Heat them with 80 to 90°C before fitting on relevant shafts;

Cool them before inserting in relevant external seats.

##### **(5) SPRING PINS**

When using split pins be sure that lengthwise cleft be positioned toward stress on pin.


Coil pins don't require specific position.

## 2) REDUCTION ASSEMBLY

### (1) DISASSEMBLY


Turn the plug toward top position and remove the plug for the air vent.

Assemble the plug temporary.




AX001

Drain oil from final drive unit.




AX002

Loosen screws securing side gear carrier to wheel hub.




AX003

Pull out complete side gear carrier.




AX004

Pull out wheel shaft with sun gear, discs carrier hub and thrust plate.




AX005

Remove brake disc pack.




AX006

Remove lock ring nut locks.




AX007

Remove locks.




AX008

Install the proper tool on pressure plate and apply the eye bolt(3EA) temporary. Tighten the eye bolt tool perfectly.



AX009

Remove the nut-adjusting by the use of the special tool.



AX0010

Remove the pressure plate, spring, cover.




AX0011

Remove the ring gear assembly.  
Attention to the weight.




AX0012

Pry off lock ring from ring from ring gear by a screw driver, and remove ring gear support.




AX0013

Remove piston, it's easier by blowing compressed air in brake oil delivery ducting.



AX0014

Remove wheel hub assembly.



AX0015

Pry off wheel hub seal and remove inner race with roller cage of wheel inside bearing. By using a punch remove from wheel hub outer races of inner and outer bearings.




AX0016



AX0017

Remove final drive cover.



AX0018

It is provided with three threaded holes (M10 x 1.5) to be used for puller screws.




AX0019

Remove the pin-planetary(3EA) from Drum-Hub(Side gear carrier support) assembly.



AX0020

Remove the planetary gear and thrust washer step by step.



AX0021

**(2) ASSEMBLY**

Insert the inner bearing cone.



AX085

Press fitting lip seal.

Smear loctite 573 or equivalent sealant on outer diameter surface.



AX086

Support suitably wheel hub while assembling parts to prevent damage of seal; then go on by fitting wheel bearing on hub spindle.



AX087

Replace O-ring seals on piston.  
Cover the oil on O-ring seal enough.




AX088

Insert piston full travel down on hub spindle.



AX089

Insert ring gear support in ring gear, then fit spring ring retaining axle.



AX090


Mount on hub spindle the complete ring gear unit.



AX091




Insert into relevant holes the six pins that, for proper operation of whole system, have to be of the same length and however in accordance with relevant drawing.



AX092

Position spring return cover on pressure plate, press compression tool.  
(Front axle only)



AX093


Assemble support assembly with spring compression tool on spindle and tighten nut-adjusting.



AX094


With proper wrench lock ring so to reach the specified wheel bearing pre-load corresponding to a rotation torque and a rope pull strength on studs included into 15~18kg.

To prevent wrong torque recording, it is advisable to set bearings, by various wheel revolutions, prior performing the check.




AX095

Remove spring compression tool.




AX096

Fit plate and assemble ring-retain.




AX097

Insert wheel shaft on which sequentially mount ; the thrust washer, discs carrier hub, sun gear and lock ring ; then push all components fully down against hub spindle.




AX098



AX099


Install brake measuring tool on hub-wheel.

Distance of brake measuring tool **J**




AX100

Measure **K** between end of measuring tool and pressure plate.



AX101

Install brake measuring tool on drum hub and measure **L**.



AX102


To determine thickness of disc pack from previously computed value **M**.

Assembly procedure of brake disc pack :

To drum hub from pressure plate **C, B, C, B.....C, B.**(C=disc-count, B=disc-brake)

Quantity of brake disc.

- Front axle : disc-count 6EA  
disc-brake 6EA
- Rear axle : disc-count 5EA  
disc-brake 5EA




AX103

Calculate stroke, and if it is not satisfied with the specification, readjust stroke by means of change the thickness of each disc.

Stroke :  $S=(K+L-2J)-M$

- Stroke  
Front axle : 4.2~4.8mm  
Rear axle : 3.5~4.0mm



Assemble disc pack according to the procedure.




AX104

- ) Arrange side gear carrier on blocks made of wood and remove pins.  
Save needle rollers of filling bearing casings.  
It is important to keep needle rollers joined with relevant pin for allowance question of pins themselves.



AX105


- ) Arrange all the three side gears into relevant seats of side gear carrier, position inner thrust washers and align holes.



AX106

- ) Mount on pins the two needle roller casings. Insert outer thrust washers, grease lower half of pin(head side) and position the first needle roller casing, insert spacer and position the second casing.

In case of needle roller replacement, use needle roller of the same selection class for the two casings of each side gear.




AX107

- ) Insert the complete pins, taking care to avoid any bump, cause of needle rollers fall.




AX108

- ) Rotate pins so to align them and allow fitting of cover that also prevent pin rotation.




AX109

- ) Fit O-ring seal on outer side.  
Mount side cover on final drive.
- Tightening torque  
Front and rear axle : 2.9~3.6kgf · m  
(21.0~26.0lbf · ft)




AX110

- ) Assemble drum-hub on hub-wheel.



AX111

- ) Tight the fixed bolt of drum-hub and assemble plug.
- Tightening torque  
Front and rear axle : 6.3~6.9kgf · m  
(45.6~50.0lbf · ft)



AX112

### 3) PARKING BRAKE(FRONT AXLE ONLY)

#### (1) DISASSEMBLY


Insert through oil adding hole of gripper the pressure of 100~120bar, in order to obtain calipers release.

Remove the cover bolts of caliper.




AX022

Release nut and screw.




AX023

Remove the split pin and nut of caliper brake. Remove the bolts.




AX024

Remove the caliper brake.




AX025

Remove the disc.



AX026

Remove the fixed bolts of bracket-caliper.




AX027

## (2) ASSEMBLY

Install bracket-caliper.


- Tightening torque  
11.4~12.6kgf · m(82.5~91.1lbf · ft)



AX113

Fit disc on flange, and tighten bolts.

- Tightening torque  
6~7kgf · m(43.4~50.6lbf · ft)



AX114


Remove cover and O-ring of caliper, and release nut and pin screw.



AX115




Release nuts on fixed bolts in order to obtain the maximum opening of gripper.



AX116


Insert fixed bolts on caliper.



AX117

Tighten nuts and split pins.

- Tightening torque  
1~3kgf · m(7.2~21.7lbf · ft)



AX118

Assemble the fixed parts on caliper-brake.


- Procedure1 : Insert O-ring in adapter bleeder and assemble it, assemble bleeder on adapter.

Adapter tightening torque : 1.2~1.6Kgf · m  
(8.7~11.6lbf · ft)

Bleeder tightening torque : 1.4~1.5Kgf · m  
(10.1~10.8lbf · ft)


- Procedure2 : Fix copper washer and connector on caliper, and assemble it.

Connector tightening torque : 2.0~2.2Kgf · m  
(14.5~15.9lbf · ft)



AX119


Press 110~120bar in brake port and close  
adhesion pad on disc by means of tightening  
pin-screw.



AX120

Check the gap between discs after unscrew-  
ing pin screw 1/8~1/4turn.


Disc gap : Each 0.125~0.25mm



AX121

Tighten nut.


- Tightening torque : 14~16Kgf · m  
(101~116lbf · ft)



AX122

Tighten bolts after assembling O-ring on cover.

- Tightening torque : 1.3~1.5Kgf · m  
(9.4~10.8lbf · ft)



AX123

#### 4) DIFFERENTIAL ASSEMBLY


##### (1) REMOVAL

Remove screws and take away air recirculation duct from differential support and axle case.




AX028

Unlock and loosen screws retaining differential group, then remove it from axle case.




AX029



AX030


##### (2) DISASSEMBLY

Place differential unit upside down; mark caps position.




AX031

Unlock and remove caps fixing screws.




AX032

Remove lock pin of ring nut, remove caps.



AX033

Lift up differential from support, by a lifting tool with proper capacity.




AX034

Place on proper support and lock the differential. Straighten notches on pinion nut, then position reaction tool on P.T.O. flange and unlock nut; release pinion nut. Remove drive flange from pinion shank.



AX035



AX036

Pry off seal from P.T.O. flange.



AX037

Drive out bevel pinion from differential support hammering by a proper remover on shank, don't damage thread.




AX038

Remove the bearing cone.



AX039


Remove the shims from P.T.O flange.



AX040

The conditions of assembled only bearing cone in pinion gear.


Remove the shim and spacer in removed pinion.



AX041

Remove outer races of pinion shank and under head bearings; save shims for axial position of pinion and ail recirculation impeller.

Press on impeller to drive out outer race of under head bearing.




AX042

### (3) ASSEMBLY

Measure the dimensions for assembly position of pinion bevel.

Decide the dimension X(shim thickness) by the calculation.




AX043

Both the pinion-bevel and the gear-bevel are marked with a number. Confirmed the some numbers both the pinion-bevel and gear-bevel.

Number location of bevel set

Bevel pinion : Head surface

Bevel ring : Outer cutting side




AX044

Measure the carrier height **A** by the special tool.

Standard value of **A**

- Front axle : 287.5mm
- Rear axle : 263.0mm




AX045

Decide a value **B** by the carved value of pinion-bevel head.

- Front axle :  $B = 231.7 \pm \text{carved value}$
- Rear axle :  $B = 208.0 \pm \text{carved value}$

In case, the carved value is -10, **B** of Front axle =  $231.7 - 0.1 = 231.6\text{mm}$




AX046

Measure the width of bearing **C**.

Standard value of **C**

- Front axle : 54.77mm
- Rear axle : 54.0mm



AX047


Determine shim X thickness for correct axial position of pinion-bevel.

$$X = A - (B + C)$$

Round up or down to the nearest tenth of millimeter the computed thickness.


2.12 rounded down to = 2.1mm

2.18 rounded up to =2.2mm




AX047

Fit in pinion shank inner race of under head bearing, heat or press-in part by installer.



AX049


Place correctly pump in relevant seat on differential support.



AX050

Insert adjustment shim for axial position of pinion.

Its value was computed previously ; also, fit outer races of pinion under head and shank bearings.




AX051




Turn the carrier upside down and assemble the bevel pinion assembly.

In order to contact between the bearing cone in pinion bevel and the bearing-cup of carrier perfectly, support the pinion-bevel by preferable tool.



AX052

Assemble the shims(3EA)



AX053

Assemble the spacer and shims(2EA).



AX054

Fit in bearing-cone by heating or pressing.



AX055

⑭ Assemble flange and holder in pinion-bevel, and tighten nut-pinion.

- ※ Pinion nut tightening torque
  - Front axle : 72~78kgf · m
  - Rear axle : 58~64kgf · m


※ Don't assemble seal.



AX056


⑮ Measure preload and confirm the follow value.

- ※ Bearing preload
  - Front axle : 0.2~0.4kg · m
  - Rear axle : 0.2~0.4kg · m
- ※ Before measuring preload, rotate two or three times. Disassemble and change adjustment shims to eliminate all end play up to reach a pre-load.



AX057

As bearing pre-load has been determined, remove drive flange and nut-pinion holder.



AX058


Assemble seal.

- ※ Cover the seal with retaining compound. Cover the seal lip and the flange with oil.




AX059

Assemble the flange and the holder on the pinion-bevel, and tighten the nut-pinion and the split pin.



AX060

Fit in the differential assembly on the carrier, and assemble nut-adjusting temporary.




AX061

Install caps, care not to reverse position and lock screws fixing to differential support with belows.

Cap tightening torque

- Front axle : 63~69Kgf · m(456~499lbf · ft)
- Rear axle : 63~69Kgf · m(456~499lbf · ft)



AX062

) Position a dial gauge perpendicular than ring gear tooth and check, with pinion steady, backlash that has to be of 0.25 ~ 0.33mm (rear) and 0.39~0.54mm(front).

Otherwise rotate both ring nuts by displacing them of the same number of notches and nearing ring gear to pinion if backlash is excessive, by moving away on the contrary.


Bevel set back lash

- Front axle : 0.39~0.54mm
- Rear axle : 0.25~0.33mm




AX063

- ) Brush red lead on some ring tooth, rotate to mesh pinion and ring gear repeatedly, so to make evident tooth contact. Proper and correct tooth contact marks are visible on a new bevel gear set as a result of an optimum contact approached on the tester, consequently, a proper axial position of pinion against ring gear will emphasise remarking of previous tester contact markings.



AX064


- ) Fit spring pins locking threaded rings of differential unit.



AX065


#### (4) HOUSING AND DIFFERENTIAL MOUNTING

Perform two securing notches on pinion nut. Clean with care contact surfaces, apply hard locking compound and then install the differential unit on axle case ; lock the connecting screws with a torque of 31.3~34.5Kgf · m(226~250lbf · ft).




AX082

Assemble O-ring on tube assembly port(3EA).  
(Front axle only)



AX083

Position the tube assembly, fit screws and lock with a torque of 3.0~3.5Kgf · m(21.7~25.3lbf · ft).  
(Front axle only)




AX084

## 5) SUPER MAX TRAC

### (1) DISASSEMBLY

Mark the two half cases(LH/RH).



AX066

Unscrew and remove the screws and open them.



AX067

Remove the planetary gear with relevant intermediate and shim discs and clutch discs.



AX068

Remove spider with the four side gears and relevant bevel thrust washers.



AX069

Remove the planetary gear with relevant intermediate and shim discs and clutch discs, in half case on bevel gear side.



AX070

Loosen bevel gear fixing screws.



AX071

## (2) ASSEMBLY

Install gear-bevel on case-LH by bolts.

Tightening torque

- Front axle : 87~95kgf · m(629~687lb · ft)
- Rear axle : 46~50kgf · m(333~362lb · ft)




AX072

Before assembling, each smooth face have to be lubricated with oil.


- Insert a lug disc(**a**) (with outer lugs) into half case.
- Insert an intermediate disc(**b**) (with inner lugs), then another disc(**a**), a disc (**b**), still lug disc(**a**).

Discs(**b**) are thin with lining on both faces, disc(**c**) is thick and lined on one face only.


- Insert a disc(**c**) with unlined face turned upward.
- Smear oil on planetary gear and insert taking care to mesh shaft splines with inner lugs of clutch discs.



Assemble side gears with relevant bevel thrust washers on spider and position them on the half case.



Insert gear side assembly in case-LH.



Assemble spider and gear-side according to procedure.



AX079

Mount the cover aligned against the lugs of lug disks, taking care to align the reference marked done before disassembling ; close the two half casings.

Screw in fixing screws and lock a torque of ;

- Front axle : 21~23kgf · m (152~166lbf · ft)
- Rear axle : 11.5~12.5kgf · m  
(83.2~90.4lbf · ft)



AX080


As assembling is done, play of each clutch pack have to be included between 0.05 and 0.1mm.

Check has to perform with 180° at the same time on both clutch packs to prevent that play between side gears and spider would mislead reading.

Make sure of proper gear rotation.

If play value of clutches results different than specified one, differential has to be disassembled again, rearrange clutch pack again, select proper disc shims.

Reassemble and check all over again.




AX081




6) TOOLS

Spring compression tool.



AX124

Nut adjusting tool of reduction assembly.



AX125