


SECTION 3 POWER TRAIN SYSTEM

GROUP 1 STRUCTURE AND FUNCTION

1. POWER TRAIN COMPONENT OVERVIEW



The power train consists of the following components:

- Transmission
- Torque converter
- Front, center, rear and upper drive shafts
- Front and rear axles

Engine power is transmitted to the transmission through the torque converter.

The transmission is a hydraulically engaged four speed forward, four speed reverse countershaft type power shift transmission. A calliper-disc type parking brake is located on the front axle.


The transmission outputs through universal joints to three drive shaft assemblies. The front drive shaft is a telescoping shaft which drives the front axle. The front axle is mounted directly to the loader frame. The front axle is equipped with limited slip differential.

The rear axle is mounted on an oscillating pivot. The rear axle is equipped with limited slip differential.


The power transmitted to front axle and rear axle is reduced by the pinion gear and ring gear of differential. It then passes from the differential to the sun gear shaft(Axle shaft) of final drive.

The power of the sun gear is reduced by a planetary mechanism and is transmitted through the planetary hub to the wheel.

1) HYDRAULIC SCHEMATIC



2) HYDRAULIC CIRCUIT




Speed	Forward				Reverse				Neutral			
	1	2	3	4	1	2	3	4	1	2	3	4
R					X	X	X	X				
F	X	X	X	X								
3	X	X	X		X	X	X		X	X	X	
2	X	X			X	X			X	X		
1	X				X				X			

X : Solenoid activated

2. TORQUE CONVERTER

1) STRUCTURE



The torque converter assembly is composed of : Torque converter, output shaft for driving the transmission, coupling and flange to mount the converter charging pump to supply oil under pressure to operate transmission clutches and for converter cooling.

The torque converter is composed of four members : The impeller(1) which is the driving member, the turbine(2) which is the driven member, the reaction member(3) which is splined on a fixed support, and the drive plate(4) which couples the converter to the engine. The impeller and drive plate members form the outer shell. The turbine runs within the outer shell and is connected to the output shaft(5). The oil is the only connection between the turbine and impeller members. The reaction member is splined to the converter support which is fixed and does not rotate in either direction. A gear is splined to the impeller hub and drives through gears rotating the charging pump mounted on the converter housing cover(6).

2) OPERATION

With the engine running, the converter charging pump draws oil from the transmission sump and directs it through oil filters to the modulation valve located on top of the transmission. From the modulation valve it is then directed through the control cover on the transmission to the converter and to the transmission clutches.

The pressure modulation valve mounted on the top of the transmission remains closed until required pressure is delivered to the transmission for actuating the direction and speed clutches. This modulation valve consists of a hardened valve spool operating in a closely fitted bore. The valve spool is backed up by a spring to hold the valve spool against its seat until the oil pressure builds up to the specified pressure. The valve spool then moves towards the spring until a port is exposed along the side of the bore. The oil can then flow through this port into a distributor which directs the oil into the converter inlet port.

After entering the converter, the oil is directed through the stator support to the converter cavity and exits between the turbine shaft and converter support. The oil then passes through an oil distributor which directs the oil out of the converter by way of a down stream regulating valve and then to the oil cooler. After leaving the cooler the oil is directed through a hose to the lubricating oil inlet on the transmission, then through a series of tubes to the transmission, bearings, and clutches. The oil then returns to the transmission sump.

A safety valve is built in the transmission control cover and will open to bypass oil only if an excessive pressure is built up due to a blocked passage.

The rear compartment of the converter unit also houses the converter output shaft. A flexible hose provides an overflow to the transmission sump.


The three members of the torque converter are composed of a series of blades. The blades are curved in such a manner as to force the oil to circulate from the impeller to the turbine, through the reaction member again into the impeller. This circulation causes the turbine to turn in the same direction as the impeller. Oil enters the inner side of the impeller and exits from the outer side into the outer side of the turbine. It then exits from the inner side of the turbine and after passing through the reaction member, again enters the inner side of the impeller.

The down stream regulating valve(9) on the converter consists of a valve body and regulator spool. The spool is backed up by a spring to hold the valve until converter oil pressure builds up to specified pressure. The valve is used to maintain a given converter pressure to insure proper performance under all conditions.

- ※ **Converter "stall" is achieved whenever the turbine and turbine shaft are stationary and the engine is operating at full power or wide open throttle.**
- ※ **Do not maintain "stall" for more than 30 seconds at a time. Excessive heat will be generated and may cause converter or transmission seal damage.**

3. TRANSMISSION

1) STRUCTURE



The control valve assembly on the transmission consists of a valve body with selector valve spools connected to the steering column by exterior linkage. A detent ball and spring in the selector spool provides four positions, one position for each speed range. A detent ball and spring in the direction spool provides three positions, one each for forward, neutral, and reverse.

The control valve also contains a shut-off valve spool operated by an hydraulic cylinder located on the control cover. This valve is connected to the brake system by a hose line. When the wheel brakes are applied, hydraulic fluid enters the valve and overcomes a spring force. This forces the spool to shift over and block pressure from entering the directional clutches. In this manner a **neutral** is established without moving the control levers.

With the engine running and the directional control lever in neutral position, oil pressure is blocked at the control valve, and the transmission is in neutral. Movement of the forward and reverse spool will direct oil, under pressure, to either the forward or reverse direction clutch as desired, and the opposite one is open to relieve pressure.

The direction or speed clutch assembly consists of a drum with internal gear teeth and a bore to receive a hydraulically actuated piston. A piston is inserted into the bore of the drum. The piston is **oil tight** by the use of sealing rings. A friction disc with internal teeth is inserted into the drum and rests against the piston. Next, a disc with splines at the outer diameter is inserted. Discs are alternated until the required total is achieved. After inserting the last disc, a series of springs and pins are assembled in such a manner that these springs rest on teeth of the piston. A heavy back-up plate is then inserted and secured by a snap ring. A hub with I.D. and O.D. splines is inserted into the splines of discs with teeth on the inner diameter and a splined shaft extending through the clutch support. This hub is retained by a snap ring. The discs and inner shaft are free to increase in speed or rotated in the opposite direction as long as no pressure is present in the direction or speed clutch.

To engage the clutch, as previously stated, the control valve is placed in the desired position. This allows oil under pressure to flow from the control cover valve, through a tube in the transmission case, to a chosen clutch. Once into the drum, oil is directed through a drilled hole into the rear side of the piston bore. Pressure of the oil forces the piston and discs over against the heavy back-up plate. The discs, with teeth on the outer diameter, clamping against discs, with teeth on inner diameter, enables the clutch drum and drive shaft to be locked together and allows them to turn as a unit.

There are bleed balls in the clutch drums which allow quick escape for oil when the pressure to the piston is released.

The transmission gear train consists of six shafts : Input shaft, reverse shaft, idler shaft, first and third shaft, second and fourth shaft, output shaft.

A screen mounted in a frame is positioned on the bottom of the transmission case, to screen out any foreign material. This screen is covered by the sump pan. This pan is provided with magnets to catch any metallic particles.


2) OPERATION OF TRANSMISSION

(1) Forward

① Forward 1st

In 1st forward, forward clutch and 1st clutch are engaged.


Forward clutch and 1st clutch are actuated by the hydraulic pressure applied to the clutch piston.



② Forward 2nd

In 2nd forward, forward clutch and 2nd clutch are engaged.


Forward clutch and 2nd clutch are actuated by the hydraulic pressure applied to the clutch piston.



③ **Forward 3rd**

In 3rd forward, forward clutch and 3rd clutch are engaged.


Forward clutch and 3rd clutch are actuated by the hydraulic pressure applied to the clutch piston.



④ **Forward 4th**

In 4th forward, forward clutch and 4th clutch are engaged.

Forward clutch and 4th clutch are actuated by the hydraulic pressure applied to the clutch piston.




(2) Reverse

① Reverse 1st

In 1st reverse, reverse clutch and 1st clutch are engaged.


Reverse clutch and 1st clutch are actuated by the hydraulic pressure applied to the clutch piston.



② Reverse 2nd

In 2nd reverse, reverse clutch and 2nd clutch are engaged.


Reverse clutch and 2nd clutch are actuated by the hydraulic pressure applied to the clutch piston.



③ Reverse 3rd

In 3rd reverse, reverse clutch and 3rd clutch are engaged.


Reverse clutch and 3rd clutch are actuated by the hydraulic pressure applied to the clutch piston.



④ **Reverse 4th**


In 4th reverse, reverse clutch and 4th clutch are engaged.

Reverse clutch and 4th clutch are actuated by the hydraulic pressure applied to the clutch piston.




3) ELECTRIC SOLENOID CONTROL VALVE


Direction & speed	Solenoids energized	Clutches pressurized
Forward 1st	U X Y Z	Forward & 1st
Forward 2nd	U Y Z	Forward & 2nd
Forward 3rd	U Z	Forward & 3rd
Forward 4th	U	Forward & 4th
Neutral 1st	X Y Z	1st
Neutral 2nd	Y Z	2nd
Neutral 3rd	Z	3rd
Neutral 4th	-	4th
Reverse 1st	V X Y Z	Reverse & 1st
Reverse 2nd	V Y Z	Reverse & 2nd
Reverse 3rd	V Z	Reverse & 3rd
Reverse 4th	V	Reverse & 4th



Energized



De-energized



4. EGS LEVER

1) SHIFT LEVER OPERATION

EGS lever applications share the principle of selecting direction and gear positions.

Direction is selected by placing the lever in **one of three detented positions**(Neutral, Forward or Reverse).


Gear shifts are made by bringing the lever either in the **upshift position** or in the **downshift position**. These positions are **spring returned**.

With the EGS, shifts are made **relative** to the previous position : The EGS **remembers** the selected gear position and shifts either to a higher gear or to a lower gear.

The EGS display always shows the selected shift lever position, the selected direction, the gear position and the gear direction.

This operating principle accounts for the flexibility of the EGS system : It makes possible to control any(Electric) powershift transmission with the same shift lever, provided the correct **software**(A program for the EGS computer) is installed.

It also facilitates features such as kickdown, automatic powerup in neutral, preset gear selection after a direction change, etc..



The **forward** driving direction is selected by pushing the lever away from the driver(This usually corresponds with pushing it to the normal driving direction).

The **reverse** driving direction is selected by pulling the lever towards the driver.

The **neutral** can be selected by placing the lever into its central detented position.

An **upshift** is requested by rotating the shift lever counter clockwise.

A **downshift** is requested by rotating the shift lever clockwise.

2) FUNCTIONAL DESCRIPTION

(1) Automatic powerup in neutral

When power is first applied to the EGS, **neutral** is always selected.

This is **regardless** of the position of the shift lever(It can be in either forward, neutral or reverse position).

In order to start driving, the driver first has to place the shift lever into the neutral(Central detented) position before a specific direction can be selected.

(2) Neutral start protection

Each EGS can have an output signal, which is deactivated whenever the shift lever is in the neutral position.

This signal can be used to control a normal closed relay preventing engine start up whenever the shift lever is **not** in the neutral detented position.

If during powerup the shiftlever is in forward or in reverse, the neutral start protection will not be activated(Due to the function **automatic powerup in neutral**). Only after leaving this function **automatic powerup in neutral** the neutral start protection will be activated.

(3) Kickdown

This EGS lever is also available with a shift lever integrated **push button**, which is used for the kickdown function.

Usually it's used for requesting a downshift from 2nd to 1st gear, which is dropped after a direction change : **F2→Kickdown→F1→R2**

This is called kickdown.

If however the speed is too high, the kickdown request is stored for a certain time. If during this time the speed has not slowed down sufficiently, the request is dropped.

3) DISPLAY FUNCTION

The EGS has an internal bicolor LED display for displaying the selected shiftablever position, the selected shiftablever direction, the transmission position and the transmission direction.

Application specific details are described in a separate document : EGS functional description.

This EGS functional description can be requested for each EGS unit. This description overrules the below description wherever applicable.

(1) Displayed information

Typically four types of information about the EGS and the transmission can be of interest to the driver :

Selected shiftablever position and transmission position

Selected shiftablever direction and transmission direction

Application specific information

Diagnostic information

① Selected position and direction

The difference between shift lever position and transmission position might not be immediately clear, but when one remembers that the EGS can protect the transmission(Example : By not allowing a downshift), it becomes clear that the **requested** position(The shift lever position) can be different from the **actual engaged** position(The position of the transmission).

Both shift lever position and transmission position can be divided in two subcategories:

Gear position (1st, 2nd, 3rd, 4th)

Driving direction (Forward, neutral, reverse)

Application specific information

This can be anything(Whatever the customer wants to see).

As an example : On an EGS automatically controlling the lockup clutch, it's interesting to see whether or not the converter is in lockup. This can be indicated on the EGS display by using the LED 7-yellow.

② Diagnostic information

Two types of diagnostic information are considered :

ON LINE diagnostics

This information is given during normal driving when something special happens.

In most applications, the LED 8 is used to indicate standstill. This helps to spot problems with the speed sensor in an early stage before the lack of protection resulting from the failure can produce damaged to the drivetrain.

Which **on line** diagnostic functions are provided is detailed in the application specific EGS Functional description.

OFF LINE diagnostics


There are three selftest modes built into the EGS. Details about their function and usage are described in clause 5), **Selftest functions**.

(2) Display layout

The EGS uses LED's(Light Emitting Diodes) to give information to the driver.

It consists of eight multicolor LED's :

Labeled 1 to 8 and can light up in **red, green** and **yellow**.



These numbered LED's are used for displaying both the shift lever selection and the transmission engagement.

They also used to indicate diagnostic information in the different test modes.

The **red** LED is labeled **N** and when this lights up it indicates that the transmission is placed in neutral(This is possible even while the shift lever is not in neutral).

The **yellow** LED is labeled **T** which stands for troubleshooting. This LED is ON while working in one of the three selftest modes described in clause 5), **Selftest function**.

(3) Display method

Basically the **gear position** is shown by turning ON the LED that corresponds with the selected position. In 1st gear, LED 1 is ON, in 2nd gear, LED 2 is ON etc..

The selected direction is shown with the **color** of the LED :

Red	Indicates	Neutral
Green	Indicates	Forward
Yellow	Indicates	Reverse

Additionally LED **N**(Red) is ON while the transmission is in neutral.

The position shown is **always** the selected **shiftlever** position. Most of the time, the actual transmission position will be the same as the shown one, and in that case that's all there is.

However if, because of an active protection or because of some internally generated delay, there is a discrepancy between transmission position and shift lever position, a 2nd LED will indicate the transmission position(Color indicates direction).

To let the driver know the difference between both indications, the transmission LED blinks while the shift lever LED stays ON all the time.

While this may seem a bit confusing at first, it's very easy to understand the shown information in reality.

Example : Driving in 4th gear forward at high speed.

→ LED 4 - Green

When the driver is making a downshift, but due to a too high speed the EGS will protect the transmission and will not allow the requested downshift. Thus the transmission will stay in 4th gear forward, while the shiftlever is in 3rd gear forward.

→ LED 3 - Green &
LED 4 - Blinking green

4) CONNECTOR PIN DESIGNATIONS

Below table lists the function of each EGS connector pin for the transmission :

Pin	Comment
1	Battery plus
2	Battery ground
3	Neutral start signal
4	CV Solenoid 1
5	CV Solenoid 2
6	CV Forward solenoid
7	CV Reverse solenoid
8	Null
9	CV High / Low solenoid
10	Speed sensor input HOT
11	Speed sensor input GND
12	Travel speed signal
13	Speed output
14	Declutch
15	Extension kick down
16	Shield ground(Internally connected to wire 2)

CV stands for control valve.

5) SELFTEST FUNCTIONS

The EGS has special circuitry to help verifying its operation.

Three selftest modes are built into the EGS control programs :

Input test

Speed sensor test + Lamptest

Output test

The EGS furthermore has the ability to check for possible problems while driving (**On line** diagnostics).

As described in clause(2), Display layout at page 3-20, the **T LED** is used for identifying different troubleshooting modes. This is done in combination with the status of the **N LED**.

(1) Operation of the N and T LED's

① Overview

Situation	LED
In normal situations(Driving, no problems)	T LED is always OFF
When error is detected	T LED is ON or BLINKING
In selftest mode	T LED is always ON

② Detailed operation

Situation	N LED	T LED
Normal operation	On when transmission neutral	OFF
Internal fault	ON	Blinking SLOWLY
Input test	Blinking SLOWLY	ON
Output test	Blinking FAST	ON
Speed sensor test	OFF	ON

(2) Selftest operation

Selftest modes can only be started **while powering up** the EGS.

Invocation of a certain mode is done by moving the shift lever to a specific position while switching on the power of the EGS.

Leaving the selftest mode is done by switching OFF the power of the EGS.

① Selftest mode invocation

Below table lists what conditions must be satisfied during **powerup** to get into a specific selftest mode :

Selftest mode	To enter mode
Input test	FWD & UP
Speed sensor test	REV & UP
Output test	FWD & DOWN

② **Input test**

When EGS shiftlever is held in the **forward up** position while power is applied, **input test** mode is activated.

In this mode, driving is not possible, since all EGS outputs remain OFF until the testmode is left.

This test is used to verify operation of the shiftlever and its inputs.

The LED's(Gear position indicators) on the EGS top cover are used to display test information :

Shift lever position	LED Color	LED Number
Neutral	RED	4
UP	RED	5
DOWN	RED	3
FWD	GREEN	4
FWD & UP	GREEN	5
FWD & DOWN	GREEN	3
REV	YELLOW	4
REV & UP	YELLOW	5
REV & DOWN	YELLOW	3
Wire 14 = GROUND	RED	1 (Together with above LED)
Wire 15 = GROUND	GREEN	1 (Together with above LED)

※ If wire 14 and wire 15 are grounded simultaneously LED 1 lights up **yellow**.

③ **Speed sensor test**

When EGS is held in the reverse up position while power is applied, **speed sensor test** mode is activated.

In this mode, driving is possible.

The test begins with a **lamp test** and then displays the speed sensor information.

④ **Speed display**

The LED corresponding with below table burns to indicate converter turbine speed :

Turbine rpm	LED Number(Green)
0	1 BLINKS
0 - 249	1 ON
250 - 499	2 ON
500 - 749	3 ON
750 - 999	4 ON
1000 -1249	5 ON
1250 - 1499	6 ON
1500 - 1749	7 ON
1750 -1999	8 ON
Above 2000	8 BLINKS

② Output test

When EGS is held in the forward down position while power is applied, **output test** mode is activated.

In this mode, driving is not possible, since all EGS outputs remain OFF until the testmode is left.

LED's 1 - 8 light up sequentially during output test :

First LED 1 is switched on shortly, then LED 2 etc..

When LED 8 is switched off, LED 1 is again switched on and so on.

The color of the LED indicates its status :


Color	Status
GREEN	Output OK
YELLOW	Output NOT connected or shorted to battery plus
RED	Output shorted to ground(or to another output)

The LED numbers correspond to output wires as follows :

LED Number	Output wire
1	6
2	7
3	4
4	5
5	13
6	9
7	8
8	3

※ To find the function of the corresponding output wires - See EGS functional description

6) REPLACING OF EP-ROM




- (1) Remove screw(33).
- (2) Remove screw(38).
- (3) Remove screw(34).
- (4) Remove screw(25).
- (5) Remove plate(26) and seal(27).
- (6) Slide the PCB's(42, 43) out of the housing, with rear cover connected(31, 35).
- (7) Remove plastic cover(40).
- (8) Replace EP-ROM(39).
- ※ **Notice the correct position of the mark on the EP-ROM (See D).**
- (9) Reassemble the EGS.

※ **Notice the correct slots for the different ports.**

See on the right figure.

- A : Slots for cover(40)
- B : Slots for PCB(42)
- C : Slots for PCB(43)




5. AXLE

1) OPERATION

- The power from the engine passes through torque converter, transmission and drive shafts, and is then sent to the front and rear axles.
- Inside the axles, the power passes from the bevel pinion to the bevel gear and is sent at right angles. At the same time, the speed is reduced and passes through the both differentials to the axle shafts. The power of the axle shafts is further reduced by planetary-gear-type final drives and is sent to the wheels.

(1) Front axle




1 Final drive

2 Differential

3 Axle

(2) Rear axle





1 Final drive

2 Differential



3 Axle

2) SECTION OF FRONT AXLE DIFFERENTIAL



- | | | | | | |
|---|--------------|---|-----------|---|-------------------------|
| 1 | Bevel pinion | 3 | Sun gears | 5 | Side gear(Differential) |
| 2 | Bevel gear | 4 | Shaft | | |

3) SECTION OF REAR AXLE DIFFERENTIAL



- | | | | | | |
|---|--------------|---|----------|---|-------------------------|
| 1 | Bevel pinion | 3 | Sun gear | 5 | Side gear(Differential) |
| 2 | Bevel gear | 4 | Shaft | | |


4) DIFFERENTIAL

(1) Description

When the machine makes a turn, the outside wheel must rotate faster than the inside wheel. A differential is a device which continuously transmits power to the right and left wheels while allowing them to turn at different speeds, during a turn.


The power from the drive shaft passes through bevel pinion(1) and is transmitted to the bevel gear(2). The bevel gear changes the direction of the motive force by 90°, and at the same time reduces the speed.

It then transmits the motive force through the differential(3) to the axle gear shaft(4).



(2) When driving straight forward


When the machine is being driven straight forward and the right and left wheels are rotating at the same speed, so the pinion gear inside the differential assembly do not rotate. The motive force of the carrier is sent through the pinion gear and the side gear, therefore the power is equally transmitted to the left and right axle gear shaft.



(3) When turning

When turning, the rotating speed of the left and right wheels is different, so the pinion gear and side gear inside the differential assembly rotate in accordance with the difference between the rotating speed of the left and right wheels.

The power of the carrier is then transmitted to the axle gear shafts.



5) TORQUE PROPORTIONING DIFFERENTIAL


(1) Function

① Because of the nature of their work, 4-wheel-drive loaders have to work in places where the road surface is bad.

In such places, if the tires slip, the ability to work as a loader is reduced, and also the life of the tire is reduced.

The torque proportioning differential is installed to overcome this problem.


In structure it resembles the differential of an automobile, but the differential pinion gear has an odd number of teeth. Because of the difference in the resistance from the road surface, the position of meshing of the pinion gear and side gear changes, and this changes the traction of the left and right tires.



(2) Operation

① **When travelling straight**(Equal resistance from road surface to left and right tires)

Under this condition, the distances involving the engaging points between right and left side gears and pinion-a and b-are equal and the pinion is balanced as $FL \times a = FR \times b$. Thus, $FL = FR$, and the right and left side gears are driven with the same force.




② **When travelling on soft ground**


(Resistance from road surface to left and right tires is different)

If the road resistance to the left wheel is smaller, the left side gear tends to rotate forward, and this rotation changes the engaging points between the side gears and pinion. As a result, the distances involving the engaging points becomes $a > b$. The pinion now is balanced as $FL \times a = FR \times b$, where $FL > FR$. The right side gear is driven with a greater force than the left side gear. The torque can be increased by up to about 30% for either side gear.

The pinion therefore does not run idle and driving power is transmitted to both side gears until the difference between road resistance to the right and left wheels reaches about 30%.



6) FINAL DRIVE(Front & rear)



1 Axle shaft


3 Ring gear

4 Sun gear

2 Planetary gear

- (1) To gain a large drive force, the final drive uses a planetary gear system to reduce the speed and send drive force to the tires.
- (2) The power transmitted from the differential through axle shaft(1) to sun gear(4) is transmitted to planetary gear(2). The planetary gear rotates around the inside of a fixed ring gear(3) and in this way transmits rotation at a reduced speed to the planetary carrier. This power is then sent to the wheels which are installed to the planetary carriers.

6. TIRE AND WHEEL



- | | | | | | |
|---|-----------|---|-----------|---|----------------|
| 1 | Wheel rim | 3 | O-ring | 5 | Side ring |
| 2 | Tire | 4 | Lock ring | 6 | Valve assembly |

- 1) The tire acts to absorb the shock from the ground surface to the machine, and at the same time they must rotate in contact with the ground to gain the power which drives the machine.
- 2) Various types of tires are available to suit the purpose. Therefore it is very important to select the correct tires for the type of work and bucket capacity.