

HYDRAULIC SYSTEM

TABLE OF CONTENTS

1. SPECIFICATIONS.....	4-3		
2. HYDRAULIC SYSTEM OVERVIEW	4-5		
2.1 Hydraulic system layout	4-5		
2.2 Circuit diagram for hydraulic system.....	4-9		
2.3 Connecting lines by hydraulic system groups...4-11			
2.3.1 HST group.....	4-11		
2.3.2 Oil tank group	4-18		
2.3.3 Suction line group.....	4-18		
2.3.4 Hydraulic pump group.....	4-19		
2.3.5 Oil cooler group	4-20		
2.3.6 Tilt cylinder group	4-21		
2.3.7 Lift cylinder group	4-22		
2.3.8 High flow group.....	4-23		
2.3.9 Quick attachment cylinder group....	4-24		
2.3.10 External hydraulic group	4-25		
2.4 Connecting lines for hydraulic valves	4-26		
2.4.1 Pilot lock valve (LF13-0284).....	4-26		
2.4.2 Shift valve (LF13-0286)	4-27		
2.4.3 Parking valve (LF13-0090)	4-28		
2.4.4 Self level valve (LF13-0218).....	4-29		
2.4.5 Quick attachment valve (LF13-0307)...	4-30		
2.4.6 Main control valve (LF13-0028)	4-31		
2.4.7 RCV assembly (RH) (LF13-0056)...	4-32		
2.4.8 RCV assembly (LH) (LF13-0055) ...	4-33		
2.5 Hose connecting lines for a driving system and circulation system	4-34		
2.5.1 Hydraulic hose (LF13-0022A).....	4-34		
2.5.2 Hydraulic hose (LF13-0158A).....	4-35		
2.5.3 Hydraulic hose (LF13-0160A).....	4-36		
2.5.4 Hydraulic hose (LF13-0323A).....	4-37		
2.5.5 Hydraulic hose (LF13-0325A).....	4-38		
2.5.6 Hydraulic hose (LF13-0340A).....	4-39		
2.5.7 Hydraulic hose (LF13-0341A)	4-40		
2.5.8 Hydraulic hose (LF13-0402A).....	4-41		
2.5.9 Hydraulic hose (LF13-0403A).....	4-42		
2.5.10 Hydraulic hose (LF13-0404A)	4-43		
2.5.11 Hydraulic hose (LF13-0407A).....	4-44		
2.5.12 Hydraulic hose (LF13-0408A)	4-45		
2.5.13 Hydraulic hose (LF13-0412A).....	4-46		
2.5.14 Hydraulic hose (LF13-0414A).....	4-47		
2.5.15 Hydraulic hose (LF13-0439A)	4-48		
2.5.16 Hydraulic hose (LF13-0576A)	4-49		
3. MAIN COMPONENTS	4-50		
3.1 HST pump (Driving pump)	4-50		
3.2 Gear pump (Main+Charge+High flow pump)...	4-52		
3.3 Track(HST) motor	4-55		
3.4 Main control valve (MCV)	4-57		
3.5 Pilot lock valve	4-59		
3.6 Self level valve	4-60		
3.7 High flow valve	4-62		
3.8 Shift valve	4-64		
3.9 Parking valve	4-65		
3.10 Ride control valve [option].....	4-66		
3.11 Quick attachment valve.....	4-67		
3.12 RCV assembly (LH).....	4-68		
3.13 RCV assembly (RH).....	4-70		
3.14 Hydraulic cylinder	4-72		
3.14.1 Lift cylinder	4-72		
3.14.2 Tilt cylinder	4-73		
3.14.3 Quick attachment cylinder.....	4-74		
3.15 Hydraulic filter.....	4-75		
3.15.1 Return filter	4-75		
3.15.2 HST filter	4-77		
3.15.3 Oil strainer.....	4-79		
3.16 Quick coupler (External hydraulic).....	4-81		
3.17 Oil cooler	4-83		

TABLE OF CONTENTS

4. OPERATING PRINCIPLE	4-84	8. HYDRAULIC SYSTEM MAINTENANCE...	4-120
4.1 Track(HST) motor.....	4-85	8.1 Main pump detach.....	4-120
4.2 Self level valve	4-87	8.2 HST pump detach.....	4-121
4.3 RCV (R/H).....	4-91	8.3 Main pump, charge pump, high flow pump disassembly	4-124
4.3.1 Boom operation (Up).....	4-92	8.4 Track(HST) motor disassembly	4-129
4.3.2 Boom operation (Down).....	4-93	8.5 Main control valve detach & Disassembly ...	4-132
4.3.3 Self leveling.....	4-94	8.6 Self level valve detach & Disassembly ...	4-142
4.3.4 Ride control [Option].....	4-95	8.7 Pilot lock valve detach & Disassembly	4-147
4.3.5 Bucket operation (Roll back).....	4-96	8.8 Shift valve detach & Disassembly	4-150
4.3.6 Bucket operation (Dump).....	4-97	8.9 Parking valve detach & Disassembly	4-153
4.3.7 Quick attachment	4-98	8.10 High flow valve detach & Disassembly....	4-156
4.3.8 External implement.....	4-99	8.11 Ride control valve detach & Disassembly [OPTION]	4-160
5. CHECK & ADJUSTMENT.....	4-102	8.12 Quick attachment valve detach & Disassembly	4-163
5.1 Main control valve (MCV) system pressure...	4-102	8.13 HST filter replacement	4-166
5.2 Main pump flow rate	4-103	8.14 Return filter replacement.....	4-168
5.3 Charging pump pressure	4-104	8.15 Lift cylinder disassembly	4-169
5.4 HST (Driving) pump pressure	4-105	8.16 TILT cylinder disassembly.....	4-172
5.5 HST (Driving) pump flow rate.....	4-106	8.17 Quick attachment cylinder disassembly...	4-174
5.6 Relief pressure setting	4-107	8.18 RCV assembly & Oil tank disassembly...	4-175
6. TROUBLESHOOTING	4-108		
7. EXPLODED VIEW	4-109		
7.1 LF1-G211003 Oil tank sub group.....	4-109		
7.2 LF1-G214003 Oil cooler group.....	4-110		
7.3 LF1-G221002 Main control valve group...	4-111		
7.4 LF1-G221503 Joystick group	4-112		
7.5 LF1-G222003 Auxiliary hydraulic group...	4-113		
7.6 LF1-G223002 Lift cylinder group	4-114		
7.7 LF1-G223504 Self leveling group	4-115		
7.8 LF1-G224502 Tilt cylinder group	4-116		
7.9 LF1-G225003 Quick attach cylinder group...	4-117		
7.10 LF1-G226002 Drain vavle group	4-118		
7.11 LF1-G231003 HST group.....	4-119		

1. SPECIFICATIONS

ITEM		SPECIFICATIONS
Hydraulic oil		<ul style="list-style-type: none"> Hydraulic oil capacity : 38 ℓ (10.0 u.s.gal.) Used oil : ISO VG46
Loader pressure	Standard	<ul style="list-style-type: none"> Loader pressure : 230 bar (3,335 psi) Loader flow : 82.9 lpm (21.9 gpm)
	High flow	<ul style="list-style-type: none"> Loader pressure : 150 bar (2,176 psi) Loader flow : 128.8 lpm (34.0 gpm)
2-Speed track motor		<ul style="list-style-type: none"> Capacity : Lo 31.5 cm³ Hi 20.6 cm³ Max. system pressure : 34.3 MPa Max. speed (At Min. capacity) : 4,170 rpm Brake pressure : 1.5 (Min) ~ 4.9 (Max) MPa 11 ~ 15 bar ((At 2,200 N·m) Maximum pressure applied to brake port (Z) : 40 bar
Pilot lock valve		<ul style="list-style-type: none"> Max. flow : 10 lpm Max. pressure : 40 bar Accumulator capacity : 0.32 ℓ Free charge pressure : 11 bar
Self level valve		<ul style="list-style-type: none"> Max. flow : A-port (Boom down) 69 lpm B-port (Boom up) 41 lpm Max. pressure : 250 bar
High flow valve		<ul style="list-style-type: none"> Max. flow : 150 lpm Max. pressure : 250 bar
Shift valve		<ul style="list-style-type: none"> Max. flow : 20 lpm Max. pressure : 210 bar
Parking valve		<ul style="list-style-type: none"> Max. flow : 20 lpm or more Max. pressure : 280 bar or more
Ride control valve (Option)		<ul style="list-style-type: none"> Max. flow : 0.5 ~40 lpm Max. operating pressure : 350 bar or more
Main control valve (MCV)		<ul style="list-style-type: none"> Rated flow : 80 lpm Max. pressure : 250 bar Max. back pressure : 25 bar
Cylinder	Quick attachment cylinder (mm)	<ul style="list-style-type: none"> Size : Ø30 × Ø60 × 209
	Tilt cylinder (mm)	<ul style="list-style-type: none"> Size : Ø40 × Ø75 × 364
	Lift cylinder (mm)	<ul style="list-style-type: none"> Size : Ø45 × Ø65 × 992

ITEM		SPECIFICATIONS
Filter	Return filter	<ul style="list-style-type: none"> • Fineness : 10 μm • Filtering dimension : 4,410 cm^2 • Flow : 125 lpm • Bypass valve setting pressure : 1.7 bar • Operating pressure : 12 bar
	HST filter	<ul style="list-style-type: none"> • Fineness : 10 μm • Filtering dimension : 415 cm^2 • Flow : 35 lpm • Bypass valve setting pressure : 6 bar • Operating pressure : 310 bar
Quick attachment valve		<ul style="list-style-type: none"> • Max. flow : 20 lpm or more, • Max. operating pressure : 280 bar or more
Main pump		<ul style="list-style-type: none"> • Capacity : 34.555 cm^3/rev • Continuous pressure : 280 bar • Peak pressure : 320 bar • Rotation speed : 500 ~ 3,000 rpm
Charge pump		<ul style="list-style-type: none"> • Capacity : 19.091 cm^3/rev • Continuous pressure : 200 bar • Peak pressure : 240 bar • Rotation speed : 500 ~ 3,000 rpm
High flow pump		<ul style="list-style-type: none"> • Capacity : 19.091 cm^3/rev • Continuous pressure : 200 bar • Peak pressure : 240 bar • Rotation speed : 500 ~ 3,000 rpm
HST pump		<ul style="list-style-type: none"> • Charge relief valve setting pressure : 2.4 MPa at 37.9 lpm • High-pressure relief valve setting pressure : 34.5 MPa at 3.8 ~ 5.6 lpm • Rated speed at maximum capacity : 3,200 rpm • Oil flow at rated speed : 59.4 lpm at 1,800 rpm • Capacity : 2 x 33.0 cm^3/rev • Direction of rotation : Clockwise
Quick coupler (External hydraulic)	Male Drain Female	<ul style="list-style-type: none"> • Size : 12.5 mm • Max. Operating pressure : 35 MPa • Rated flow : 100 lpm
RCV assembly (LH, RH)		<ul style="list-style-type: none"> • Min. initial pressure : 30 bar • Max. initial pressure : 100 bar • Min. rated flow : 5 lpm • Max. rated flow : 20 lpm

SAFETY FIRST

ENGINE

DRIVING & CHASSIS

HYDRAULIC SYSTEM

ELECTRIC SYSTEM


CABIN

INDEX

2. HYDRAULIC SYSTEM OVERVIEW

2.1 HYDRAULIC SYSTEM LAYOUT


LH



LT1W416A

- | | | |
|----------------------|-------------------------------|--------------------|
| (1) Quick coupler | (5) Quick attachment cylinder | (9) Parking valve |
| (2) RCV assembly | (6) Tilt cylinder | (10) Track motor |
| (3) Pilot lock valve | (7) High flow valve | (11) Lift cylinder |
| (4) Selt level valve | (8) Shift valve | |

RH



LT1W417A

- | | | |
|----------------------------|-------------------|-------------------|
| (1) Return filter | (3) Lift cylinder | (5) Oil tank |
| (2) Quick attachment valve | (4) Track motor | (6) Tilt cylinder |

SAFETY FIRST

ENGINE

DRIVING & CHASSIS

HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN

INDEX

SAFETY FIRST

ENGINE

DRIVING & CHASSIS


HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN

INDEX


OVER VIEW



LT1W418A

- | | |
|--------------------------------|---|
| (1) Lift cylinder (RH) | (13) Lift cylinder (LH) |
| (2) Return filter | (14) HST filter |
| (3) Main control valve (MCV) | (15) HST pump |
| (4) Track motor-RH | (16) Track motor-LH |
| (5) Quick attachment valve | (17) Parking valve |
| (6) Main pump | (18) Selt level valve |
| (7) Charge pump | (19) Shift valve |
| (8) High flow pump | (20) Pilot lock valve |
| (9) Oil tank | (21) RCV assembly (LH- Driving) |
| (10) RCV assembly (RH-Working) | (22) High flow valve |
| (11) Tilt cylinder (RH) | (23) Tilt cylinder (LH) |
| (12) Quick attachment cylinder | (24) Quick coupler (External hydraulic) |


FRONT VIEW



- (1) Main control valve (MCV)
- (2) RCV assembly (RH-Working)
- (3) Oil tank
- (4) Track(HST) motor (RH)
- (5) HST filter

- (6) RCV asbly (LH-Driving)
- (7) Quick coupler (External hydraulic)
- (8) Track(HST) motor (LH)
- (9) High flow valve
- (10) Ride control valve

2.2 CIRCUIT DIAGRAM FOR HYDRAULIC SYSTEM



75HP CTL	
FULL OPT	
Speed	2
High flow	O
Self leveling	O
Quick attachment	O
External hydraulic	O

SAFETY FIRST

ENGINE

DRIVING & CHASSIS

HYDRAULIC SYSTEM


ELECTRIC SYSTEM

CABIN

INDEX

2.3 CONNECTING LINES BY HYDRAULIC SYSTEM GROUPS

2.3.1 HST GROUP



SAFETY FIRST

ENGINE

DRIVING & CHASSIS

HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN

INDEX

SAFETY FIRST

ENGINE

DRIVING & CHASSIS



HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN


INDEX

HST PUMP




LT1W421A

LH



LT1W422A

RH




LT1W423A



TRACK MOTOR

Track motor (LH)

* The track motor (RH) is symmetrical for the track motor (LH)






LT1W424A




SAFETY FIRST
ENGINE
DRIVING & CHASSIS
HYDRAULIC SYSTEM
ELECTRIC SYSTEM
CABIN
INDEX

HYDRAULIC HOSE






LT1W429A




LT1W430A

2.3.2 OIL TANK GROUP




LT1W431A


2.3.3 SUCTION LINE GROUP



LT1W434A



LT1W432A



LF1W421A

SAFETY FIRST

ENGINE

DRIVING & CHASSIS


HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN

INDEX

2.3.4 HYDRAULIC PUMP GROUP



SAFETY FIRST

ENGINE

DRIVING & CHASSIS

HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN

INDEX

2.3.5 OIL COOLER GROUP

SAFETY FIRST

ENGINE


DRIVING & CHASSIS

HYDRAULIC SYSTEM




ELECTRIC SYSTEM

CABIN

INDEX



2.3.6 TILT CYLINDER GROUP



SAFETY FIRST

ENGINE

DRIVING & CHASSIS

HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN

INDEX

2.3.7 LIFT CYLINDER GROUP

SAFETY FIRST

ENGINE


DRIVING & CHASSIS

HYDRAULIC SYSTEM


ELECTRIC SYSTEM

CABIN

INDEX




LF1W428A



LF1W429A

2.3.8 HIGH FLOW GROUP



LT1W436A

- SAFETY FIRST
- ENGINE
- DRIVING & CHASSIS
- HYDRAULIC SYSTEM**
- ELECTRIC SYSTEM
- CABIN
- INDEX

2.3.9 QUICK ATTACHMENT CYLINDER GROUP

SAFETY FIRST

ENGINE


DRIVING & CHASSIS

HYDRAULIC SYSTEM


ELECTRIC SYSTEM

CABIN

INDEX





LF1W431A



LF1W432A

2.3.10 EXTERNAL HYDRAULIC GROUP



SAFETY FIRST

ENGINE

DRIVING & CHASSIS

HYDRAULIC SYSTEM


ELECTRIC SYSTEM

CABIN

INDEX

2.4 CONNECTING LINES FOR HYDRAULIC VALVES

2.4.1 PILOT LOCK VALVE (LF13-0284)



LT1W437A

- (P1) (Working)
Thru shift valve elbow
- (P2) To parking valve elbow (Driving)
- (T) To oil tank
- (U2) From RCV assembly-LH (Driving)
- (U1) (fitting)
 - (1) To main control valve (V)
 - (2) To RCV assembly-RH (Working)

PORT	FITTING	HOSE
T	LF13-0029	LF13-0109
P2	LF13-0095	LF13-0342
U2	LF13-0029	LF13-0522
P1	LF13-0095	LF13-0339
U1	LF13-0445	LF13-0100 To MCV
		LF13-0060 To RCV

SAFETY FIRST

ENGINE

DRIVING & CHASSIS


HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN

INDEX

2.4.2 SHIFT VALVE (LF13-0286)



LT1W438A

PORT	FITTING	HOSE
P	LF13-0092	LF13-0339, To pilot lock valve
		LF13-0340, To HST pump
T	LF13-0045	LF13-0467
2SPD	LF13-0092	LF13-0407, To HST motor-LH
		LF13-0408, To HST motor-RH

2.4.3 PARKING VALVE (LF13-0090)

SAFETY FIRST

ENGINE

DRIVING & CHASSIS


HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN

INDEX


CTL



LF1W437A

PORT	FITTING	HOSE
1	LF13-0108	LF13-0338
2	LF13-0092	LF13-0337, To HST motor-LH
		LF13-0336, To HST motor-RH
3	LF13-0092	LF13-0342, To pilot lock valve
		LF13-0341, From HST pump

SSL




LF1W438A

PORT	FITTING	HOSE
1	LF13-0376	LF13-0089
2	LF13-0092	LF13-0088, To HST motor-RH
		LF13-0087, To HST motor-LH
3	LF13-0045	LF13-0102


2.4.4 SELF LEVEL VALVE (LF13-0218)

CTL




PORT	FITTING	HOSE
A	LF13-0141	LF13-0350
B	LF13-0141	LF13-0351
C	LF13-0141	LF13-0353
D	LF13-0141	LF13-0352

SSL



PORT	FITTING	HOSE
A	LF13-0141	LF13-0350
B	LF13-0141	LF13-0351
C	LF13-0276	LF13-0556
D	LF13-0276	LF13-0570

2.4.5 QUICK ATTACHMENT VALVE (LF13-0307)



LF1W440A

CTL

PORT	FITTING	HOSE
A	LF13-0374	LF13-0370, To LF13-0373 hydraulic tube
B	LF13-0374	LF13-0371, To LF13-0372 hydraulic tube
P	LF13-0045	LF13-0375, To HST pump
T	LF13-0426	LF13-0377, To hydraulic oil tank

SSL

PORT	FITTING	HOSE
A	LF13-0374	LF13-0370, To LF13-0373 hydraulic tube
B	LF13-0374	LF13-0371, To LF13-0372 hydraulic tube
P	LF13-0045	LF13-0375, To HST pump
T	LF13-0426	LF13-0463, To hydraulic oil tank

SAFETY FIRST

ENGINE

DRIVING & CHASSIS


HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN

INDEX


2.4.6 MAIN CONTROL VALVE (LF13-0028)



- (L) To oil tank
- (V) From pilot lock valve U1
- (V3) From RCV (Boom up)
- (V1) From RCV (Roll back)
- (V4) From RCV (Boom down)
- (V2) From RCV (Dump)
- (A1) To tilt cylinder (Roll back)
- (A2) To lift cylinder (Lift)
- (A3) To external hydraulic (Female)
- (B1) To tilt cylinder (Dump)
- (B2) To self level (A)
- (B3) To external hydraulic (Male)

PORT	FITTING	HOSE		PORT	FITTING	HOSE (TUBE)	
		CTL	SSL			CTL	SSL
L	LF13-0029	0567	0556	A1	0358	0505 To tilt (A1-1)	
						0353 From self level (A1-2)	0556 From self level (A1-2)
V	0029	0551	0551	A2	0324	0303	
V1	0045	0069	0558	A3	0356	0392	0558 FROM RCV-RH 4번
V2	0045	0062	0560	B1	0358	0507 to tilt (B1-1)	
						0352 From self level (B1-2)	0570 From self level (B1-2)
V3	0045	0068	0559	B2	0324	0350	
V4	0045	0067	0561	B3	0324	0394	
P	0428	0553	0553	T	0440	0158 to oil cooler (T-1)	0158 to oil cooler (T-1)
						0448 From high flow (T-2)	0562 From high flow (T-2)

2.4.7 RCV ASSEMBLY (RH) (LF13-0056)



PORT	LINE	FITTING	HOSE	
			CTL	SSL
1	MCV (Boom down)	Short LF13-0070	LF13-0067	LF13-0561
2	MCV (Dump)	Short LF13-0070	LF13-0062	LF13-0560
3	MCV (Boom up)	Short LF13-0070	LF13-0068	LF13-0559
4	MCV (Roll back)	Short LF13-0070	LF13-0069	LF13-0558
P	Pilot lock valve	Long LF13-0057	LF13-0060	LF13-0557
T	Oil tank	Long LF13-0057	LF13-0053	LF13-0566

SAFETY FIRST

ENGINE

DRIVING & CHASSIS


HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN

INDEX

2.4.8 RCV ASSEMBLY (LH) (LF13-0055)



PORT	LINE	FITTING	HOSE	
			CTL	SSL
5	Hydraulic block	Short LF13-0070	LF13-0331	LF13-0058
C	HST pump (Forward-RH)	Short LF13-0070	LF13-0329	LF13-0063
D	HST pump (Reverse-LH)	Long LF13-0057	LF13-0327	LF13-0064
E	HST pump (Reverse-RH)	Long LF13-0057	LF13-0328	LF13-0066
F	HST pump (Forward-LH)	Short LF13-0070	LF13-0330	LF13-0065
P	Pilot lock valve	Short LF13-0070	LF13-0522	LF13-0061
T	Oil tank	Long LF13-0057	LF13-0052	LF13-0565

SAFETY FIRST

ENGINE

DRIVING & CHASSIS

HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN

INDEX

2.5 HOSE CONNECTING LINES FOR A DRIVING SYSTEM AND CIRCULATION SYSTEM

2.5.1 HYDRAULIC HOSE (LF13-0022A)

SAFETY FIRST

ENGINE





DRIVING & CHASSIS

HYDRAULIC SYSTEM

ELECTRIC SYSTEM


CABIN

INDEX



LF1W445A

2.5.2 HYDRAULIC HOSE (LF13-0158A)



SAFETY FIRST

ENGINE

DRIVING & CHASSIS

HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN

INDEX

2.5.3 HYDRAULIC HOSE (LF13-0160A)

SAFETY FIRST

ENGINE


DRIVING & CHASSIS

HYDRAULIC SYSTEM




ELECTRIC SYSTEM

CABIN

INDEX




LF1W448A






LF1W449A

2.5.4 HYDRAULIC HOSE (LF13-0323A)



LF1W450A



LF1W451A

SAFETY FIRST

ENGINE

DRIVING & CHASSIS

HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN

INDEX

2.5.5 HYDRAULIC HOSE (LF13-0325A)

SAFETY FIRST

ENGINE


DRIVING & CHASSIS

HYDRAULIC SYSTEM




ELECTRIC SYSTEM

CABIN

INDEX







LF1W452A



LF1W453A

2.5.6 HYDRAULIC HOSE (LF13-0340A)



SAFETY FIRST

ENGINE

DRIVING & CHASSIS

HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN

INDEX

2.5.7 HYDRAULIC HOSE (LF13-0341A)

SAFETY FIRST

ENGINE




DRIVING & CHASSIS

HYDRAULIC SYSTEM


ELECTRIC SYSTEM

CABIN



INDEX



2.5.8 HYDRAULIC HOSE (LF13-0402A)



LF1W458A



LF1W459A

SAFETY FIRST

ENGINE

DRIVING & CHASSIS

HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN

INDEX

2.5.9 HYDRAULIC HOSE (LF13-0403A)

SAFETY FIRST

ENGINE


DRIVING & CHASSIS

HYDRAULIC SYSTEM




ELECTRIC SYSTEM

CABIN

INDEX




LF1W460A






LF1W461A

2.5.10 HYDRAULIC HOSE (LF13-0404A)



LF1W462A



LF1W463A

SAFETY FIRST

ENGINE

DRIVING & CHASSIS

HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN

INDEX

2.5.11 HYDRAULIC HOSE (LF13-0407A)

SAFETY FIRST

ENGINE





DRIVING & CHASSIS

HYDRAULIC SYSTEM

ELECTRIC SYSTEM





CABIN

INDEX



LF1W465A

2.5.12 HYDRAULIC HOSE (LF13-0408A)



LF1W467A

SAFETY FIRST

ENGINE

DRIVING & CHASSIS

HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN

INDEX

2.5.13 HYDRAULIC HOSE (LF13-0412A)

SAFETY FIRST

ENGINE





DRIVING & CHASSIS

HYDRAULIC SYSTEM


ELECTRIC SYSTEM

CABIN




INDEX



2.5.14 HYDRAULIC HOSE (LF13-0414A)



LF1W470A



LF1W471A

2.5.15 HYDRAULIC HOSE (LF13-0439A)

SAFETY FIRST

ENGINE





DRIVING & CHASSIS

HYDRAULIC SYSTEM


ELECTRIC SYSTEM

CABIN




INDEX



2.5.16 HYDRAULIC HOSE (LF13-0576A)



LF1W474A



LF1W475A

SAFETY FIRST

ENGINE

DRIVING & CHASSIS

HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN

INDEX

3. MAIN COMPONENTS

3.1 HST PUMP (DRIVING PUMP)

SAFETY FIRST

ENGINE



DRIVING & CHASSIS

HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN

INDEX



LT1W460A

LT1W439A


The HST pump is assembled with the engine flywheel with the coupling engagement so that the rotating power from the engine is directly delivered to the inside of the HST pump.


This HST pump is a hydraulic tandem piston pump which has three different types of gear pumps mounted on its inlet in a row. The HST pump is connected to the RCV (LH), being involved in controlling hydraulic flow for driving, and it also supplies hydraulic flow to the track motors (LH/RH) for forward/reverse driving of the vehicle.

SPECIFICATIONS

Type	Axial piston unit, Closed circuit, Double pump, Variable swash plate
Flow (at rated rpm)	59.4 ±0.4 L/min at 1,800 rpm
Rated pressure limit	35.0 MPa
Capacity	2 x 33.0 cm ³ /rev
Input shaft rotation direction	Clockwise
High pressure relief pressure	34.5 MPa at 3.8 ~ 5.6 lpm
Rated rpm limit	3,200 rpm (at Max. Capacity)
Charging relief setting pressure	2.4 ±0.07 MPa at 37.9 lpm


CIRCUIT DIAGRAM & EXTERIOR





LT1W440B

3.2 GEAR PUMP (MAIN+CHARGE+HIGH FLOW PUMP)



The gear pumps are connected to the HST pump in a row and receives the rotating power from the engine through the HST pump. The main pump (1), charge pump (2), and high-flow pump (3) are mounted in order when seen from the HST pump side.

SPECIFICATIONS

ITEM	MAIN PUMP (1)	CHARGE PUMP (2)	HIGH FLOW PUMP (3)
Capacity (cm ³ / rev)	34.555	19.091	19.091
Maximum continuous pressure (bar)	280	200	200
Maximum peak pressure (bar)	320	240	240
Speed (rpm)	500 ~ 3,000		
Temperature (°C)	-25 ~ 80 (Continuous) / 100 (Peak)		
Rotation direction	Clockwise (View from drive shaft)		

SAFETY FIRST

ENGINE

DRIVING & CHASSIS


HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN

INDEX


COMPONENTS



LF1W483A


- | | | | |
|------------------|-----------------------|--------------------|------------------|
| (1) Housing 1 | (9) Driven Gear | (17) Seal | (25) Backup Ring |
| (2) Housing 2 | (10) Drive Shaft | (18) Seal | (26) Sleeve |
| (3) Housing 3 | (11) Driven Gear | (19) Square O-Ring | (27) Flange |
| (4) Rear Cover | (12) Bolt | (20) Square O-Ring | (28) Hub |
| (5) Front Cover | (13) Bolt | (21) Square O-Ring | (29) Hub |
| (6) Thrust Block | (14) Glove Screw Seal | (22) Shaft Seal | (30) Dowel Pin |
| (7) Thrust Plate | (15) Washer | (23) Snap Ring | (31) Dowel Pin |
| (8) Drive Gear | (16) Washer | (24) Backup Ring | (32) Bush |

EXTERIOR



LF1W484A

3.3 TRACK(HST) MOTOR



LT1W442A



LT1W462A



The track motors (1) are mounted on the left and right sides of the main frame.

It consists of the 2-speed variable axial piston motor and 2-speed planetary gearbox, and it is integrated with the parking brake package.


SPECIFICATIONS

Type		2 speed variable capacity shaft type piston motor
Capacity (2 speed)		LO : 31.5 cc/rev HI : 20.6 cc/rev
Max. system pressure		34.3 MPa
Max. speed (at min. capacity)		4,170 rpm
Parking brake	Torque (Calculation)	223 N·m
	Release pressure	Min 1.5 MPa Max 4.9 MPa
Gear box	Gear ratio	1/25.68
	Max. output torque (Calculation)	4,442 N·m
	Gear oil	API GL-4 Grade, SAE90 1.0L
	Weight	57kg

EXTERIOR & CIRCUIT DIAGRAM



3.4 MAIN CONTROL VALVE (MCV)




SPECIFICATIONS


ITEM	SPECIFICATION
Rated flow	80 l/min
Max. pressure	250 bar
Max. back pressure	25 bar
Operating temperature	-20°C ~ 80°C

The main control valve is located on the right upper section in the engine compartment and it receives hydraulic flow from the main pump. The main control valve is designed to control the area related to the attachment of the vehicle, and it is connected to the RCV (RH). Basically, it controls the loader's boom and bucket operation, supplying the lift cylinder and tilt cylinder with hydraulic flow. It is also connected to the self-leveling valve, ride control valve, and auxiliary output port.

CIRCUIT DIAGRAM



EXTERIOR



3.5 PILOT LOCK VALVE




The pilot lock valve is mounted on the left middle section of the main frame. When the seat bar is raised, this valve blocks the main oil gallery in order to stop the whole hydraulic operation. When the seat bar is lowered and the reset switch is turned on, the main oil gallery is restored for normal operation.


SPECIFICATIONS

ITEM	SPECIFICATION
Max. flow	10 ℓ/min
Max. pressure	40 bar
Accumulator capacity	0.32 ℓ
Free charge pressure	11 bar

CIRCUIT DIAGRAM



EXTERIOR



SAFETY FIRST

ENGINE

DRIVING & CHASSIS


HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN


INDEX

3.6 SELF LEVEL VALVE



The self-leveling valve is located on the left rear section of the main frame. This valve is designed to maintain the bucket parallel to the ground regardless of the lifting height of the bucket in order to prevent the falling of objects in the bucket as the angle of the bucket changes along with the lifting height of the boom while the boom is being raised.


CIRCUIT DIAGRAM



SPECIFICATIONS


ITEM	SPECIFICATION
A-port max. flow (Boom down)	69 ℓ/min
B-port max. flow (Boom up)	41 ℓ/min
Max. pressure	250 bar
Operating temperature	-20°C ~ 80°C

EXTERIOR



LF1W496A

3.7 HIGH FLOW VALVE




The high-flow valve is located under the floor of the cabin. When the switch is turned on to operate the high-flow valve, additional flow is supplied to the male side of the quick coupler for the external use of hydraulic pressure and this flow is used solely for the necessary operation.


SPECIFICATIONS

ITEM	SPECIFICATION
Max. flow	150 ℓ/min
Max. pressure	250 bar
Oil operating temperature	-20°C ~ 80°C

EXTERIOR & CIRCUIT DIAGRAM



LF1W499A



3.8 SHIFT VALVE

SAFETY FIRST

ENGINE


DRIVING & CHASSIS

HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN

INDEX




The shift valve is located on the left lower section of the main frame. This valve is for the 2-speed shift driving motor and is used to shift between the 1st gear speed and the 2nd gear speed.


SPECIFICATIONS

ITEM	SPECIFICATION
Max. operating pressure	280 bar or more
Max. flow	20 l/min or more
Port size	9/16 -18 UNF
Oil operating temperature	-20°C ~ 80°C


CIRCUIT DIAGRAM



EXTERIOR



3.9 PARKING VALVE




LT1W452A

The parking valve is located behind the shift valve on the left section of the main frame. The parking valve controls the parking brake located on the HST motor (track motor). When the hydraulic system normally operates with the key in the ON position, it discharges the hydraulic flow through the parking brake oil passage to compress the parking brake spring toward the release side, disengaging the parking brake.


SPECIFICATIONS

ITEM	SPECIFICATION
Max. operating pressure	280 bar or more
Max. flow	20 l/min or more
Oil operating temperature	-20°C ~ 80°C

CIRCUIT DIAGRAM



EXTERIOR



3.10 RIDE CONTROL VALVE [OPTION]

SAFETY FIRST

ENGINE


DRIVING & CHASSIS

HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN

INDEX





SPECIFICATIONS


ITEM	SPECIFICATION
Max. operating pressure	350 bar or more
Max. flow	0.5 ~ 40 l/min
Switching time	Opening ≤ 50 ms Closing ≤ 100 ms
Accumulator capacity	0.75 l
Max. allowable pressure	250 bar
Max. Free charge pressure	130 bar

The ride control valve is located under the front section of the cabin floor. The ride control valve helps stabilize the driving condition on a bumpy road by canceling some of the vibration coming from the road surface to the vehicle through its operation with the hydraulic flow control of the accumulator.

EXTERIOR & CIRCUIT DIAGRAM



3.11 QUICK ATTACHMENT VALVE





SPECIFICATIONS

ITEM	SPECIFICATION
Max. operating pressure	280 bar or more
Max. flow	20 l/min
A, B, P, T port size	9/16 - 18 UNF

The quick attachment valve is located in front of the main control valve on the right rear section of the main frame. The quick attachment valve controls the operation of the quick attachment cylinder with hydraulic flow when attaching and detaching the bucket to/from the equipment.

EXTERIOR & CIRCUIT DIAGRAM



SAFETY FIRST

ENGINE

DRIVING & CHASSIS

HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN

INDEX

3.12 RCV ASSEMBLY (LH)




The RCV assembly (LH) is located on the left side of the driver's seat. It is used to control not only the major driving functions such as the forward driving, reverse driving, left turn, and right turn, but also the auxiliary power operation, ride control, 2-speed shift, and horn.


SPECIFICATIONS

ITEM	SPECIFICATION
Min. initial pressure	30 bar
Max. initial pressure	100 bar
Max. back pressure	3 bar
Min. rated flow	5 ℓ/min
Max. rated flow	20 ℓ/min
Oil operating temperature	-10°C ~ 80°C

EXTERIOR & CIRCUIT DIAGRAM



LF1W4A15A



LF1W4A16B

3.13 RCV ASSEMBLY (RH)




The RCV assembly (RH) is located on the right side of the driver's seat. This is used to control not only the operation of the attachment, such as boom up, boom down, bucket rollback, and bucket dump, but also auxiliary hydraulic operation and electric operation.


SPECIFICATIONS

ITEM	SPECIFICATION
Min. initial pressure	30 bar
Max. initial pressure	100 bar
Max. back pressure	3 bar
Min. rated flow	5 ℓ/min
Max. rated flow	20 ℓ/min
Oil operating temperature	-10°C ~ 80°C

EXTERIOR & CIRCUIT DIAGRAM



LF1W4A18A




LF1W4A19B

3.14 HYDRAULIC CYLINDER

3.14.1 LIFT CYLINDER

SAFETY FIRST


ENGINE



DRIVING & CHASSIS

The lift cylinders (1) are located on the left and right sides of the main frame. These are single rod, double acting cylinders that are used to raise and lower the loader's boom.

HYDRAULIC SYSTEM



ELECTRIC SYSTEM

CABIN


INDEX

- | | | |
|-----------------------|-----------------------------------|----------------------------------|
| (1) Rear Cover & Tube | (7) Seal & Retaining Ring 55X45X3 | (13) PFC Support Ring |
| (2) Piston | (8) 605 Shaft Ring | (14) 754 Glyd Ring |
| (3) Rod Assembly | (9) O-Ring retaining ring | (15) Slotted Taper End Set Screw |
| (4) Front Cover | (10) O-Ring | (16) Composite Bushing |
| (5) Composite Bushing | (11) PFC Support Ring | (17) Joint Type Oil Cup 45° |
| (6) 839N Dust Ring | (12) O-Ring | |

3.14.2 TILT CYLINDER




The tilt cylinders (1) are located on the left and right sides of the quick coupler for the bucket. These are single rod, double acting cylinders that are used for rollback and the dump operation of the bucket.




- | | | |
|-----------------------|-------------------------------------|--------------------------------------|
| (1) Rear Cover & Tube | (8) PFC Support Ring | (15) 754 Glyd Ring |
| (2) Rod Assembly | (9) GSJ Step Ring | (16) PFC Support Ring |
| (3) Front Cover | (10) O-Ring | (17) Threaded O-Ring Flat Seal Joint |
| (4) Piston | (11) O-Ring | (18) Composite Bushing |
| (5) 839N Dust Ring | (12) O-Ring | (19) O-Ring |
| (6) O-Ring | (13) Lock Nut | |
| (7) 605 Shaft Ring | (14) Hexagon Socket Taper Set Screw | |

3.14.3 QUICK ATTACHMENT CYLINDER




The quick attachment cylinder (1) is on top of the quick coupler for the bucket, and it is a single rod, double acting cylinder used for automatic operation of attachment and detachment of the bucket using hydraulic flow.



- | | | |
|-----------------------|---------------------|--|
| (1) Rear Cover & Tube | (7) 605 Shaft Ring | (13) 754 Glyd Ring |
| (2) Rod Assembly | (8) Gsj Step Ring | (14) PFC Support Ring |
| (3) Piston | (9) O-Ring | (15) Lock Nut |
| (4) Front Cover | (10) O-Ring | (16) Cross Recessed Set Screw With Tapered End |
| (5) 839 Dust Ring | (11) PFC Guide Ring | (17) O-Ring |
| (6) O-Ring | (12) O-Ring | |

3.15 HYDRAULIC FILTER

3.15.1 RETURN FILTER



The return filter is located on the right upper section in the engine compartment. It is used to filter the oil after it is cooled down through the oil cooler before it is returned to the oil tank.

SPECIFICATIONS

ITEM	SPECIFICATION
Fineness	10 μm
Filtering dimension	4,410 cm ²
Rated flow	125 ℓ/min
By-pass valve setting pressure	1.7 bar (25 psi)
Operation pressure	12 bar (174 psi)
Oil operating temperature	-20°C ~ 110°C

SAFETY FIRST

ENGINE

DRIVING & CHASSIS


HYDRAULIC SYSTEM

ELECTRIC SYSTEM


CABIN

INDEX

EXTERIOR



COMPONENTS




LF1W4A28A

- (1) Filter case
- (2) Head
- (3) Nut

- (4) Spring
- (5) Sealing plate
- (6) Backup washer

- (7) By-pass valve

3.15.2 HST FILTER



The HST filter is located on the left upper section of the main frame, and it filters the hydraulic oil discharged from the charge pump to the quick attachment valve and HST pump.

SPECIFICATIONS

ITEM	SPECIFICATION
Fineness	10 μm
Filtering dimension	415 cm ²
Rated flow	35 l/min
By-pass valve setting pressure	6 bar (87 psi)
Operation pressure	310 bar (4,496 psi)
Oil operating temperature	-30°C ~ 90°C

SAFETY FIRST

ENGINE

DRIVING & CHASSIS


HYDRAULIC SYSTEM

ELECTRIC SYSTEM


CABIN

INDEX

EXTERIOR



COMPONENTS




LF1W4A31A

- (1) Filter element
- (2) Filter case
- (3) Body

- (4) Backup ring
- (5) Filter gasket
- (6) O-Ring

- (7) Steel plug
- (8) By-pass valve

3.15.3 OIL STRAINER



LF1W4A32A



LF1W4A33A




LF1W4A34A

The oil strainer is a suction filter located on the inlet on the front bottom section of the oil tank. It filters the oil before it is delivered to the main pump and high-flow pump.

SPECIFICATIONS

ITEM	SPECIFICATION
Number of folds	57
Effective filtering dimension	0.157 m ²

EXTERIOR




(1) Head
(2) End plate

(3) Inner core plate
(4) Filter

(5) O-Ring

LF1W4A35A


3.16 QUICK COUPLER (EXTERNAL HYDRAULIC)




LT1W456A

SPECIFICATIONS

ITEM	SPECIFICATION
Max. operating pressure	35 MPa
Rated flow	100 ℓ/min
Oil operating temperature	-25°C ~ 100°C



LF1W4A37A



LF1W4A38A

The quick coupler is located on the front left section of the boom structure and consists of the male (1), drain (2), and female (3) couplings.

SAFETY FIRST

ENGINE

DRIVING & CHASSIS

HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN

INDEX

SAFETY FIRST

ENGINE

DRIVING & CHASSIS



HYDRAULIC SYSTEM

ELECTRIC SYSTEM


CABIN

INDEX

EXTERIOR & CIRCUIT DIAGRAM



3.17 OIL COOLER



The oil cooler is located next to the radiator on the cooling unit. The oil cooler is used to cool the oil returned from the high-flow valve (optional) and MCV (Main Control Valve) before it is delivered to the oil tank.

SPECIFICATIONS

ITEM	SPECIFICATION
Heat rejection rate	24,000 kcal -5%
Flow	165 ℓ/min
Pressure drop	96.5 kPa
Core type	BAR PLATE
Core size	113(W) × 595(H) × 269(L) mm
Capacity	4.7 ℓ

SAFETY FIRST

ENGINE

DRIVING & CHASSIS


HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN

INDEX

4. OPERATING PRINCIPLE



LT1W457A

SAFETY FIRST

ENGINE

DRIVING & CHASSIS

HYDRAULIC SYSTEM


ELECTRIC SYSTEM

CABIN

INDEX

4.1 TRACK(HST) MOTOR

OVERVIEW



LT1W464A

This track (HST) motor is a 2-speed variable displacement axial piston hydraulic motor, and it functions as a hydrostatic motor to convert oil flow into mechanical rotation.

The hydrostatic motor converts hydraulic power into torque and velocity.

As the hydraulic oil under high pressure enters the input main port, it applies pressure on the rear section of the piston which then moves downward along the swash plate.

When the piston is returned onto the swash plate again, the hydraulic oil is discharged through the output main port.

This rotating piston is located in and connected to the cylinder block with its shaft, and its output torque is delivered to the 1st sun gear of the gearbox.

The swash plate of this motor can be switched between the minimum angle (12°) and the maximum angle (18°) to increase the torque and velocity. While there is no control pressure applied on the piston, the motor operates at full displacement (capacity) and delivers the full output torque.

When the control pressure is applied on the piston, its spool is moved and high system pressure is transferred to the servo piston, thereby changing the motor's displacement to the minimum.

The motor in the minimum displacement state delivers the highest velocity. If the shift orifice is selected under this state, the shift operation can be retarded.

On the other hand, the gearbox adopted for the tractor motor is designed to increase the torque and decrease the speed, and it consists of the 2-speed planetary gear assembly that has the two gears connected in series.

The planetary gear assembly consists of the sun gear, ring gear, and planetary gear set that is installed on the carrier. The load is uniformly distributed at the engagement points of the planetary gears and ring gear with the sun gear located in the center.

The hydrostatic track motor runs the 1st sun gear first, and then runs the 1st planetary gears inside the ring gear to rotate the 1st gear carrier.


In addition, the 1st gear carrier is directly connected to the 2nd sun gear, the 2nd gear carrier is a part of the motor housing, and the 2nd planetary gears deliver the torque to the ring gear.

As a result, the hub is rotated in the reverse rotating direction of the input. The planetary gears are supported by the bearings and the final output hub is also supported by the bearing to process massive external load.



REMARK

- Do not use the shift control pressure function in the range between 3 bar and 15 bar to prevent the unstable position of the swash plate.



The motor can be switched into the low-torque high-speed mode in case that the equipment needs to be operated at a high speed with low motor load. This function is achieved by the functioning valve inside the motor that cuts the flow required to rotate the motor in half.

- Loop flushing valve

The loop flushing valve is used to change the hydraulic oil in the system circuit to decrease the transmission temperature or remove excessive contamination in the closed circuit.


The end cap is equipped with the shuttle spool and charge relief valve to provide the loop flushing function.

The shuttle valve selects the low system pressure, and the charge relief valve adjusts the charge pressure level.

In addition, the shuttle valve is centered by its spring, so the loss of the high-pressure flow does not occur in the circuit.


4.2 SELF LEVEL VALVE

COMPONENTS



- (1) Flow divider spool
- (2) solenoid valve
- (3) Fixed orifice (Ø2.0)
- (4) Control orifice
- (5) Flow check valve
- (6) Cylinder lock valve
- (7) Lock valve damping orifice (Ø0.7)
- (8) Main relief valve
- (9) Anti-chattering orifice (Ø2.0)

CIRCUIT DIAGRAM



SAFETY FIRST

ENGINE

DRIVING & CHASSIS



HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN

INDEX



RAISING THE BOOM WITH THE TILT CYLINDER FULLY EXTENDED



In the self-leveling state, the lift cylinder continues to rise even when extending it fully or moving the bucket spool to the dump position.

This is because the main relief valve (8) opens and the oil supplied to the tilt cylinder head port is returned to the tank, preventing the lift cylinder from stopping during the lift operation.

RETRACTING THE LIFT CYLINDER



As the boom spool is pushed, the hydraulic oil is directly led into port A of the self-leveling valve.

This hydraulic oil enters the self-leveling valve and opens the lift check valve (2). Then, it flows into the rod port of the lift cylinder due to the pressure difference between port B and flow divider spool, resulting in no extension of the tilt cylinder.

SAFETY FIRST

ENGINE

DRIVING & CHASSIS


HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN


INDEX

EXTENDING THE TILT CYLINDER




LF1W4A56B


RETRACTING THE TILT CYLINDER



LF1W4A58B



LT1W404A



LT1W405A

As the bucket spool is pulled, the hydraulic oil is directly led to the head port of the tilt cylinder from the control valve. The hydraulic oil flows to port C, but it is also blocked by the flow check valve (5).

The oil from the rod port flows directly to the control valve and returns to the tank.

The returned oil goes to port D of the self-leveling valve, but it is blocked by the cylinder lock valve (6).


As the bucket spool is pushed, the hydraulic oil is directly led into the rod port of the tilt cylinder.

The hydraulic oil also flows to port D of the self-leveling valve through the connection T, but it is blocked by the cylinder lock valve (6).

The oil that has returned from the head port flows directly to the control valve and returns to the tank.

The oil from the head port also flows to port C of the self-leveling valve through the connection T, but it is blocked by the flow check valve (5).

4.3 RCV (R/H)



SAFETY FIRST

ENGINE

DRIVING & CHASSIS


HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN

INDEX

4.3.1 BOOM OPERATION (UP)



LF1W4A60C

RCV(RH)(Joystick lever) pulled backward

- 1) Pilot line : RCV-RH → MCV (switches to UP direction)
- 2) Pump supply line : Gear pump → MCV → Lift cylinder head → Boom up
- 3) T line : Lift cylinder rod → Self-leveling valve port A → MCV → Oil tank

SAFETY FIRST

ENGINE

DRIVING & CHASSIS


HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN

INDEX

4.3.2 BOOM OPERATION (DOWN)



RCV(RH)(Joystick lever) pulled forward

- 1) Pilot line : RCV-RH → MCV (switches to DOWN direction)
- 2) Pump supply line : Gear pump → MCV → Lift cylinder rod → Boom down
- 3) T line : Lift cylinder head → MCV → Oil tank

4.3.3 SELF LEVELING

SAFETY FIRST

ENGINE






DRIVING & CHASSIS

HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN


INDEX



► SELF LEVELING FUNCTIONS

The rollback of the bucket during boom up operations reduces work efficiency. The self-leveling valve diverts some of the flow from the lift cylinder toward the tilt cylinder in order to maintain the horizontal position of the bucket. This function is known as self-leveling.

- Type : Hydraulic (Boom up leveling)
- Flow rate : 49 ℓ/min (Boom up)
- Maximum operation pressure : 210 bar



► **BUCKET LOWERED ON THE GROUND**



Boom up → Port B → Port A, Port C → Bucket dump

► **TILT CYLINDER BEING FULLY EXTENDED**

Boom up → Port B → Port A → MCV → Oil tank

* The proportion of the division of the flow rate is determined by the setting of the adjustment orifice (4).


4.3.4 RIDE CONTROL [OPTION]



► **RIDE CONTROL FUNCTIONS**

When driving on uneven ground, the gravel in the bucket may pour out as the machine shakes due to the force applied to the lift cylinder. When the ride control function is used, the accumulator absorbs this force to enable more stable operation while the skid loader is traveling.

4.3.5 BUCKET OPERATION (ROLL BACK)



LF1W4A68C

RCV(RH)(Joystick lever) pushed to the left

- 1) Pilot line : RCV-RH → MCV (switches to rollback direction)
- 2) Pump supply line : Gear pump → MCV → Tilt cylinder rod → Bucket roll back
- 3) T line : Tilt cylinder head → MCV → Oil tank

SAFETY FIRST

ENGINE

DRIVING & CHASSIS


HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN

INDEX

4.3.6 BUCKET OPERATION (DUMP)



RCV(RH)(Joystick lever) pushed to the right

- 1) Pilot line : RCV-RH → MCV (switches to dump direction)
- 2) Pump supply line : Gear pump → MCV → Tilt cylinder head → Bucket dump
- 3) T line : Tilt cylinder rod → MCV → Oil tank

4.3.7 QUICK ATTACHMENT

SAFETY FIRST

ENGINE



DRIVING & CHASSIS

HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN

INDEX





► QUICK ATTACHMENT FUNCTIONS

Previously, in order to mount the bucket on the skid loader, the attachment lever had to be locked manually. As a result, there was the inconvenience of having to leave the machine in order to mount the bucket. As shown in the figure above, the quick attach cylinder and valve enable the operator to mount the bucket with a single button without having to leave the machine itself.

4.3.8 EXTERNAL IMPLEMENT



GENERAL



► EXTERNAL IMPLEMENT FUNCTIONS

Necessary when using an implement aside from the bucket, this function actuates the implement with hydraulics by connecting the quick coupler and implement with hydraulic hoses

HIGH FLOW




► HIGH FLOW VALVE FUNCTIONS

This option is necessary when using an implement which requires a relatively high flow rate. It increases the flow rate to the quick coupler by means of a high-flow pump and valve.

- Max. operating pressure : 210 bar
- Max. flow : 150 l/min

MALE / HIGH FLOW


- █ Pump supply line
- █ High flow line
- █ T Line



LF1W4A77C

RCV(RH)(Joystick lever) "male" button pushed

- 1) MCV solenoid "On" → Switches to Male
- 2) Pump supply line : Gear pump → MCV → Quick coupler (male)
- 3) T line : Quick coupler (female) → MCV → Oil tank



REMARKS

- The female coupler shuts off the high-flow function electrically, so pressing the high-flow switch does not activate the high-flow function.


RCV(RH)(Joystick lever) "Female" button pushed

- 1) MCV solenoid "On" → Switches to Female
- 2) Pump supply line : Gear pump → MCV → Quick coupler (female)
- 3) T line : Quick coupler (male) → MCV → Oil tank

SAFETY FIRST
ENGINE
DRIVING & CHASSIS
HYDRAULIC SYSTEM
ELECTRIC SYSTEM
CABIN
INDEX

5. CHECK & ADJUSTMENT

5.1 MAIN CONTROL VALVE (MCV) SYSTEM PRESSURE



LT1W467A

Install a pressure gauge on the position (1), and then move the RCV (RH) (joystick lever) to the right with the engine running at 2,550 RPM. The pressure gauge should indicate 230 bar. If not, adjust or replace the main relief valve on the position (2).

(Port size (1) : M16 x 2.0)

SAFETY FIRST

ENGINE

DRIVING & CHASSIS


HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN

INDEX


5.2 MAIN PUMP FLOW RATE



Install a flowmeter on position (3) and measure the flow with the engine running at 2,550 RPM. The flowmeter should indicate 66 lpm. If the measured flow is below 52.8 lpm, the main pump is excessively worn. In this case, repair or replace it.

(Port size (3) : O-ring boss elbow SAE 1-1/16-12UN)

5.3 CHARGING PUMP PRESSURE




Install a pressure gauge on the position (4) and measure the pressure with the engine idling at a low speed. The gauge should indicate 23-25 bar. If not, replace the relief valve of the charge pump as it cannot be adjusted.

(Port size (4) : O-ring boss connector 7/8-14UNF)

(Almost identical pressure is measured at the parking solenoid valve supply section that has a pressure port.)

5.4 HST (DRIVING) PUMP PRESSURE



For the HST (driving) pump valve block, the four relief valves should be inspected. All of the relief valves have the same setting and they are located as shown in the above figure.


Example: The shaded area in the above figure for the driving circuit hydraulic oil flow diagram shows the flow of the hydraulic oil for the inspection of the relief valve cartridge when the right-hand track (HST) motor moves in the forward driving direction.

Install a pressure gauge on the position (6), run the engine at 2,550 RPM, and then raise the seat bar to apply the parking brake. Push the RCV (RH) (joystick lever) forward slowly to bring driving to a stop. The gauge should indicate 360 bar at this moment. If the measured pressure is incorrect, replace the relief valve cartridge under the port, as it is not adjustable.

According to the hydraulic oil flow diagram above, install pressure gauges on the positions (5 & 6) and test the three relief valve cartridges. With the engine running at 2,550 RPM, raise the seat bar to apply the parking brake. Then, move the RCV (LH) and RCV (RH) (joystick levers) forward/backward slowly to bring driving to a stop.

(Port size (5), (6) : O-ring boss connector 9/16-18UNF)

5.5 HST (DRIVING) PUMP FLOW RATE




Before performing the pump oil flow test, lift up the loader and use jack stands or chocks to keep the crawler off the ground.

Perform the oil flow test to measure the oil flow of the left-hand and right-hand HST (driving) pumps. According to the above HST (driving) circuit oil flow diagram, install flowmeters on the positions (5 & 6) and test the forward driving oil flow of the track (HST) motors (LH/RH). With the engine running at 1,800 RPM, the gauge should indicate 60 lpm. At this moment, fully push the RCV (LH) joystick lever forward/backward to a stop.

If the flow is less than the specified capacity, the HST (driving) pump is worn, so repair or replace it with a new one.



5.6 RELIEF PRESSURE SETTING



1. Install a pressure gauge (300 bar or higher) on the pressure gauge port (M16 P2.0) of the main pump.
2. After starting the engine, run it at $2,550 \pm 50$ rpm and move the bucket to the lowest position.
3. Raise the oil temperature up to $50^\circ \pm 5^\circ$. Then, check the pressure when the main relief valve is activated while lowering the boom.
4. If the measured pressure is not 230 ± 5 bar, adjust the relief valve of the MCV (Main Control Valve) for correct specified pressure.

REMARKS

RELIEF VALVE ADJUSTMENT



- After securing the adjusting bolt (A) from rotating, unscrew the mounting nut (B) and turn the adjusting bolt to set the relief valve pressure. (Clockwise: increasing pressure, Counterclockwise: decreasing pressure)
- After setting the correct pressure, tighten the mounting nut (B) fully with the adjusting bolt (A) fixed.
- Tools needed
 - Adjusting bolt (A) : 5 mm L Wrench
 - Mounting nut (B) : 13 mm or 1/2 inch Spanner

6. TROUBLESHOOTING

SYMPTOM	CAUSES	REMEDY
The hydraulic oil pressure is weak. (The oil does not flow in the charge and main pumps.)	<ul style="list-style-type: none"> Insufficient oil in the tank Damaged coupling between the engine and pump Malfunctioning main pump Defective main pump shaft Faulty spline coupling between front/rear pumps 	<ul style="list-style-type: none"> Check for leakage and add the oil to the tank. Check for any damaged part and replace it as necessary. Check for proper alignment. Check for any damaged part, and replace it as necessary. Check for any damaged part, and replace it as necessary. Check for any damaged part, and replace it as necessary.
	<ul style="list-style-type: none"> Locked auxiliary valve spool Disconnected or stuck component linkage Defective relief valve and repair impossible 	<ul style="list-style-type: none"> Unlock it. Check and adjust or repair it. Check the pressure and repair as necessary.
The hydraulic operation is not smooth, but intermittent.	<ul style="list-style-type: none"> Insufficient oil in the tank Worn or loose component linkage Air in the hydraulic system Rod check valve inoperable The control valve spool spring won't return 	<ul style="list-style-type: none"> Check for leakage and add oil to the tank. Check and adjust or replace any damaged part. Check for oil leakage between the oil tank and pump. Operate the lift cylinder several times to bleed the system. Check and replace any damaged part. Check and replace any damaged part.
The boom rises slowly.	<ul style="list-style-type: none"> Insufficient oil in the tank Defective component linkage Locked auxiliary switch Exceeding rated capacity Excessively low engine RPM 	<ul style="list-style-type: none"> Check for leakage and add the oil to the tank. Check and adjust it. Unlock the auxiliary switch. Reduce the load. Check and readjust the engine RPM.
The boom rises slowly at the maximum RPM.	<ul style="list-style-type: none"> Defective or incorrectly adjusted relief valve Leakage from the lift cylinder piston seal Internal leakage from the main pump Internal leakage from the control valve 	<ul style="list-style-type: none"> Check the pressure and adjust or repair it. Check for leakage of the piston seal and repair it as necessary. Test and repair the main pump. Check and repair the control valve.
The boom and bucket cylinder cannot overcome the load.	<ul style="list-style-type: none"> External oil leakage between the control valve and cylinder Incorrectly centered control valve spool Oil leakage from one or both lift cylinder piston seal(s) Internal leakage from the control valve 	<ul style="list-style-type: none"> Check and repair it. Check if the control lever is stuck and repair it. Check if the spring return device of the control valve spool is damaged. Check for leakage of the piston seal and repair it as necessary. Check and repair the control valve.
The hydraulic oil warning lamp is turned on. The hydraulic oil is overheated.	<ul style="list-style-type: none"> Insufficient oil in the tank Clogged or contaminated oil cooler or engine radiator Locked auxiliary switch Excessively low engine RPM Engine cooling fan rotating in the opposite direction Defective or incorrectly adjusted relief valve Defective temperature sensor switch Faulty hydraulic oil 	<ul style="list-style-type: none"> Check for leakage and add the oil. Clean the oil cooler fins. Unlock the auxiliary switch. Check and readjust the engine RPM. Check and reinstall the fan. Check and adjust the pressure. Replace Replace

SAFETY FIRST

ENGINE

DRIVING & CHASSIS

HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN


INDEX

7. EXPLODED VIEW

REMARKS

- The manufacturing parts are subject to change without notice. Therefore, check the parts catalog or electronic manual for latest information.

7.1 LF1-G211003 OIL TANK SUB GROUP



LT1W4A52A

COMPONENTS

- | | | | |
|-------------------|-------------------|-------------------|---------------------------|
| (1) Strainer, Oil | (8) Connector | (15) Band, Hose | (22) Hose, Air Breather 1 |
| (2) Bolt, Washer | (9) Elbow | (16) Joint Pin | (23) Hose, Air Breather 2 |
| (3) Elbow-T Type | (10) Connector | (18) Bolt | (24) Connector |
| (4) Elbow | (11) Band, Hose | (17) Tube, Oiling | (25) Clmap, Hose |
| (5) Elbow-T Type | (12) Air Breather | (19) Plug, Oil | |
| (6) Connector | (13) Bolt | (20) Hose | |
| (7) Elbow | (14) Hose | (21) Hoseclamp | |

7.2 LF1-G214003 OIL COOLER GROUP

SAFETY FIRST

ENGINE


DRIVING & CHASSIS

HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN

INDEX



LT1W4A53A

COMPONENTS

- | | | |
|-----------------------------|-------------------------|-------------------|
| (1) Hose, HYD-MCV | (5) Bolt | (9) Bolt, Washer |
| (2) Elbow | (6) Hose, HYD-Filter OT | (10) Washer, Seal |
| (3) Return-Filter | (7) Hose, HYD-OC Filter | (11) Band, Cord |
| (4) Elbow-PF 1 1 7/16-12 UN | (8) Tube, HYD-MCV OC | |

7.3 LF1-G221002 MAIN CONTROL VALVE GROUP

SAFETY FIRST

ENGINE


DRIVING & CHASSIS

HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN

INDEX



LT1W4A54A

COMPONENTS

- | | | |
|------------------|--------------------------|-------------------------|
| (1) MCV | (6) Hose, HYD-OL Pilot T | (11) Connector |
| (2) Elbow | (7) Hose, HYD-OL Pilot V | (12) Hose, HYD-Pump MCV |
| (3) Washer Bolt | (8) Connector | (13) Washer, Seal |
| (4) Elbow-T Type | (9) Elbow | (14) Wir'g Clamp |
| (5) Elbow | (10) Connector | |

7.4 LF1-G221503 JOYSTICK GROUP

SAFETY FIRST

ENGINE


DRIVING & CHASSIS

HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN

INDEX



LT1W4A55A

COMPONENTS

- | | | |
|-------------------------|--------------------------|--------------------------|
| (1) Lever, Joystick-RH | (7) Hose, HYD-RCV(RH) 2 | (13) Hose, HYD-RCV(LH) C |
| (2) Bolt, Flange | (8) Hose, HYD-RCV(RH) 3 | (14) Hose, HYD-RCV(LH) D |
| (3) Connector | (9) Hose, HYD-RCV(RH) 4 | (15) Hose, HYD-RCV(LH) E |
| (4) Hose, HYD-RCV(RH) P | (10) Hose, HYD-RCV(RH) T | (16) Hose, HYD-RCV(LH) F |
| (5) Connector | (11) Lever, Joystick-LH | (17) Hose, HYD-RCV(LH) T |
| (6) Hose, HYD-RCV(RH) 1 | (12) Hose, HYD-RCV(LH) P | (18) Hose, HYD-RCV(LH) 5 |

7.5 LF1-G222003 AUXILIARY HYDRAULIC GROUP

SAFETY FIRST

ENGINE


DRIVING & CHASSIS

HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN

INDEX



COMPONENTS

- | | | |
|-----------------------------|----------------------------|------------------------------|
| (1) Pilot Lock Valve | (5) Elbow | (9) Bolt |
| (2) Bolt, Washer | (6) Hose, HYD-Pilot Lock T | (10) Connector |
| (3) Elbow | (7) Elbow-T Type | (11) Hose, HYD-Pilot Lock P2 |
| (4) Hose, HYD-Pilot Lock P1 | (8) Plate-Port | (12) Elbow-T Type |

7.6 LF1-G223002 LIFT CYLINDER GROUP

SAFETY FIRST

ENGINE


DRIVING & CHASSIS

HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN

INDEX



COMPONENTS

- | | | |
|------------------------|-----------------------|------------------------------|
| (1) Hose, HYD-MCV Lift | (5) Bolt, Washer | (9) Hose, HYD-Lift CYL(Down) |
| (2) Tube, HYD | (6) Nut | (10) Hose, HYD-Lift CYL(Up) |
| (3) Tube, HYD-Up | (7) Cylinder, Lift-RH | (11) Cap, Plug-13_16 |
| (4) Bracket | (8) Cylinder, Lift-LH | |

7.7 LF1-G223504 SELF LEVELING GROUP

SAFETY FIRST

ENGINE


DRIVING & CHASSIS

HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN

INDEX



LT1W4A58A

COMPONENTS

- (1) Valve, Selfe Leveling
- (2) Hose, HYD-SL B
- (3) Washer Bolt

- (4) Connector
- (5) Hose, HYD-SL A
- (6) Connector

- (7) Connector
- (8) Hose, HYD-SL C
- (9) Hose, HYD-SL D

7.8 LF1-G224502 TILT CYLINDER GROUP

SAFETY FIRST

ENGINE


DRIVING & CHASSIS

HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN

INDEX




LT1W4A59A

COMPONENTS

- | | | |
|-----------------------------|------------------------------|----------------------------|
| (1) Tube, HYD | (10) Clamp, Pipe | (19) Hose, HYD-BK Dump 3 |
| (2) Tube, HYD | (11) Bolt | (20) Cylinder, Tilt-RH |
| (3) Bracket | (12) Hose, HYD-BK Rollback 2 | (21) Cylinder, Tilt-LH |
| (4) Bolt, Washer | (13) Hose, HYD-BK Dump 2 | (22) Cover, Cyl-RH |
| (5) Nut | (14) Tube, HYD | (23) Cover, Cyl-LH |
| (6) Hose, HYD-BK Dump 1 | (15) Bolt, Flange | (24) Bolt, Flange |
| (7) Hose, HYD-BK Rollback 1 | (16) Tube, HYD | (25) Holder, Pipe-Rubber 2 |
| (8) Tube, HYD | (17) Bolt Flange | (26) Band, Cord |
| (9) Tube, HYD | (18) Hose, HYD-BK Rollback 3 | |

7.9 LF1-G225003 QUICK ATTACH CYLINDER GROUP



LT1W4A60A

COMPONENTS

- | | | |
|--------------------------|------------------------------|-------------------------------|
| (1) Valve, Quick Attatch | (8) Hose, HYD-QA A(Unlock) 1 | (15) Clamp |
| (2) Washer Bolt | (9) Hose, HYD-QA B(Lock) 1 | (16) Bolt, With Washer |
| (3) Elbow | (10) Tube, HYD | (17) Hose, HYD-QA B(Lock) 2 |
| (4) Hose, HYD-QA P | (11) Tube, HYD | (18) Hose, HYD-QA A(Unlock) 2 |
| (5) Elbow | (12) Nut | (19) Quick Attach Cylinder |
| (6) Hose, HYD-QA T | (13) Bracket | (20) Bracket |
| (7) Connector | (14) Bolt, Washer | (21) Holder, Pipe-Rubber 1 |

7.10 LF1-G226002 DRAIN VAVLE GROUP

SAFETY FIRST

ENGINE


DRIVING & CHASSIS

HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN

INDEX



LT1W4A61A

COMPONENTS

- (1) Hose, HYD -DV A
- (2) Elbow

- (3) Valve, Drain
- (4) Bolt

- (5) Connector
- (6) Hose, HYD -DV B

7.11 LF1-G231003 HST GROUP

SAFETY FIRST

ENGINE


DRIVING & CHASSIS

HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN

INDEX



LT1W4A62A

COMPONENTS

- | | | |
|----------------------------|--------------------------------|----------------------------|
| (1) Pump, HST | (16) Elbow-T Type | (31) Washer |
| (2) Washer, Spring | (17) Tube, HYD | (32) Bolt |
| (3) Bolt | (18) Washer, Plain | (33) Elbow |
| (4) Elbow | (19) Bolt | (34) Elbow |
| (5) Elbow | (20) Connector | (35) Hose, HYD-Motor T(RH) |
| (6) Hose, HYD-HST A(LH) | (21) Elbow-T Type | (36) Hose, HYD-Motor T(LH) |
| (7) Hose, HYD-HST B(LH) | (22) Connector | (37) Elbow |
| (8) Hose, HYD-HST C(RH) | (23) Hose, HYD-HST T | (38) Hose, HYD-Parking(LH) |
| (9) Elbow | (24) Valve, Shift | (39) Hose, HYD-Parking(RH) |
| (10) Connector | (25) Bolt, Washer | (40) Valve, Parking |
| (11) Hose, HYD-HST D(RH) | (26) Elbow-T Type | (41) Bolt |
| (12) Elbow-T Type | (27) Hose, HYD-Shift Motor(LH) | (42) Hose, HYD-Parking T |
| (13) Hose, HYD-Parking P | (28) Hose, HYD-Shift Motor(RH) | (43) Elbow-T Type |
| (14) Hose, HYD-HST Shift P | (29) Hose, HYD-Shift T | (44) Adapter -Port PF1_4 |
| (15) Elbow | (30) Motor, HST 2-Speed Track | |

8. HYDRAULIC SYSTEM MAINTENANCE

8.1 MAIN PUMP DETACH

SAFETY FIRST

ENGINE


DRIVING & CHASSIS

HYDRAULIC SYSTEM


ELECTRIC SYSTEM

CABIN


INDEX




1. Open or remove the cabin.





2. Drain the hydraulic oil from the oil tank.



3. Disconnect the high-flow pump hydraulic hose (1), charge pump hydraulic hose (2), and main pump hydraulic hose (3).



4. Disconnect the suction hose (1) from the main pump and the suction hose (2) from the high-flow pump.




5. Unscrew the main pump mounting bolts, nuts (1)(2EA) to remove the main pump assembly (2).

Mounting bolt (nut)


**tightening torque..... 102.9 ~ 117.6 N·m
10.5 ~ 12.0 kgf·m
75.6 ~ 86.4 lb·ft**

8.2 HST PUMP DETACH

1. Remove the engine assembly. (See the engine removal instructions)




LT1W225A




LT1W226A

2. Unscrew the engine flywheel housing mounting bolts (1)(7EA) to remove the HST pump assembly (2).




LF1W4A99A



LF1W4B01A

3. Unscrew the hub mounting bolts (1) on the HST pump assembly housing section to remove the hub assembly (2).



REMARKS



LF1W4B04A

- When installing the hub on the pump housing, its section marked "E" should face the engine. In addition, tighten the mounting bolts to the specified torque.

Mounting bolt
tightening torque 196.0 ~ 215.6 N·m
20.0 ~ 22.0 kgf·m
144.0 ~ 158.4 lb·ft



4. Unscrew the housing mounting bolts (1) on the HST pump assembly to remove the housing (2).


REMARKS

- When reinstalling the housing mounting bolt, apply the sealant (LOCTITE 271 or equivalent) on its threads and tighten it to the specified torque.

Mounting bolt	
tightening torque	196.0 ~ 225.4 N·m
	20.0 ~ 23.0 kgf·m
	144.0 ~ 165.6 lb·ft

REMARKS


ELBOW ASSEMBLY



- **Tightening torque**
 - ①, ② (1·5/16-12 UN) : 270.0 ~ 300.0 N·m
27.55 ~ 30.61 kgf·m
198.4 ~ 220.4 lb·ft
 - ③ (7/8-14 UNF) : 98.0 ~ 110.0 N·m
10.0 ~ 11.22 kgf·m
72.0 ~ 80.8 lb·ft
 - ④ (9/16-18 UNF) : 33.0 ~ 35.0 N·m
3.37 ~ 3.57 kgf·m
24.3 ~ 25.7 lb·ft
 - ⑤ (PF1/4) : 34.3 ~ 39.2 N·m
3.5 ~ 4.0 kgf·m
25.2 ~ 28.8 lb·ft
- **Assembly angle**
 - ① : 40°
 - ③ : 30°
 - ④ : 35°

REMARKS

ELBOW ASSEMBLY




LT1W4A65A

- **Tightening torque**
 - ①, ③ (1-5/16-12 UN) : 270.0 ~ 300.0 N·m
27.55 ~ 30.61 kgf·m
198.4 ~ 220.4 lb·ft
 - ② (1-1/16-12 UN) : 170.0 ~ 183.0 N·m
17.35 ~ 18.67 kgf·m
124.9 ~ 134.4 lb·ft
 - ④ (7/8-14 UNF) : 98.0 ~ 110.0 N·m
10.0 ~ 11.22 kgf·m
72.0 ~ 80.8 lb·ft
 - ⑤, ⑥, ⑦ (9/16-18 UNF) : 33.0 ~ 35.0 N·m
3.37 ~ 3.57 kgf·m
24.3 ~ 25.7 lb·ft
 - ⑧ (PF1/4) : 34.3 ~ 39.2 N·m
3.5 ~ 4.0 kgf·m
25.2 ~ 28.8 lb·ft
- **Assembly angle**
 - ①, ③ : 30°
 - ④ : 90°
 - ⑤ : 20°


REMARKS

ELBOW ASSEMBLY



LT1W4A66A

- **Tightening torque**
 - ①, ② (1-5/16-12 UN) : 270.0 ~ 300.0 N·m
27.55 ~ 30.61 kgf·m
198.4 ~ 220.4 lb·ft
- **Assembly angle**
 - ① : 70°



LT1W4A67A

8.3 MAIN PUMP, CHARGE PUMP, HIGH FLOW PUMP DISASSEMBLY

SAFETY FIRST

ENGINE



DRIVING & CHASSIS

HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN

INDEX




- (1) Main pump
- (2) Charge pump
- (3) High flow pump


REMARKS

ELBOW ASSEMBLY



L, LQ MODEL



LQF MODEL




- **Tightening torque**
 - ① (7/8-14 UNF) : 98.0 ~ 110.0 N·m
10.0 ~ 11.22 kgf·m
72.0 ~ 80.8 lb·ft
 - ② (1-1/16-12 UN) : 170.0 ~ 183.0 N·m
17.35 ~ 18.67 kgf·m
124.9 ~ 134.4 lb·ft
 - ③ (PF1/4) : 34.3 ~ 39.2 N·m
3.5 ~ 4.0 kgf·m
25.2 ~ 28.8 lb·ft
- **Assembly angle**
 - ① : 15°
 - ② : 90°




1. Unscrew the rear cover mounting bolts (1)(4EA), and then remove the high-flow pump (2) and charge pump (3) from the main pump (4).

► HIGH FLOW PUMP DISASSEMBLY




1. Remove the thrust plate assembly (1) from the pump housing.




2. Remove the drive gear (1) and driven gear (2) from the thrust plate.

► CHARGE PUMP DISASSEMBLY





1. Remove the cover (1) and thrust plate assembly (2) from the charge pump housing.








2. Remove the drive gear (1) and driven gear (2) from the thrust plate.

REMARKS




- When installing the charge pump and high-flow pump, the thrust plate seal opening (A) should face the suction side.

► MAIN PUMP DISASSEMBLY




1. Unscrew the hex wrench bolts (1)(4EA) and then remove the front cover (2).

2. Remove the thrust plate assembly (1) from the main pump body.




3. Remove the drive gear (2) and driven gear (3) from the thrust plate.



 REMARKS

- The seal opening (A) should face the suction side.


8.4 TRACK(HST) MOTOR DISASSEMBLY



1. Unscrew the cover mounting flange bolts (1)(2EA) on the top of the track frame to remove the cover (2).




2. Release the tension of the crawler tension adjuster by unscrewing the grease nipple valve (1) of the tension adjuster and draining the grease from the inside. Then, loosen the crawler (2) to remove it.



LT1W4A03A

3. Remove the cover frame (1).




LT1W4A04A

4. Disconnect the parking valve hydraulic hose (1) and shift valve hydraulic hose (2) of the track motor.

REMARKS


ASSEMBLY ANGLE AND TIGHTENING TORQUE WHEN INSTALLING THE ELBOW

TRACK(HST) 2-SPEED MOTOR(RH)]



LT1W4A50A

TRACK(HST) 2-SPEED MOTOR(RH)]





LT1W4A70A

- **Tightening torque**
 - ① (PF 1/4) : 25.0 ~ 30.0 N·m
2.55 ~ 3.06 kgf·m
18.4 ~ 22.0 lb·ft
 - ② (9/16-18 UNF) : 33.0 ~ 35.0 N·m
3.37 ~ 3.57 kgf·m
24.3 ~ 25.7 lb·ft
 - ③ (PF1/4) : 140.0 ~ 160.0 N·m
14.29 ~ 16.33 kgf·m
102.9 ~ 117.6 lb·ft
 - ④ (1 1/16-12 UN) : 170.0 ~ 183.0 N·m
17.35 ~ 18.67 kgf·m
124.9 ~ 134.4 lb·ft
 - ⑤ (PF 1/2) : 75.0 ~ 95.0 N·m
7.65 ~ 9.69 kgf·m
55.1 ~ 69.8 lb·ft
- **Assembly angle**
 - ①, ④ : 15°
 - ⑤ : 90°


※ The track motor (LH) is symmetrical for the track motor (RH)



5. Disconnect the oil tank hydraulic hose (1).



6. Disconnect the hydraulic hose (1) of the HST pump (forward driving) and hydraulic hose (2) of the HST pump (reverse driving).



7. Unscrew the track motor mounting bolts (1)(7EA) to remove the track motor assembly (2). If necessary, unscrew the sprocket mounting bolts (3) from the track motor assembly to remove the sprocket. When installing the track motor and sprocket, apply LOCTITE 271 or equivalent to mounting bolts (1, 3) and tighten them to the specified torque.

Mounting bolt (M16 P2.0)

tightening torque..... 308.7 ~ 340.1 N·m
 31.5 ~ 34.7 kgf·m
 226.8 ~ 249.8 lb·ft

8.5 MAIN CONTROL VALVE DETACH & DISASSEMBLY

SAFETY FIRST

ENGINE


DRIVING & CHASSIS

HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN


INDEX





1. Disconnect the hydraulic tube (LF13-0365) (1).




1-3. Disconnect the hydraulic hose (1) to the hydraulic tube from the outside of the right section of the main frame.





1-1. Disconnect the hydraulic hoses (1 & 2) to the hydraulic tube from the inside of the main frame.




1-2. Disconnect the hydraulic hose (1) to the hydraulic tube from the outside of the left section of the main frame.




1-4. Remove the covers (1 & 2) from the left and right sides of the main frame.






1-5. Unscrew the left-hand and right-hand hydraulic tube mounting nuts (1) to disconnect the hydraulic tubes (2).



2. Hydraulic tube (LF13-0363)(2) detach




2-1. Disconnect the hydraulic hose (1) to the hydraulic tube from the inside of the main frame.




2-2. Disconnect the hydraulic hoses from the left section (1) and right section (2) of the main frame.


2-3. Unscrew the left-hand and right-hand hydraulic tube mounting nuts (1) to disconnect the hydraulic tubes (2).




3. Disconnect the tilt cylinder rollback hydraulic hose (1) and tilt cylinder dump hydraulic hose (2) from the main control valve.




6. Disconnect the external hydraulic (male) hose (1) and self-leveling hydraulic hose (2).




4. Disconnect the oil cooler hose (1), high-flow valve hose (2), and oil cooler hydraulic hose (3).



7. Disconnect the oil tank return hose (1), pilot lock valve UI hose (2), RCV boom up hose (3), and RCV rollback hose (4).



5. Disconnect the external hydraulic (female) hose (1) and lift cylinder (lifting) hydraulic hose (2).




8. Disconnect the RCV boom down hose (1) and RCV dump hose (2).




LF1W4B54A

9. Disconnect the main control valve connector (1).



LF1W4B55A


10. Unscrew the three main control valve mounting bolts and nuts (1)(3EA), and then remove the main control valve assembly (2).



LF1W4B56A

REMARKS

ELBOW ASSEMBLY



LF1W4D93A

- When installing the elbow, install it according to the direction and specified torque.

Mounting section tightening torque

- ① (1-1/16-12 UN) : 170.5 ~ 183.3 N·m
17.4 ~ 18.7 kgf·m
125.3 ~ 134.6 lb·ft
- ②, ③ (7/8-14 UNF) : 98.0 ~ 109.8 N·m
10.0 ~ 11.2 kgf·m
72.0 ~ 80.6 lb·ft
- ④ (1-1/16-12 UN) : 170.5 ~ 183.3 N·m
17.4~18.7 kgf·m
125.3 ~ 134.6 lb·ft

Hose tightening torque


- ① (1-3/16-12 UN) : 117.6 ~ 127.4 N·m
12.0 ~ 13.0 kgf·m
86.4 ~ 93.6 lb·ft
- ②, ③ (13/16-16 UN) : 58.8 ~ 63.7 N·m
6.0 ~ 6.5 kgf·m
43.2 ~ 46.8 lb·ft
- ④ (1-3/16-12 UN) : 117.6 ~ 127.4 N·m
12.0 ~ 13.0 kgf·m
86.4 ~ 93.6 lb·ft
- and (1-7/16-12 UN) : 181.3 ~ 191.1 N·m
18.5 ~ 19.5 kgf·m
133.2 ~ 140.4 lb·ft

Assembly angle

- ① : 15°
- ② : 20°
- ④ : 15°

REMARKS

ELBOW ASSEMBLY





Mounting section tightening torque

- ⑤, ⑥, ⑦ (9/16-18 UNF) : 33.3 ~ 35.3 N·m
3.4 ~ 3.6 kgf·m
24.5 ~ 25.9 lb·ft
- ⑧, ⑨ (7/16-20 UNF) : 19.6 ~ 21.6 N·m
2.0 ~ 2.2 kgf·m
14.4 ~ 15.8 lb·ft

Hose tightening torque

- ⑤, ⑥, ⑦ (9/16-18 UNF) : 24.5 ~ 29.4 N·m
2.5 ~ 3.0 kgf·m
18.0 ~ 21.6 lb·ft
- ⑧, ⑨ (9/16-18 UNF) : 24.5 ~ 29.4 N·m
2.5 ~ 3.0 kgf·m
18.0 ~ 21.6 lb·ft
- ⑤ : 45°

CAUTION



- ① When connecting the hydraulic hose to the elbow, keep the clearance from the CCRT for at least 50 mm to prevent any interference.

DISASSEMBLY

SAFETY FIRST

ENGINE





DRIVING & CHASSIS

HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN




INDEX





1. Remove the left-hand and right-hand bucket spool covers (1) of the control valve.







2. Pull out the bucket spools (1).



4. Pull out the boom spool (1).






3. After removing the boom spool covers (1), remove the components (2, 3, & 4) from the left side as well as the components (5, 6, 7, & 8) from the right side.



5. Remove the solenoid valves (1 & 2).

6. Remove the left-hand cover (1) and right-hand cover (2) from the main control valve body.



7. Pull out the external hydraulic flow spool (1) from the main control valve body.

8. Remove the relief valve assembly (1).

8.6 SELF LEVEL VALVE DETACH & DISASSEMBLY

SAFETY FIRST

ENGINE


DRIVING & CHASSIS

HYDRAULIC SYSTEM


ELECTRIC SYSTEM

CABIN


INDEX



LT1W476A




1. Disconnect the solenoid valve connector (1).





2. Disconnect the MCV hydraulic hose (1) and lift cylinder (lowering) hydraulic hose (2) from the top of the self-leveling valve body.

REMARKS


SELF-LEVELING ADJUSTMENT




1. Set the machine with the boom in the lowest position and the bucket in the maximum rollback position.
2. Run the engine at its maximum rpm (2,550 ± 50) to check the angle of the bucket after the boom is raised up to the highest position.
Bucket angle : 5~10 °
3. If the angle of the bucket is abnormal.




- Remove the cap.
- Unscrew the mounting nut.
- Turn the adjusting bolt clockwise or counterclockwise to adjust it.
(Adjustment should be done within 1 and a half turns.)
- Clockwise direction: decreasing bucket dump ratio
- Counterclockwise direction: increasing bucket dump ratio
- After setting the adjusting bolt, lock it with the mounting nut.
- Install the cap again.



3. Disconnect the tilt cylinder (dump) hydraulic hose (1) and tilt cylinder (rollback) hydraulic hose (2).




4. Unscrew the self-leveling valve body mounting bolts (1)(2EA), and then remove the self-leveling valve (2).



REMARKS

ELBOW ASSEMBLY



• When installing the elbow, be careful with its tightening torque.

Mounting section (7/8-14 UNF)

tightening torque98.0 ~ 109.8 N·m
 10.0 ~ 11.2 kgf·m
 72.0 ~ 80.6 lb·ft

Hose (1-3/16-12 UN)

tightening torque117.6 ~ 127.4 N·m
 12.0 ~ 13.0 kgf·m
 86.4 ~ 93.6 lb·ft

DISASSEMBLY

SAFETY FIRST

ENGINE





DRIVING & CHASSIS

HYDRAULIC SYSTEM

ELECTRIC SYSTEM





CABIN

INDEX





1. Remove the solenoid magnet (1) from the valve body.

2. Remove the solenoid valve (1).




3. Remove the relief valve (1).

4. Remove the horizontal balance control valve (1).




5. Unscrew the holder (1) on top of the valve body to remove the spring (2) and valve (3).




6. Assemble in the reverse order of disassembly.

8.7 PILOT LOCK VALVE DETACH & DISASSEMBLY




LT1W4A16A




LT1W4A19A

3. Disconnect the parking valve hose (1) and oil tank hose (2).




LT1W4A17A

1. Disconnect the solenoid connector (1).



LT1W4A20A

4. Unscrew the two pilot lock valve body mounting bolts (1) and then remove the pilot lock valve assembly (2).



LT1W4A18A


2. Disconnect the HST pump driving hose (1) and HST pump shift valve hose (2), RCV assembly (RH) hose (3) and main control valve hose (4).



LT1W4A21A

REMARKS

ELBOE ASSEMBLY



LT1W479A

- When installing the elbow, install it according to the direction and specified torque.

①, ②, ③, ④


Mounting section (7/16-20 UNF)

tightening torque19.6 ~ 21.6 N·m
 2.0 ~ 2.2 kgf·m
 14.4 ~ 15.8 lb·ft


Hose (9/16-18 UNF)

tightening torque24.5 ~ 29.4 N·m
 2.5 ~ 3.0 kgf·m
 18.0 ~ 21.6 lb·ft

DISASSEMBLY




LT1W4A22A



LT1W4A23A

1. Remove the solenoid magnets (1) from the pilot lock valve body.



2. Remove the solenoid valves (1).

8.8 SHIFT VALVE DETACH & DISASSEMBLY

SAFETY FIRST

ENGINE


DRIVING & CHASSIS

HYDRAULIC SYSTEM


ELECTRIC SYSTEM

CABIN


INDEX



LT1W4A26A




LT1W4A29A




LT1W4A27A

1. Disconnect the solenoid magnet connector (1).

3. Disconnect the HST motor (RH) hose (1) and HST motor (LH) hose (2).




LT1W4A30A



LT1W4A28A

2. Disconnect the HST pump hose (1), oil tank return hose (2) from the valve assembly.




LT1W4A31A

4. Unscrew the shift valve mounting bolts (1)(2EA) to remove the shift valve (2).

REMARKS

CONNECTOR ASSEMBLY



LT1W482A

- When installing the connector, install it according to the specified torque.


Mounting section (9/16-18 UNF)

tightening torque 33.3 ~ 35.3 N·m
 3.4 ~ 3.6 kgf·m
 24.5 ~ 25.9 lb·ft


Hose (9/16-18 UNF)

tightening torque 24.5 ~ 29.4 N·m
 2.5 ~ 3.0 kgf·m
 18.0 ~ 21.6 lb·ft

DISASSEMBLY




LT1W4A32A




LT1W4A33A

1. Remove the solenoid magnet (1).




LT1W4A34A



LT1W4A35A





2. Remove the solenoid valve (1).



LT1W4A36A


3. Assemble in the reverse order of disassembly.

8.9 PARKING VALVE DETACH & DISASSEMBLY




1. Disconnect the solenoid magnet connector (1).

3. Unscrew the two parking valve mounting bolts (1) to remove the parking valve assembly (2).



2. Disconnect the HST motor (RH) hose (1), HST motor (LH) hose (2), oil tank return hose (3), HST pump hose (4), and pilot lock valve (5).


REMARKS



- Check the knob is in the full lock position before temporary assembly of the parking valve. (Full lock position: knob turned clockwise completely with a hand)

REMARKS

CONNECTOR ASSEMBLY



LT1W484A

- When installing the connector, install it according to the specified torque.

Mounting section tightening torque :

①, ②, ④ (9/16-18 UNF) : 33.3 ~ 35.3 N·m
 3.4 ~ 3.6 kgf·m
 24.5 ~ 25.9 lb·ft


③ (9/16-18 UNF) : 24.5 ~ 29.4 N·m
 2.5 ~ 3.0 kgf·m
 18.0 ~ 21.6 lb·ft

⑤ (PF1/4) : 24.5 ~ 30 N·m
 2.5 ~ 3.06 kgf·m
 18.0 ~ 22.0 lb·ft


Hydraulic hose tightening torque :

(9/16-18 UNF) : 24.5 ~ 29.4 N·m
 2.5 ~ 3.0 kgf·m
 18.0 ~ 21.6 lb·ft

DISASSEMBLY




LT1W4A42A




LT1W4A43A

1. Remove the solenoid magnet (1).



LT1W4A44A



LT1W4A45A

2. Assemble in the reverse order of disassembly.

8.10 HIGH FLOW VALVE DETACH & DISASSEMBLY

SAFETY FIRST

ENGINE


DRIVING & CHASSIS

HYDRAULIC SYSTEM


ELECTRIC SYSTEM

CABIN


INDEX



LF1W4C37A




LF1W4C40A




LF1W4C38A

1. Disconnect the solenoid magnet connector (1).



LF1W4C41A

3. Unscrew the two high-flow valve mounting bolts (1) and remove the high-flow valve assembly (2).




LF1W4C39A

2. Disconnect the hydraulic hoses (1, 2, & 3) from the high-flow valve body.

REMARKS

CONNECTOR ASSEMBLY



- When installing the connector, install it according to the specified torque.



Mounting section tightening torque :

- ① (1-5/16-12 UN) : 270.5 ~ 299.9 N·m
27.6 ~ 30.6 kgf·m
198.7 ~ 220.3 lb·ft
- ② (1-1/16-12 UN) : 170.5 ~ 183.3 N·m
17.4 ~ 18.7 kgf·m
125.3 ~ 134.6 lb·ft
- ③ (7/8-14 UNF) : 98.0 ~ 109.8 N·m
10.0 ~ 11.2 kgf·m
72.0 ~ 80.6 lb·ft





Hose tightening torque :

- ① (1-3/16-12 UN) : 117.6 ~ 127.4 N·m
12.0 ~ 13.0 kgf·m
86.4 ~ 93.6 lb·ft
- ②, ③ (13/16-16 UN) : 58.8 ~ 63.7 N·m
6.0 ~ 6.5 kgf·m
43.2 ~ 46.8 lb·ft

DISASSEMBLY





1. Remove the solenoid magnet (1).




2. Remove the solenoid valve (1).

3. Unscrew the plugs (1) and remove the springs (2) and spools (3).



4. Unscrew the cap (1) on top of the valve body to remove the spring (2) and valve (3).



5. Assemble in the reverse order of disassembly.

8.11 RIDE CONTROL VALVE DETACH & DISASSEMBLY [OPTION]

SAFETY FIRST

ENGINE


DRIVING & CHASSIS

HYDRAULIC SYSTEM


ELECTRIC SYSTEM

CABIN


INDEX



LF1W4C51A



LF1W4C54A




LF1W4C52A



LF1W4C55A

1. Disconnect the solenoid valve connector (1).

3. Unscrew the two valve body mounting bolts (1) and then remove the ride control valve assembly (2).




LF1W4C53A

2. Disconnect the lift cylinder (lifting) hydraulic hose (1).

REMARKS

CONNECTOR ASSEMBLY



- When installing the connector, install it according to the specified torque.

Mounting section (9/16-18 UNF)
 tightening torque33.3 ~ 35.3 N·m
 3.4 ~ 3.6 kgf·m
 24.5 ~ 25.9 lb·ft

Hose (11/16-16 UN)
 tightening torque37.2 ~ 42.1 N·m
 3.8 ~ 4.3 kgf·m
 27.4 ~ 31.0 lb·ft

DISASSEMBLY



- Remove the solenoid magnet (1).



2. Remove the solenoid valve (1).

3. Remove the accumulator (1).



4. Assemble in the reverse order of disassembly.

8.12 QUICK ATTACHMENT VALVE DETACH & DISASSEMBLY

SAFETY FIRST

ENGINE



DRIVING & CHASSIS

HYDRAULIC SYSTEM


ELECTRIC SYSTEM

CABIN


INDEX



3. Disconnect the quick attachment cylinder hydraulic hoses (1 & 2).



1. Disconnect the solenoid connector (1).




2. Disconnect the hydraulic hoses (1 & 2).

4. Unscrew the two valve body mounting bolts (1) and then remove the quick attachment valve assembly (2).

REMARKS

CONNECTOR ASSEMBLY



LF1W4E09A

- When connecting the hoses, ensure to connect them correctly to the "lock" and "release" ports and tighten them to the specified torque.

Mounting section (9/16-18UNF)

tightening torque : 33.3 ~ 35.3 N·m

3.4 ~ 3.6 kgf·m

24.5 ~ 25.9 lb·ft

Hose tightening torque :

①, ③ (11/16-18UN) : 37.2 ~ 47.0 N·m

3.8 ~ 4.8 kgf·m


27.4 ~ 34.7 lb·ft

② (9/16-18UNF) : 24.5 ~ 29.4 N·m


2.5 ~ 3.0 kgf·m

18.0 ~ 21.6 lb·ft

DISASSEMBLY




LF1W4C69A




LF1W4C70A

1. Remove the solenoid magnets (1).




LF1W4C71A



LF1W4C72A

2. Remove the solenoid valves (1).



LF1W4C73A

3. Assemble in the reverse order of disassembly.

8.13 HST FILTER REPLACEMENT

SAFETY FIRST

ENGINE




DRIVING & CHASSIS

HYDRAULIC SYSTEM

ELECTRIC SYSTEM


CABIN

INDEX



1. Disconnect the hydraulic hoses (1 & 2).


2. Unscrew the filter support mounting bolts (1)(2EA) to remove the HST filter assembly (2).



3. Unscrew the HST filter case (1) and remove the filter element (2) from the inside. Then, replace the element with a new one as necessary.

REMARKS

ASSEMBLY ANGLE AND TIGHTENING TORQUE WHEN INSTALLING THE ELBOW



- **Tightening torque**
 - ①, ② (PF1/2) : 58.8 ~ 63.7 N·m
6.0 ~ 6.5 kgf·m
43.2 ~ 46.8 lb·ft
- **Assembly angle**
 - ①, ② : 40°
- **When installing ③ and ⑤, make sure to follow the stamped arrow mark.**
- **Apply LOCTITE 577 or equivalent on the threads of ① and ④ and install them on ③.**

8.14 RETURN FILTER REPLACEMENT

SAFETY FIRST

ENGINE

DRIVING & CHASSIS

HYDRAULIC SYSTEM

ELECTRIC SYSTEM

CABIN


INDEX



1. With a filter wrench completely engaged with the filter, turn the wrench counterclockwise to remove the return filter (1). After inspection, replace it with a new one as necessary.


REMARKS

ASSEMBLY ANGLE AND TIGHTENING TORQUE WHEN INSTALLING THE ELBOW




- ①, ② Elbow Mounting section (PF1)
 - : 181.3 ~ 191.1 N·m
 - 18.5 ~ 19.5 kgf·m
 - 133.2 ~ 140.4 lb·ft
- Hydraulic hose tightening (1-5/16-12 UN)
 - : 181.3 ~ 191.1 N·m
 - 18.5 ~ 19.5 kgf·m
 - 133.2 ~ 140.4 lb·ft

8.15 LIFT CYLINDER DISASSEMBLY




1. Remove the boom support (1) that is attached on the bar on the opposite side of the lift cylinder to be disassembled.



2. Raise the boom assembly (1) with the lift cylinder (2). After installing the boom support (3), that was previously removed, on the lobe section of the lift cylinder, lower the lift cylinder until the boom support makes contact with the boom assembly.

REMARKS





- After inserting the boom support ("L" shape) into the lift cylinder section (A), fit the head pin (B) into the boom support hole and fix it with the snap pin (C).

REMARKS

TIP FOR INSTALLING THE BOOM SUPPORT


- Install it on the lift cylinder on the opposite side of the lift cylinder to be serviced.




3. Remove the top pin (1) from the lift cylinder to be disassembled. Then, lower the lift cylinder (2).

4. Pull out the lower pin (1) of the lift cylinder for a proper amount. The cylinder lower pin may be stuck so may not be pulled out easily. In this case, support the bucket (B) with a hoist and pull out the pin little by little while moving the bucket up and down.

REMARKS



- Do not pull out the cylinder lower pin (B) completely.
A (pulling out amount) : approx. 156 mm (6.14 in.)



LT1W4A78A



LF1W4D79A

5. Lift the lift cylinder (1) out of the main frame (2), disconnect the hydraulic hose (3), and remove the cylinder.

Hydraulic hose

tightening torque 58.8 ~ 63.7 N·m
6.0 ~ 6.5 kgf.m
43.2 ~ 46.8 lb·ft

6. Assemble in the reverse order of disassembly.

8.16 TILT CYLINDER DISASSEMBLY

SAFETY FIRST

ENGINE


DRIVING & CHASSIS

HYDRAULIC SYSTEM

ELECTRIC SYSTEM






CABIN

INDEX




LT1W493A

1. Remove the tilt cylinder covers (1).




2. Disconnect the tilt cylinder hydraulic hoses (1 & 2).



LF1W4C99A

3. Remove the tilt cylinder retaining pins (1 & 2) through the inside in order to remove the tilt cylinders (3).


 REMARKS



- When connecting the hydraulic tube connecting hose, check the port location and tighten it with the specified torque.

Hose (13/16-16 UN)

tightening torque58.8 ~ 63.7 N·m
 6.0 ~ 6.5 kgf·m
 43.2 ~ 46.8 lb·ft



- When connecting the hose between the hydraulic tube and tilt cylinder, check the port location and tighten it with the specified torque.

Hose (13/16-16 UN)

tightening torque58.8 ~ 63.7 N·m
 6.0 ~ 6.5 kgf·m
 43.2 ~ 46.8 lb·ft

8.17 QUICK ATTACHMENT CYLINDER DISASSEMBLY

SAFETY FIRST

ENGINE


DRIVING & CHASSIS

HYDRAULIC SYSTEM


ELECTRIC SYSTEM

CABIN

INDEX




1. Disconnect the quick attachment cylinder hydraulic hoses (1 & 2) from the back of the bucket.



2. Separate the left-hand and right-hand quick attachment operating lever connections (2) and then remove the quick attachment cylinder.

REMARKS


QUICK ATTACHMENT ASSEMBLY PORT



- When connecting the hose, make sure to check the "Lock" and "Release" ports.


Hose (11/16-18 UN)
 tightening torque 37.2 ~ 47.0 N·m
 3.8 ~ 4.8 kgf·m
 27.4 ~ 34.7 lb·ft

QUICK ATTACHMENT HYDRAULIC TUBE





Hose (11/16-18 UN)
 tightening torque 37.2 ~ 47.0 N·m
 3.8 ~ 4.8 kgf·m
 27.4 ~ 34.7 lb·ft

8.18 RCV ASSEMBLY & OIL TANK DISASSEMBLY




1. Remove the rubber bellows (1) of the joystick lever and then remove the RCV assembly cover (2).



2. Remove the RCV assembly kit brackets (1).



4. Disconnect the hydraulic hoses (1) from the RCV assembly.




3. Pull out the RCV assembly and disconnect the wiring connector (1).


REMARKS

CONNECTOR ASSEMBLY

RCV (LH) - DRIVING



RCV (RH) - WORKING




- When installing the connector, install it according to the specified torque.

Mounting section (7/16-20 UNF)


tightening torque19.6 ~ 21.6 N·m
 2.0 ~ 2.2 kgf·m
 14.4 ~ 15.8 lb·ft

Hose (9/16-18 UNF)


tightening torque24.5 ~ 29.4 N·m
 2.5 ~ 3.0 kgf·m
 18.0 ~ 21.6 lb·ft




5. Disconnect the RCV (RH)(1) and aux. hydraulic (2), HST pump (3) and left-hand RCV (4) hydraulic hose from the oil tank.



6. Disconnect the suction hose (1) and drain hose (2) from the oil tank.






7. Disconnect the oil tank hose (1), main control valve hose (2), oil cooler hose (3) and quick-attachment cylinder hose (4).




LT1W410A

8. Disconnect the external hydraulic hose (1), HST pump hydraulic hose (2) and track (HST) motor hose (3).



LT1W411A


9. Remove the right-hand RCV assembly support (1).



LT1W414A

10. Unscrew the oil tank mounting bolts (1)(6EA) and then remove the oil tank (2) from the main frame.

 REMARKS



- When installing the oil gauge, install it according to the specified torque.

Oil gauge bolt (M52 P2.0)

tightening torque	61.7 ~ 75.5 N·m
	6.3 ~ 7.7 kgf.m
	45.4 ~ 55.4 lb·ft