

SECTION 8 DISASSEMBLY AND ASSEMBLY

| | | |
|----------|---|-------|
| Group 1 | Precaution | 8-1 |
| Group 2 | Tightening Torque | 8-4 |
| Group 3 | Pump Device | 8-7 |
| Group 4 | Main Control Valve | 8-32 |
| Group 5 | Swing Device | 8-46 |
| Group 6 | Travel Device | 8-65 |
| Group 7 | RCV Lever | 8-129 |
| Group 8 | Turning Joint | 8-143 |
| Group 9 | Boom, Arm, Bucket and Dozer Cylinders | 8-146 |
| Group 10 | Undercarriage | 8-166 |
| Group 11 | Work Equipment | 8-178 |


SECTION 8 DISASSEMBLY AND ASSEMBLY

GROUP 1 PRECAUTIONS

1. REMOVAL WORK

- 1) Lower the work equipment completely to the ground.
If the coolant contains antifreeze, dispose of it correctly.
- 2) After disconnecting hoses or tubes, cover them or fit blind plugs to prevent dirt or dust from entering.
- 3) When draining oil, prepare a container of adequate size to catch the oil.
- 4) Confirm the match marks showing the installation position, and make match marks in the necessary places before removal to prevent any mistake when assembling.
- 5) To prevent any excessive force from being applied to the wiring, always hold the connectors when disconnecting the connectors.
- 6) Fit wires and hoses with tags to show their installation position to prevent any mistake when installing.
- 7) Check the number and thickness of the shims, and keep in a safe place.
- 8) When raising components, be sure to use lifting equipment of ample strength.
- 9) When using forcing screws to remove any components, tighten the forcing screws alternately.
- 10) Before removing any unit, clean the surrounding area and fit a cover to prevent any dust or dirt from entering after removal.
- 11) When removing hydraulic equipment, first release the remaining pressure inside the hydraulic tank and the hydraulic piping.
- 12) If the part is not under hydraulic pressure, the following corks can be used.

| Nominal number | Dimensions | | |
|----------------|------------|------|----|
| | D | d | L |
| 06 | 6 | 5 | 8 |
| 08 | 8 | 6.5 | 11 |
| 10 | 10 | 8.5 | 12 |
| 12 | 12 | 10 | 15 |
| 14 | 14 | 11.5 | 18 |
| 16 | 16 | 13.5 | 20 |
| 18 | 18 | 15 | 22 |
| 20 | 20 | 17 | 25 |
| 22 | 22 | 18.5 | 28 |
| 24 | 24 | 20 | 30 |
| 27 | 27 | 22.5 | 34 |



2. INSTALL WORK

- 1) Tighten all bolts and nuts (sleeve nuts) to the specified torque.
- 2) Install the hoses without twisting or interference.
- 3) Replace all gaskets, O-rings, cotter pins, and lock plates with new parts.
- 4) Bend the cotter pin or lock plate securely.
- 5) When coating with adhesive, clean the part and remove all oil and grease, then coat the threaded portion with 2-3 drops of adhesive.
- 6) When coating with gasket sealant, clean the surface and remove all oil and grease, check that there is no dirt or damage, then coat uniformly with gasket sealant.
- 7) Clean all parts, and correct any damage, dents, burrs, or rust.
- 8) Coat rotating parts and sliding parts with engine oil.
- 9) When press fitting parts, coat the surface with antifriction compound (LM-P).
- 10) After installing snap rings, check that the snap ring is fitted securely in the ring groove (Check that the snap ring moves in the direction of rotation).
- 11) When connecting wiring connectors, clean the connector to remove all oil, dirt, or water, then connect securely.
- 12) When using eyebolts, check that there is no deformation or deterioration, and screw them in fully.
- 13) When tightening split flanges, tighten uniformly in turn to prevent excessive tightening on one side.
- 14) When operating the hydraulic cylinders for the first time after repairing and reassembling the hydraulic cylinders, pumps, or other hydraulic equipment or piping, always bleed the air from the hydraulic cylinders as follows:
 - (1) Start the engine and run at low idling.
 - (2) Operate the control lever and actuate the hydraulic cylinder 4-5 times, stopping 100mm before the end of the stroke.
 - (3) Next, operate the piston rod to the end of its stroke to relieve the circuit. (The air bleed valve is actuated to bleed the air.)
 - (4) After completing this operation, raise the engine speed to the normal operating condition.
 - ※ If the hydraulic cylinder has been replaced, carry out this procedure before assembling the rod to the work equipment.
 - ※ Carry out the same operation on machines that have been in storage for a long time after completion of repairs.

3. COMPLETING WORK

- 1) If the coolant has been drained, tighten the drain valve, and add water to the specified level. Run the engine to circulate the water through the system. Then check the water level again.
- 2) If the hydraulic equipment has been removed and installed again, add engine oil to the specified level. Run the engine to circulate the oil through the system. Then check the oil level again.
- 3) If the piping or hydraulic equipment, such as hydraulic cylinders, pumps, or motors, have been removed for repair, always bleed the air from the system after reassembling the parts.
- 4) Add the specified amount of grease (molybdenum disulphied grease) to the work equipment related parts.

GROUP 2 TIGHTENING TORQUE

1. MAJOR COMPONENTS

| No. | Descriptions | Bolt size | Torque | | |
|-----|--------------------|---|-------------|------------|-------------|
| | | | kgf · m | lbf · ft | |
| 1 | Engine | Engine mounting bolt (engine-bracket, FR) | M12 × 1.75 | 11.5 ± 1.0 | 83.2 ± 7.2 |
| 2 | | Engine mounting bolt (engine-bracket, RR) | M12 × 1.75 | 11.5 ± 1.0 | 83.2 ± 7.2 |
| 3 | | Engine mounting bolt (bracket-frame, FR) | M16 × 2.0 | 29.7 ± 4.5 | 215 ± 32.5 |
| 4 | | Engine mounting bolt (bracket-frame, RR) | M16 × 2.0 | 29.7 ± 4.5 | 215 ± 32.5 |
| 5 | | Radiator mounting bolt | M16 × 2.0 | 29.7 ± 4.5 | 215 ± 32.5 |
| 6 | | Coupling mounting socket bolt | M16 × 2.0 | 22.0 ± 1.0 | 159 ± 7.2 |
| 7 | | Main pump housing mounting bolt | M10 × 1.5 | 6.5 ± 0.7 | 47.0 ± 5.1 |
| 8 | Hydraulic system | Main pump mounting socket bolt | M16 × 2.0 | 29.7 ± 4.5 | 215 ± 32.5 |
| 9 | | Main control valve mounting bolt | M12 × 1.75 | 12.2 ± 1.3 | 88.2 ± 9.4 |
| 10 | | Fuel tank mounting bolt | M20 × 2.5 | 57.8 ± 5.8 | 418 ± 42.0 |
| 11 | | Hydraulic oil tank mounting bolt | M20 × 2.5 | 57.8 ± 5.8 | 418 ± 42.0 |
| 12 | | Turning joint mounting bolt, nut | M12 × 1.75 | 12.8 ± 3.0 | 92.6 ± 21.7 |
| 13 | Power train system | Swing motor mounting bolt | M16 × 2.0 | 29.6 ± 3.2 | 214 ± 23.1 |
| 14 | | Swing bearing upper part mounting bolt | M18 × 2.5 | 41.3 ± 4.0 | 299 ± 28.9 |
| 15 | | Swing bearing lower part mounting bolt | M16 × 1.5 | 29.7 ± 3.0 | 215 ± 21.7 |
| 16 | | Travel motor mounting bolt | M16 × 2.0 | 25.7 ± 3.0 | 185 ± 21.7 |
| 17 | | Sprocket mounting bolt | M16 × 2.0 | 29.7 ± 3.0 | 215 ± 21.7 |
| 18 | Under carriage | Upper roller mounting bolt, nut | M16 × 2.0 | 57.9 ± 6.0 | 419 ± 43.4 |
| 19 | | Lower roller mounting bolt | M16 × 2.0 | 57.9 ± 6.0 | 419 ± 43.4 |
| 20 | | Track tension cylinder mounting bolt | M16 × 2.0 | 29.7 ± 4.5 | 215 ± 32.5 |
| 21 | | Track shoe mounting bolt, nut | 5/8 - 18UNF | 42 ± 4.0 | 304 ± 28.9 |
| 22 | | Track guard mounting bolt | M16 × 2.0 | 29.7 ± 4.5 | 215 ± 32.5 |
| 23 | Others | Counterweight mounting bolt | M36 × 3.0 | 308 ± 46 | 2228 ± 333 |
| 24 | | Cab mounting bolt | M12 × 1.75 | 12.8 ± 3.0 | 92.6 ± 21.7 |
| 25 | | Operator's seat mounting bolt | M 8 × 1.25 | 4.05 ± 0.8 | 29.3 ± 5.8 |
| 26 | | Under cover mounting bolt | M12 × 1.75 | 12.8 ± 3.0 | 92.6 ± 21.7 |

※ For tightening torque of engine and hydraulic components, see engine maintenance guide and service manual.

2. TORQUE CHART

Use following table for unspecified torque.

1) BOLT AND NUT

(1) Coarse thread

| Bolt size | 8.8T | | 10.9T | | 12.9T | |
|------------|-------------|-------------|-------------|-------------|-------------|-------------|
| | kgf·m | lbf·ft | kgf·m | lbf·ft | kgf·m | lbf·ft |
| M 6 × 1.0 | 0.8 ~ 1.2 | 5.8 ~ 8.6 | 1.2 ~ 1.8 | 8.7 ~ 13.0 | 1.5 ~ 2.1 | 10.9 ~ 15.1 |
| M 8 × 1.25 | 2.0 ~ 3.0 | 14.5 ~ 21.6 | 2.8 ~ 4.2 | 20.3 ~ 30.4 | 3.4 ~ 5.0 | 24.6 ~ 36.1 |
| M10 × 1.5 | 4.0 ~ 6.0 | 29.0 ~ 43.3 | 5.6 ~ 8.4 | 40.5 ~ 60.8 | 6.8 ~ 10.0 | 49.2 ~ 72.3 |
| M12 × 1.75 | 6.8 ~ 10.2 | 50.0 ~ 73.7 | 9.6 ~ 14.4 | 69.5 ~ 104 | 12.3 ~ 16.5 | 89.0 ~ 119 |
| M14 × 2.0 | 10.9 ~ 16.3 | 78.9 ~ 117 | 16.3 ~ 21.9 | 118 ~ 158 | 19.5 ~ 26.3 | 141 ~ 190 |
| M16 × 2.0 | 17.9 ~ 24.1 | 130 ~ 174 | 25.1 ~ 33.9 | 182 ~ 245 | 30.2 ~ 40.8 | 141 ~ 295 |
| M18 × 2.5 | 24.8 ~ 33.4 | 180 ~ 241 | 34.8 ~ 47.0 | 252 ~ 340 | 41.8 ~ 56.4 | 302 ~ 407 |
| M20 × 2.5 | 34.9 ~ 47.1 | 253 ~ 340 | 49.1 ~ 66.3 | 355 ~ 479 | 58.9 ~ 79.5 | 426 ~ 575 |
| M22 × 2.5 | 46.8 ~ 63.2 | 339 ~ 457 | 65.8 ~ 88.8 | 476 ~ 642 | 78.9 ~ 106 | 570 ~ 766 |
| M24 × 3.0 | 60.2 ~ 81.4 | 436 ~ 588 | 84.6 ~ 114 | 612 ~ 824 | 102 ~ 137 | 738 ~ 991 |
| M30 × 3.5 | 120 ~ 161 | 868 ~ 1164 | 168 ~ 227 | 1216 ~ 1641 | 202 ~ 272 | 1461 ~ 1967 |

(2) Fine thread

| Bolt size | 8.8T | | 10.9T | | 12.9T | |
|------------|-------------|-------------|-------------|-------------|-------------|-------------|
| | kgf · m | lbf · ft | kgf · m | lbf · ft | kgf · m | lbf · ft |
| M 8 × 1.0 | 2.1 ~ 3.1 | 15.2 ~ 22.4 | 3.0 ~ 4.4 | 21.7 ~ 31.8 | 3.6 ~ 5.4 | 26.1 ~ 39.0 |
| M10 × 1.25 | 4.2 ~ 6.2 | 30.4 ~ 44.9 | 5.9 ~ 8.7 | 42.7 ~ 62.9 | 7.0 ~ 10.4 | 50.1 ~ 75.2 |
| M12 × 1.25 | 7.3 ~ 10.9 | 52.8 ~ 78.8 | 10.3 ~ 15.3 | 74.5 ~ 110 | 13.1 ~ 17.7 | 94.8 ~ 128 |
| M14 × 1.5 | 12.4 ~ 16.6 | 89.7 ~ 120 | 17.4 ~ 23.4 | 126 ~ 169 | 20.8 ~ 28.0 | 151 ~ 202 |
| M16 × 1.5 | 18.7 ~ 25.3 | 136 ~ 182 | 26.3 ~ 35.5 | 191 ~ 256 | 31.6 ~ 42.6 | 229 ~ 308 |
| M18 × 1.5 | 27.1 ~ 36.5 | 196 ~ 264 | 38.0 ~ 51.4 | 275 ~ 371 | 45.7 ~ 61.7 | 331 ~ 446 |
| M20 × 1.5 | 37.7 ~ 50.9 | 273 ~ 368 | 53.1 ~ 71.7 | 384 ~ 518 | 63.6 ~ 86.0 | 460 ~ 622 |
| M22 × 1.5 | 51.2 ~ 69.2 | 370 ~ 500 | 72.0 ~ 97.2 | 521 ~ 703 | 86.4 ~ 116 | 625 ~ 839 |
| M24 × 2.0 | 64.1 ~ 86.5 | 464 ~ 625 | 90.1 ~ 121 | 652 ~ 875 | 108 ~ 146 | 782 ~ 1056 |
| M30 × 2.0 | 129 ~ 174 | 933 ~ 1258 | 181 ~ 245 | 1310 ~ 1772 | 217 ~ 294 | 1570 ~ 2126 |

2) PIPE AND HOSE (FLARE TYPE)

| Thread size (PF) | Width across flat (mm) | kgf · m | lbf · ft |
|------------------|------------------------|---------|----------|
| 1/4" | 19 | 4 | 28.9 |
| 3/8" | 22 | 5 | 36.2 |
| 1/2" | 27 | 9.5 | 68.7 |
| 3/4" | 36 | 18 | 130 |
| 1" | 41 | 21 | 152 |
| 1-1/4" | 50 | 35 | 253 |

3) PIPE AND HOSE (ORFS TYPE)

| Thread size (UNF) | Width across flat (mm) | kgf · m | lbf · ft |
|-------------------|------------------------|---------|----------|
| 9/16-18 | 19 | 4 | 28.9 |
| 11/16-16 | 22 | 5 | 36.2 |
| 13/16-16 | 27 | 9.5 | 68.7 |
| 1-3/16-12 | 36 | 18 | 130 |
| 1-7/16-12 | 41 | 21 | 152 |
| 1-11/16-12 | 50 | 35 | 253 |

4) FITTING

| Thread size | Width across flat (mm) | kgf · m | lbf · ft |
|-------------|------------------------|---------|----------|
| 1/4" | 19 | 4 | 28.9 |
| 3/8" | 22 | 5 | 36.2 |
| 1/2" | 27 | 9.5 | 68.7 |
| 3/4" | 36 | 18 | 130 |
| 1" | 41 | 21 | 152 |
| 1-1/4" | 50 | 35 | 253 |

GROUP 3 PUMP DEVICE

1. REMOVAL AND INSTALL

1) REMOVAL

- (1) Lower the work equipment to the ground and stop the engine.
- (2) Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping
- (3) Loosen the breather slowly to release the pressure inside the hydraulic tank.

▲ Escaping fluid under pressure can penetrate the skin causing serious injury.

- (4) Loosen the drain plug under the hydraulic tank and drain the oil from the hydraulic tank.

· Hydraulic tank quantity : 96 ℓ (25.4 U.S. gal)

- (5) Remove socket bolts (11) and disconnect hoses (1,2).

- (6) Disconnect pilot line hoses (5, 6, 7, 8, 9, 10).

- (7) Remove socket bolts (12) and disconnect pump suction pipe (4).

※ When pump suction tube is disconnected, the oil inside the piping will flow out, so catch it in oil pan.



- (8) Sling the pump assembly and remove the pump mounting bolts.

· Weight : 88 kg (194 lb)

· Tightening torque : 29.7 ± 4.5 kgf·m
(215 ± 32.5 lbf·ft)

※ Pull out the pump assembly from housing.

When removing the pump assembly, check that all the hoses have been disconnected.




2) INSTALL

- (1) Carry out installation in the reverse order to removal.
- (2) Remove the suction strainer and clean it.
- (3) Replace return filter with new one.
- (4) Remove breather and clean it.
- (5) After adding oil to the hydraulic tank to the specified level.
- (6) Bleed the air from the hydraulic pump.
 - ① Remove the air vent plug (2EA).
 - ② Tighten plug lightly.
 - ③ Start the engine, run at low idling, and check oil come out from plug.
 - ④ Tighten plug.
- (7) Start the engine, run at low idling (3~5 minutes) to circulate the oil through the system.
- (8) Confirm the hydraulic oil level and check the hydraulic oil leak or not.

2. MAIN PUMP


1) STRUCTURE (1/2)



140Z92MP02

| | | |
|---------------------|-------------------------|----------------------|
| 111 Drive shaft (F) | 272 Pump casing (R) | 711 O-ring |
| 113 Drive shaft (R) | 312 Valve block | 717 O-ring |
| 116 1st Gear | 313 Valve plate (R) | 723 O-ring |
| 123 Roller bearing | 314 Valve plate (L) | 724 O-ring |
| 124 Needle bearing | 401 Hexagon socket bolt | 728 O-ring |
| 127 Bearing spacer | 402 Hexagon socket bolt | 732 O-ring |
| 141 Cylinder block | 406 Hexagon socket bolt | 733 O-ring |
| 151 Piston | 415 Hexagon socket bolt | 734 O-ring |
| 152 Shoe | 466 Plug | 774 Oil seal |
| 153 Set plate | 467 plug | 789 Back up ring |
| 156 Bushing | 468 Plug | 792 Back up ring |
| 157 Cylinder spring | 490 Plug | 806 Nut |
| 211 Shoe plate | 531 Tilting pin | 808 Hexagon head nut |
| 212 Swash plate | 532 Servo piston | 824 Snap ring |
| 214 Bushing | 533 Plug | 886 Spring pin |
| 251 Support | 534 Stopper (L) | 901 Eye bolt |
| 255 Lock pin | 535 Stopper (S) | 953 Set screw |
| 261 Seal cover (F) | 548 Pin | 954 Set screw |
| 263 Seal cover (R) | 702 O-ring | 981 Plate |
| 271 Pump casing (F) | 710 O-ring | 983 Pin |

STRUCTURE (2/2)





140Z92MP03

| | | | | | |
|-----|----------------|-----|---------------------|-----|---------------|
| 04 | Gear pump | 128 | Bearing spacer | 711 | O-ring |
| 115 | Shaft | 262 | Cover | 728 | O-ring |
| 117 | Gear No. 2 | 326 | Gear case | 825 | Retainer ring |
| 118 | Gear No. 3 | 414 | Hexagon socket bolt | 826 | Retainer ring |
| 125 | Ball bearing | 435 | Flange socket bolt | 855 | Spring pin |
| 126 | Roller bearing | 468 | Plug | 886 | Pin |

2) TOOLS AND TIGHTENING TORQUE

(1) Tools

The tools necessary to disassemble/reassemble the pump are shown in the follow list.


| Tool name & size | | Part name | | | |
|---|----|--|---------------------|----------------------------|------------------------------|
| Name | B | Hexagon socket head bolt | PT plug (PT thread) | ROH/VP/UNF plug (PF screw) | Hexagon socket head setscrew |
| Allen wrench  | 4 | M 5 | BP-1/16 | - | M 8 |
| | 5 | M 6 | BP-1/8 | - | M10 |
| | 6 | M 8 | BP-1/4 | PF-1/4 | M12, M14 |
| | 8 | M10 | BP-3/8 | PF-3/8 | M16, M18 |
| | 10 | M12 | BP-1/2 | PF-1/2 | M20 |
| | 14 | M16, M18 | BP-3/4 | PF-3/4 | - |
| | 17 | M20, M22 | BP-1 | PF-1 | - |
| Double ring spanner, socket wrench, double (single) open end spanner  | - | Hexagon bolt | Hexagon nut | VP plug (PF screw) | |
| | 19 | M12 | M12 | PF-1/4 | |
| | 24 | M16 | M16 | - | |
| | 27 | M18 | M18 | PF-1/2 | |
| | 30 | M20 | M20 | - | |
| | 41 | - | - | - | PF-1 |
| Adjustable angle wrench | | Medium size, 1 set | | | |
| Screw driver | | Minus type screw driver, Medium size, 2 sets | | | |
| Hammer | | Plastic hammer, 1 set | | | |
| Pliers | | For snap ring, TSR-160 | | | |
| Steel bar | | Steel bar of key material approx. 10×8×200 | | | |
| Torque wrench | | Capable of tightening with the specified torques | | | |

(2) Tightening torque

| Part name | Bolt size | Torque | | Wrench size | |
|---|-----------|---------|----------|-------------|----|
| | | kgf · m | lbf · ft | in | mm |
| Hexagon socket head bolt (material : SCM435) | M 5 | 0.7 | 5.1 | 0.16 | 4 |
| | M 6 | 1.2 | 8.7 | 0.20 | 5 |
| | M 8 | 3.0 | 21.7 | 0.24 | 6 |
| | M10 | 5.8 | 42.0 | 0.31 | 8 |
| | M12 | 10.0 | 72.3 | 0.39 | 10 |
| | M14 | 16.0 | 116 | 0.47 | 12 |
| | M16 | 24.0 | 174 | 0.55 | 14 |
| | M18 | 34.0 | 246 | 0.55 | 14 |
| PT Plug (material : S45C) ※Wind a seal tape 1.5 to 2 turns round the plug | PT1/16 | 0.7 | 5.1 | 0.16 | 4 |
| | PT 1/8 | 1.05 | 7.59 | 0.20 | 5 |
| | PT 1/4 | 1.75 | 12.7 | 0.24 | 6 |
| | PT 3/8 | 3.5 | 25.3 | 0.31 | 8 |
| | PT 1/2 | 5.0 | 36.2 | 0.39 | 10 |
| PF Plug (material : S45C) | PF 1/4 | 3.0 | 21.7 | 0.24 | 6 |
| | PF 3/8 | 7.55 | 54.6 | 0.31 | 8 |
| | PF 1/2 | 10.0 | 72.3 | 0.39 | 10 |
| | PF 3/4 | 15.0 | 109 | 0.55 | 14 |
| | PF 1 | 19.0 | 137 | 0.67 | 17 |
| | PF 1 1/4 | 27.0 | 195 | 0.67 | 17 |
| | PF 1 1/2 | 28.0 | 203 | 0.67 | 17 |

3) DISASSEMBLY

- (1) Select place suitable to disassembling.
 - ※ Select clean place.
 - ※ Spread rubber sheet, cloth or so on on overhaul workbench top to prevent parts from being damaged.
- (2) Remove dust, rust, etc, from pump surfaces with cleaning oil or so on.
- (3) Remove drain port plug (468) and drain oil pump casing (271, 272).
- (4) Remove hexagon socket head bolts (412, 413) and remove regulator.



140Z98MP11

- (5) Place pump horizontally on workbench with its regulator fitting surface down, and remove flange socket (435) and remove PTO unit (05).
 - ※ Be careful about the attaching direction of the PTO unit (05).
 - ※ Before bringing regulator fitting surface down, spread rubber sheet on workbench without fail to prevent this surface from being damaged.



140Z98MP12

- (6) In case the pump is provided without the PTO unit (05), remove the cover (262) with the hexagon socket head cap screws (414).



140Z98MP13

- (7) Remove flange socket (435) and remove gear pump (04).



140Z98MP14


- (8) Loosen hexagon socket head bolt (401) which tighten pump casing (271, 272) and valve block (312).



140Z98MP15

- (9) Place pump horizontally on workbench with its regulator fitting surface down, and separate pump casing (271,272) from valve block (312).


- ※ Remove 1st gear (116) when separating pump casing from valve block (312) too.



140Z98MP16

- (10) Pull out cylinder (141), pistons (151), set screw (153), spherical bush (156) and cylinder springs (157) simultaneously from pump casing (271, 272) straightly over drive shaft (111, 113).

- ※ Take care not to damage sliding surface of cylinder (141), spherical bush (156), shoes (152), swash plate (212), etc.



140Z98MP17

(11) Remove hexagon socket head bolts (406) and then seal cover (F, 261).

※ In the case removing it is difficult, and hooking pull thin rod into notch, and the cover can be removed easily.

※ Since oil seal is fitted on seal cover (F) (261), take care not to damage it at removing the cover.



140Z98MP18

(12) Tapping shaft ends of drive shaft (111, 113) lightly with plastic hammer, remove it from pump casing (271, 272).



140Z98MP19

(13) Remove shoe plate (211) and swash plate (212) from pump casing (271, 272).



140Z98MP20

(14) Insert thin steel bar into the hole and remove the lock pin (255) from pump casing (271, 272).

※ When holding with thin steel bar, do not confuse the unlocking hole with the arc shaped oil passage.



140Z98MP21

(15) Remove valve plate (313, 314) from valve block (312).

※ These may be removed in Work 8.



140Z98MP22

If necessary, remove stopper (L) (534), Qmin. plug (533), servo piston (532) and tilting pin (531) from pump casing (271, 272), and needle bearing (124) from valve block.

- ※ When removing tilting pin, use a protector to prevent pin head from being damaged.
- ※ Since lock tight is applied to fitting areas of tilting pin (531) and servo piston (532), take care not to damage servo piston (532).
- ※ Do not remove needle bearing (124) as far as possible, except the case that considered to be out of its life span.
- ※ Do not loosen hexagon nuts of valve block (312) and Qmin. plug (533).
If loosened, flow setting will be changed.

4) ASSEMBLY


(1) For reassembling reverse the disassembling procedures, paying attention to the following items.

- ① Do not fail to repair the parts damaged during disassembling, and repair replacement parts in advance.
- ② Clean each part fully with cleaning oil and dry it with compressed air.
- ③ Do not fail to apply clean working oil to sliding sections, bearings, etc. before assembling them.
- ④ In principle, replace seal parts, such as O-rings, oil seals, etc.
- ⑤ For fitting bolts, plug, etc., prepare a torque wrench or so on, and tighten them with torques shown in page 8-11, 12.
- ⑥ For the double-pump, take care not to mix up parts of the front pump with those of the rear pump.

(2) Insert the lock pin (255) after the swash plate support (251) into the pump casing (271, 272), and fit the lock pin (255) into the hole of the swash plate support (251).

※ In case the servo piston, tilting pin, stopper (L), stopper (S), and Qmin. plug have been removed, attached then to the pump casing in advance.

※ In the tightening work of the servo piston and the tilting pin, use the tool not to damaged the head of the tilting pin and the feed back pin. Besides, apply loctite (of medium strength) to the thread portion.



140Z98MP23

(3) Fit tilting bush (214) of swash plate (212) to tilting pin (531), and fit swash plate (212) with shoe plate (211) to swash plate support (251) correctly.

- ※ Confirm with fingers of both hands that swash plate can be removed smoothly.
- ※ Apply grease to sliding sections of swash plate (212) and swash plate support (251), and drive shaft (111, 113) can be fitted easily.
- ※ Take care not to damage shoe plate (211) surface.



140Z98MP24

(4) To pump casing (271, 272), fit drive shaft (111, 113) set with bearing (123), bearing spacer (127) and stop ring (824).



140Z98MP25

(5) In assemble of front pump, assemble seal cover (F) (261) to pump casing (271) and fix it with hexagon socket head bolt (406).

- ※ Apply grease lightly to oil seal in seal cover (F) (261).
- ※ For assemble oil seal (774), taking full care not to damage it.



140Z98MP26

(6) Assemble piston cylinder subassembly [cylinder (141), piston subassembly (151, 152), set plate (153), spherical bush (156) and cylinder spring (157)]. Fitting spline phases of cylinder, spherical bush (156) and drive shaft (111, 113), insert piston cylinder subassembly into pump casing (271, 272).



140Z98MP27

- (7) Fit valve plate (313, 314) to valve block (312), spring pin (886) into pin hole.
※ Take care not to mistake suction/delivery direction of valve plate (312).



140Z98MP28

- (8) Place pump horizontally on workbench with its regulator fitting surface down, and attach pump casing (271, 272) to valve block (312). Fit 1st gear (116) simultaneously.
※ Before bringing regulator fitting surface down, spread rubber sheet on workbench without fail to prevent this surface from being damaged.
※ Take care not to mistake direction of valve block (312). [Clockwise rotation (viewed from input shaft side)]. Fit the valve block (312) with suction flange left when regulator side below, viewed from front side.



140Z98MP29

- (9) Fix valve block (312) to pump casing (271, 272) with hexagon socket head bolts (401).



140Z98MP30

- (10) Fit gear pump (04) to pump casing (272) with hexagon socket head bolts (435).



140Z98MP31

- (11) Attach the PTO unit (05) by fastening the flange socket (435) to the valve block (312).



140Z98MP32

- (12) In case the pump is not provided with the PTO unit (05), attach the cover (262) with the hexagon socket head cap screw (414).



140Z98MP33

- (13) Putting feedback lever (611) of regulator into feedback pin (548) of tilting pin (531), fit regulator with hexagon socket head bolt (415).

※ Take care not to mix up regulator of front pump and that of rear pump.









140Z98MP34

- (14) Fit drain port plug (468).
This is the end of reassembling procedures.


3. REGULATOR

1) STRUCTURE (1/2)



140Z92MP04

STRUCTURE (2/2)





140Z92MP05

| | | |
|--------------------------|----------------------|---------------|
| 079 EPPR valve assembly | 624 Spring seat (C) | 708 O-ring |
| 412 Hexagon socket screw | 625 Outer spring | 724 O-ring |
| 413 Hexagon socket screw | 626 Inner spring | 725 O-ring |
| 418 Hexagon socket screw | 627 Adjust stem (C) | 728 O-ring |
| 437 Hexagon socket screw | 628 Adjust screw (C) | 730 O-ring |
| 438 Hexagon socket screw | 629 Cover (C) | 734 O-ring |
| 439 Hexagon socket screw | 630 Lock nut | 753 O-ring |
| 466 Plug | 631 Sleeve, Pf | 755 O-ring |
| 496 Plug | 641 Pilot cover | 757 O-ring |
| 601 Casing | 643 Pilot piston | 801 Nut |
| 611 Feed back lever | 644 Spring seat (Q) | 802 Nut |
| 612 Lever (1) | 645 Adjust stem (Q) | 814 Snap ring |
| 613 Lever (2) | 646 Pilot spring | 836 Snap ring |
| 614 Center plug | 651 Sleeve | 874 Pin |
| 615 Adjust plug | 652 Spool | 875 Pin |
| 616 Plug | 653 Spring seat | 887 Pin |
| 621 Compensator piston | 654 Return spring | 897 Pin |
| 622 Piston case | 655 Set spring | 898 Pin |
| 623 Compensator rod | 656 Block cover | 924 Set screw |

2) TOOLS AND TIGHTENING TORQUE

(1) Tools

The tools necessary to disassemble/reassemble the pump are shown in the follow list.

| Tool name & size | | Part name | | | |
|---|---|--|---------------------|---------------------|------------------------------|
| Name | B | Hexagon socket head bolt | PT plug (PT thread) | PO plug (PF thread) | Hexagon socket head setscrew |
| Allen wrench  | 4 | M5 | BP-1/16 | - | M 8 |
| | 5 | M6 | BP-1/8 | - | M10 |
| | 6 | M8 | BP-1/4 | PO-1/4 | M12, M14 |
| Double ring spanner, socket wrench, double (single) open end spanner  | - | Hexagon head bolt | Hexagon nut | VP plug (PF thread) | |
| | 6 | M 8 | M 8 | - | |
| Adjustable angle wrench | | Small size, Max 36 mm | | | |
| Screw driver | | Minus type screw driver, Medium size, 2 sets | | | |
| Hammer | | Plastic hammer, 1 set | | | |
| Pliers | | For snap ring, TSR-160 | | | |
| Steel bar | | 4 × 100 mm | | | |
| Torque wrench | | Capable of tightening with the specified torques | | | |
| Pincers | | - | | | |
| Bolt | | M4, Length : 50 mm | | | |

(2) Tightening torque


| Part name | Bolt size | Torque | | Wrench size | |
|---|-----------|---------|----------|-------------|----|
| | | kgf · m | lbf · ft | in | mm |
| Hexagon socket head bolt (material : SCM435) | M 5 | 0.7 | 5.1 | 0.16 | 4 |
| | M 6 | 1.2 | 8.7 | 0.20 | 5 |
| | M 8 | 3.0 | 21.7 | 0.24 | 6 |
| | M10 | 5.8 | 42.0 | 0.31 | 8 |
| | M12 | 10.0 | 72.3 | 0.39 | 10 |
| | M14 | 16.0 | 116 | 0.47 | 12 |
| | M16 | 24.0 | 174 | 0.55 | 14 |
| | M18 | 34.0 | 246 | 0.55 | 14 |
| | M20 | 44.0 | 318 | 0.67 | 17 |
| PT Plug (material : S45C) ※Wind a seal tape 1 1/2 to 2 turns round the plug | PT1/16 | 0.7 | 5.1 | 0.16 | 4 |
| | PT 1/8 | 1.05 | 7.59 | 0.20 | 5 |
| | PT 1/4 | 1.75 | 12.7 | 0.24 | 6 |
| | PT 3/8 | 3.5 | 25.3 | 0.31 | 8 |
| | PT 1/2 | 5.0 | 36.2 | 0.39 | 10 |
| PF Plug (material : S35C) | PF 1/4 | 3.0 | 21.7 | 0.24 | 6 |
| | PF 1/2 | 10.0 | 72.3 | 0.39 | 10 |
| | PF 3/4 | 15.0 | 109 | 0.55 | 14 |
| | PF 1 | 19.0 | 137 | 0.67 | 17 |
| | PF 1 1/4 | 27.0 | 195 | 0.67 | 17 |
| | PF 1 1/2 | 28.0 | 203 | 0.67 | 17 |

3) DISASSEMBLY


Since the regulator consists of small precision finished parts, disassembly and assembly are rather complicated.

For this reason, replacement of a regulator assembly is recommended, unless there is a special reason, but in case disassembly is necessary for an unavoidable reason, read through this manual to the end before starting disassembly.

- (1) Choose a place for disassembly.
 - ※ Choose a clean place.
 - ※ Spread rubber sheet, cloth, or so on on top of work-bench to prevent parts from being damaged.
- (2) Remove dust, rust, etc. from surfaces of regulator with clean oil.
- (3) Remove hexagon socket head screw (412, 413) and remove regulator main body from pump main body.
 - ※ Take care not to lose O-ring.




- (4) Remove hexagon socket head screw (438) and remove cover (C,629)
 - ※ Cover (C) is fitted with adjusting screw (C, 628), adjusting ring (C, 627), lock nut (630), hexagon nut (801) and adjusting screw (924).
 - ※ Do not loosen these screws and nuts. If they are loosened, adjusted pressure-flow setting will vary.




- (5) After removing cover (C, 629) subassembly, take out outer spring (625), inner spring (626) and spring seat (C, 624) from compensating section.

Then draw out adjusting ring (Q, 645), pilot spring (646) and spring seat (644) from pilot section.

- ※ Adjusting ring (Q,645) can easily be drawn out with M4 bolt.




- (6) Remove hexagon socket head screws (436, 438) and remove pilot cover (641). After removing pilot cover, take out set spring (655) from pilot section.




- (7) Remove snap ring (814) and take out spring seat (653), return spring (654) and sleeve (651).


- ※ Sleeve (651) is fitted with snap ring (836).
- ※ When removing snap ring (814), return spring (654) may pop out. Take care not to lose it.




- (8) Remove prevention plug (616) and take out center plug (614) and adjusting plug (615).

- ※ Center plug (614) and adjusting plug (615) can easily be taken out with M6 bolt.







- (9) Remove lever (2, 613). Do not draw out pin (875).
※ Work will be promoted by using pincers or so on.



- (10) Draw out pin (874) and remove feedback lever (611).
Push out pin (874, 4 mm in dia.) from above with slender steel bar so that it may not interfere with lever (1, 612).



- (11) Remove lever (1, 612). Do not draw out pin (875).
 - (12) Draw out pilot piston (643) and spool (652).
 - (13) Draw out piston case (622), compensating piston (621) and compensating rod (623).
- ※ Piston case (622) can be taken out by pushing compensating rod (623) at opposite side of piston case.

This completes disassembly.

4) ASSEMBLY

(1) For assembly, reverse disassembly procedures, but pay attention to the following items.


- ① Always repair parts that were scored at disassembly.
- ② Get replacement parts ready beforehand.
Mixing of foreign matter will cause malfunction.
Therefore, wash parts well with cleaning oil, let them dry with jet air and handle them in clean place.
- ③ Always tighten bolts, plugs, etc. to their specified torques.
- ④ Do not fail to coat sliding surfaces with clean hydraulic oil before assembly.
- ⑤ Replace seals such as O-ring with new ones as a rule.

(2) Put compensating rod (623) into compensating hole of casing (601).


(3) Put pin force-fitted in lever (1, 612) into groove of compensating rod and fit lever (1) to pin force-fitted in casing.

(4) Fit spool (652) and sleeve (651) into hole in spool of casing.


- ※ Confirm that spool and sleeve slide smoothly in casing without binding.
- ※ Pay attention to orientation of spool.




- (5) Fit feedback lever (611), matching its pin hole with pin hole in spool.
Then insert pin (874).
- ※ Insert pin in feedback lever a little to ease operation.
 - ※ Take care not to mistake direction of feedback lever.




- (6) Put pilot piston (643) into pilot hole of casing.
- ※ Confirm that pilot piston slides smoothly without binding.
- (7) Put pin force-fitted in lever (2, 613) into groove of pilot piston.
Then fix lever (2).



- (8) Fit center plug (614) so that pin force-fitted in center plug (614) can be put into pin hole of lever (2).
Then install prevention plug (858).
- (9) Insert adjusting plug (615) and fit locking ring.
- ※ Take care not to mistake inserting holes for fulcrum plug and adjusting plug.
- At this point in time move feedback lever to confirm that it has no large play and is free from binding.




- (10) Fit return spring (654) and spring seat (653) into spool hole and attach snap ring (814).




- (11) Fit set spring (655) to spool hole and put compensating piston (621) and piston case (622) into compensating hole.

Fit pilot cover (641) and tighten it with hexagonal socket head screws (437, 438).




- (12) Put spring seat (644), pilot spring (646) and adjusting ring (Q, 645) into pilot hole. Then fix spring seat (624), inner spring (626) and outer spring (625) into compensating hole.

※ When fitting spring seat, take care not to mistake direction of spring seat.



- (13) Install cover (C, 629) fitted with adjusting screws (628), adjusting ring (C, 627), lock nut (630), hexagon nut (801) and adjusting screw (924).

Then tighten them with hexagonal socket head screws (438).



This completes assembly.

GROUP 4 MAIN CONTROL VALVE

1. REMOVAL AND INSTALL OF MOTOR




1) REMOVAL

- (1) Lower the work equipment to the ground and stop the engine.
 - (2) Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping.
 - (3) Loosen the breather slowly to release the pressure inside the hydraulic tank.
- ▲ Escaping fluid under pressure can penetrate the skin causing serious injury.
- ※ When pipes and hoses are disconnected, the oil inside the piping will flow out, so catch it in oil pan.
- (4) Remove the wirings for the pressure sensor and so on.
 - (5) Remove bolts and disconnect pipe.
 - (6) Disconnect pilot line hoses.
 - (7) Disconnect pilot piping.


- (8) Sling the control valve assembly and remove the control valve mounting bolt and bracket.
 - Weight : 140 kg (309 lb)
 - Tightening torque : $12.2 \pm 1.3 \text{ kgf} \cdot \text{m}$
($88.2 \pm 9.4 \text{ lbf} \cdot \text{ft}$)
- (9) Remove the control valve assembly.
When removing the control valve assembly, check that all the piping have been disconnected.

2) INSTALL

- (1) Carry out installation in the reverse order to removal.
- (2) Bleed the air from below items.
 - ① Cylinder (Boom, arm, bucket)
 - ② Swing motor
 - ③ Travel motor※ See each item removal and install.
- (3) Confirm the hydraulic oil level and recheck the hydraulic oil leak or not.




2. STRUCTURE (1/4)



145A8MC04

| | | | | | |
|----|-----------------------|----|--------------------|----|------------------|
| 1 | Housing-P1 | 26 | Lock valve kit B | 51 | Pilot B1 cap |
| 4 | Spool assy-travel LH | 27 | Regeneration block | 53 | Socket head bolt |
| 7 | Spool assy-boom 1 | 33 | Plug | 56 | Plain washer |
| 10 | Spool assy-arm 2 | 41 | Plug | 58 | O-ring |
| 12 | Spool assy-arm regen | 42 | Plug | 59 | O-ring |
| 14 | Spool assy-bucket | 45 | Poppet | 69 | O-ring |
| 20 | Nega con relief valve | 48 | Orifice | 81 | Spring |
| 22 | Bucket stroke limiter | 49 | Coin type filter | 82 | Pin-regeneration |
| 24 | Holding valve kit A1 | 50 | Pilot A cap | | |

STRUCTURE (2/4)




145A8MC05

- 16 Main relief valve
- 17 Overload relief valve
- 28 Plug
- 29 Plug
- 31 Plug
- 32 Plug
- 34 Plug
- 35 Plug
- 39 Plug

- 43 Poppet
- 44 Poppet
- 58 O-ring
- 59 O-ring
- 61 O-ring
- 62 O-ring
- 63 O-ring
- 66 O-ring
- 67 O-ring

- 71 O-ring
- 72 O-ring
- 74 Back up ring
- 75 Back up ring
- 76 Back up ring
- 79 Spring
- 80 Spring
- 83 Plug


STRUCTURE (3/4)



145A8MC06

- | | | | | | |
|----|----------------------------|----|------------------------|----|------------------|
| 2 | Housing-P2 | 26 | Lock valve kit-B | 54 | Socket head bolt |
| 3 | Spool assy-straight travel | 29 | Plug | 55 | Socket head bolt |
| 4 | Spool assy-travel RH | 30 | Plug | 56 | Plain washer |
| 6 | Spool assy-swing | 40 | Plug | 57 | Spring washer |
| 8 | Spool assy-swing priority | 46 | Travel straight sleeve | 59 | O-ring |
| 9 | Spool assy-boom 2 | 47 | Travel straight piston | 61 | O-ring |
| 11 | Spool assy-arm 1 | 50 | Pilot A cap | 63 | O-ring |
| 13 | Spool assy-option B | 51 | Pilot B1 cap | 69 | O-ring |
| 15 | Spool assy-dozer | 52 | Pilot B2 cap | 75 | Back up ring |
| 25 | Holding valve kit A2 | 53 | Socket head bolt | | |

STRUCTURE (4/4)



145A8MC07

- | | | | | | |
|----|-----------------------|----|------------------|----|--------------|
| 17 | Overload relief valve | 37 | Plug | 65 | O-ring |
| 19 | Overload relief valve | 43 | Poppet | 67 | O-ring |
| 21 | Swing logic valve | 44 | Poppet | 68 | O-ring |
| 23 | ON/OFF valve-option | 48 | Orifice-signal | 72 | O-ring |
| 28 | Plug | 49 | Coin type filter | 73 | O-ring |
| 29 | Plug | 59 | O-ring | 77 | Back up ring |
| 31 | Plug | 60 | O-ring | 78 | Back up ring |
| 32 | Plug | 62 | O-ring | 79 | Spring |
| 34 | Plug | 63 | O-ring | 80 | Spring |
| 36 | Plug | 64 | O-ring | | |

3. DISASSEMBLY AND ASSEMBLY

1) GENERAL PRECAUTIONS

- (1) All hydraulic components are manufactured to a high precision. Consequently, before disassembling and assembling them, it is essential to select an especially clean place.
- (2) In handling a control valve, pay full attention to prevent dust, sand, etc. from entering into it.
- (3) When a control valve is to be removed from the machine, apply caps and masking seals to all ports. Before disassembling the valve, recheck that these caps and masking seals are fitted completely, and then clean the outside of the assembly. Use a proper bench for working. Spread paper or a rubber mat on the bench, and disassemble the valve on it.
- (4) Support the body section carefully when carrying or transferring the control valve. Do not lift by the exposed spool, end cover section etc.
- (5) After disassembling and assembling of the component it is desired to carry out various tests (for the relief characteristics, leakage, flow resistance, etc.), but hydraulic test equipment is necessary for these tests. Therefore, even when its disassembling can be carried out technically, do not disassemble such components that cannot be tested, adjusted, and so on. Additionally one should always prepare clean cleaning oil, hydraulic oil, grease, etc. beforehand.

2) TOOLS


Before disassembling the control valve, prepare the following tools beforehand.

| Name of tool | Quantity | Size (mm) |
|-----------------------------------|--------------|--|
| Vice mounted on bench (soft jaws) | 1 unit | |
| Hexagon wrench | Each 1 piece | 5, 6, 10, 12 and 14 |
| Socket wrench | Each 1 piece | 27 and 32 |
| Spanner | Each 1 piece | 32 (main relief valve, overload relief valve, negative relief valve) 26 (holding valve) |

3) DISASSEMBLY

(1) Disassembly of spools without holding valve


- ① Loosen hexagon socket head bolts with washer.
(hexagon wrench : 5 mm)
 - ② Remove the pilot cover.
- ※ Pay attention not to lose the O-ring under the pilot cover.
 - ③ Remove the spool assembly from the body by hand slightly.
- ※ When extracting each spool from its body, pay attention not to damage the body.
 - ※ When extracting each spool assembly, it must be extracted from spring side only.
 - ※ When any abnormal parts are found, replace it with completely new spool assembly.
 - ※ When disassembled, tag the components for identification so that they can be reassembled correctly.



145LCR8MC10

(2) Disassembly of spools with holding valve (boom 1, Arm 1 spool)


- ① Loosen hexagon socket head bolts with washer.
(hexagon wrench : 5 mm)
- ② Remove the pilot cover with internal parts.
 - ※ Pay attention not to lose the O-ring and the poppet under the pilot cover.
 - ※ Pay attention not to damage the "piston A" under pilot cover.
- ③ Remove the spool assembly from the body by hand slightly.
 - ※ When extracting each spool from its body, pay attention not to damage the body.
 - ※ When extracting each spool assembly, it must be extracted from spring side only.
 - ※ When any abnormal parts are found, replace it with completely new spool assembly.
 - ※ When disassembled, tag the components for identification so that they can be reassembled correctly.



145LCR8MC11

(3) Disassembly of the holding valve


- ① Remove the pilot cover with the holding valve as described on previous page.
 - ※ Do not disassemble internal parts of the pilot cover.
- ② Loosen the poppet seat and remove the poppet, spring seat, spring and check.
(spanner : 26 mm)
 - ※ Pay attention not to lose the poppet.
 - ※ Do not disassemble internal parts of the check.



145LCR8MC12

(4) Disassembly of the load check valve and the negative relief valve

- ① The load check valve
 - a. Fix the body to suitable work bench.
 - ※ Pay attention not to damage the body.
 - b. Loosen the plug (hexagon wrench : 10 mm).
 - c. Remove the spring and the load check valve with pincers or magnet.
- ② The negative relief valve
 - a. Loosen the socket (spanner : 32 mm).
 - b. Remove the spring, spring holder, piston and negative control poppet.



14W98MC13

(5) Disassembly of the main and overload relief valve

① Fix the body to suitable work bench.



② Remove the main relief valve.
(spanner : 32 mm)

③ Remove the overload relief valve.
(spanner : 32 mm)

※ When disassembled, tag the relief valve for identification so that they can be reassembled correctly.

※ Pay attention not to damage seat face.

※ When any abnormal parts are found, replace it with completely new relief valve assembly.



145LCR8MC14

(6) Inspection after disassembly

Clean all disassembled parts with clean mineral oil fully, and dry them with compressed air. Then, place them on clean papers or cloths for inspection.

① Control valve

- a. Check whole surfaces of all parts for burrs, scratches, notches and other defects.
- b. Confirm that seal groove faces of body and block are smooth and free of dust, dent, rust etc.
- c. Correct dents and damages and check seat faces within the body, if any, by lapping.
※ Pay careful attention not to leave any lapping agent within the body.
- d. Confirm that all sliding and fitting parts can be moved manually and that all grooves and paths are free foreign matter.
- e. If any spring is broken or deformed, replace it with new one.
- f. When a relief valve does not function properly, repair it, following it's the prescribed disassembly and assembly procedures.
- g. Replace all seals and O-rings with new ones.

② Relief valve

- a. Confirm that all seat faces at ends of all poppets and seats are free of defects and show uniform and consistent contact faces.
- b. Confirm manually that main poppet and seat can slide lightly and smoothly.
- c. Confirm that outside face of main poppet and inside face of seat are free from scratches and so on.
- d. Confirm that springs are free from breakage, deformation, and wear.
- e. Confirm that orifices of main poppet and seat section are not clogged with foreign matter.
- f. Replace all O-rings with new ones.
- g. When any light damage is found in above inspections, correct it by lapping.
- h. When any abnormal part is found, replace it with a completely new relief valve assembly.

4) ASSEMBLY

(1) General precaution

- ① In this assembly section, explanation only is shown.
For further understanding, please refer to the figures shown in the previous structure & disassembly section.
- ② Pay close attention to keeping all seals free from handling damage and inspect carefully for damage before using them.
- ③ Apply clean grease or hydraulic oil to the seal so as to ensure it is fully lubricated before assembly.
Do not stretch seals so much as to deform them permanently.
- ④ In fitting O-rings, pay close attention not to roll them into their final position in addition, a twisted
- ⑤ O-ring cannot easily untwist itself naturally and could thereby cause inadequate sealing and thereby both internal and external oil leakage.
- ⑥ Tighten fitting bolts for all sections with a torque wrench adjusted to the respective tightening torque.
- ⑦ Do not reuse removed O-rings and seals.

(2) Load check valve

- ① Assemble the load check valve and spring.
- ② Put O-rings on to plug.
- ③ Tighten plug to the specified torque.
 - Hexagon wrench : 10 mm
 - Tightening torque : 6~7 kgf · m (43.4~50.6 lbf · ft)

(3) Negative control relief valve

- ① Assemble the nega-con poppet, piston, spring holder and spring together into body.
- ② Put O-ring on to plug and tighten the latter to its specified torque.
 - Hexagon wrench : 12 mm
 - Tightening torque : 8~9 kgf · m (57.8~65.1 lbf · ft)

(4) Main relief, overload relief valves

Install main relief valve, overload relief valve into the body and tighten to the specified torque.

| Component | Tools | Tightening torque | |
|-----------------------|---------------|-------------------|-----------|
| | | kgf · m | lbf · ft |
| Main relief valve | Spanner 32 mm | 8~9 | 57.8~65.1 |
| Overload relief valve | Spanner 32 mm | 8~9 | 57.8~65.1 |

(5) Main spools

- ① Carefully insert the previously assembled spool assemblies into their respective bores within of body.
- ※ Fit spool assemblies into body carefully and slowly. Do not under any circumstances push them forcibly in.

(6) Pilot covers

① Fit spool covers to the non-spring assembly end of the spool, and tighten the hexagonal socket head bolts to the specified torque.

- Hexagon wrench : 5 mm
- Tightening torque : 1.0~1.1 kgf · m (7.2~7.9 lbf · ft)

※ Confirm that O-rings have been fitted.

② Fit spring covers to the spring end for the spools, and tighten hexagon socket head bolts to the specified torque.

- Hexagon wrench : 5mm
- Tightening torque : 1.0~1.1 kgf·m (7.2~7.9 lbf·ft)

※ Confirm that O-rings have been fitted.

(7) Holding valves

① Assemble the check, spring seat and poppet together into body.

② Tighten the poppet seat to the specified torque.

- Spanner : 26 mm
- Tightening torque : 6~7 kgf · m (43.4~50.6 lbf · ft)

③ Fit the "piston A" under pilot cover with internal parts into hole on the poppet seat.

④ Tighten hexagon socket head bolt to specified torque.

- Hexagon wrench : 5mm
- Tightening torque : 1.0~1.1 kgf · m (7.2~7.9 lbf · ft)

GROUP 5 SWING DEVICE

1. REMOVAL AND INSTALL OF MOTOR

1) REMOVAL

- (1) Lower the work equipment to the ground and stop the engine.
- (2) Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping.
- (3) Loosen the breather slowly to release the pressure inside the hydraulic tank.

▲ Escaping fluid under pressure can penetrate the skin causing serious injury.

※ When pipes and hoses are disconnected, the oil inside the piping will flow out, so catch it in oil pan.



- (4) Disconnect hose assembly (2).
- (5) Disconnect pilot line hoses (3, 4, 5, 6, 7, 8).
- (6) Sling the swing motor assembly (1) and remove the swing motor mounting socket bolts (9).
 - Weight : 130 kg (287 lb)
 - Tightening torque : 29.6 ± 3.2 kgf · m
(214 ± 23.1 lbf · ft)

- (7) Remove the swing motor assembly.

※ When removing the swing motor assembly, check that all the piping have been disconnected.



2) INSTALL

- (1) Carry out installation in the reverse order to removal.
- (2) Bleed the air from the swing motor.
 - ① Remove the air vent plug.
 - ② Pour in hydraulic oil until it overflows from the port.
 - ③ Tighten plug lightly.
 - ④ Start the engine, run at low idling and check oil come out from plug.
 - ⑤ Tighten plug fully.
- (3) Confirm the hydraulic oil level and check the hydraulic oil leak or not.



2. DISASSEMBLY AND ASSEMBLY OF SWING MOTOR

1) STRUCTURE



| | | | | | |
|----|----------------|----|----------------|----|-------------------------|
| 1 | Casing | 15 | Shoe | 29 | Spring |
| 2 | Oil seal | 16 | Separate plate | 30 | Plug assy |
| 3 | Ball bearing | 17 | Friction plate | 31 | Relief valve assy |
| 4 | Drive shaft | 18 | O-ring | 32 | Port block assy |
| 5 | Shoe plate | 19 | O-ring | 33 | Socket bolt |
| 6 | Rotary block | 20 | Brake piston | 34 | Socket bolt |
| 7 | Washer | 21 | Spring | 35 | Name plate |
| 8 | Spring | 22 | Valve casing | 36 | Screw |
| 9 | Snap ring | 23 | Spring pin | 37 | Plug |
| 10 | Roller | 24 | Ball bearing | 38 | Plug |
| 11 | Collar washer | 25 | Valve plate | 39 | Reactionless valve assy |
| 12 | Thrust ball | 26 | O-ring | 40 | Snap ring |
| 13 | Retainer plate | 27 | Plug assy | 41 | Socket bolt |
| 14 | Piston | 28 | Plunger | | |

140A2SM02

3. REMOVAL AND INSTALL OF REDUCTION GEAR


1) REMOVAL

- (1) Remove the swing motor assembly.
For details, see removal of swing motor assembly.
- (2) Sling reduction gear assembly (1) and remove dowel pin (3) and mounting bolts (2).
- (3) Remove the reduction gear assembly.
 - Reduction gear device weight : 75 kg
(165 lb)




2) INSTALL

- (1) Carry out installation in the reverse order to removal.
 - Tightening torque : 29.6 ± 3.2 kgf · m
(214 ± 23.1 lbf · ft)



4. DISASSEMBLY AND ASSEMBLY OF REDUCTION GEAR

1) STRUCTURE



125LCR2SM23

| | | | | | |
|----|----------------------|----|----------------------|----|-------------------|
| 1 | Ring gear | 11 | Planetary gear No. 2 | 21 | Carrier pin No. 1 |
| 2 | Drive shaft | 12 | Needle bearing | 22 | Sun gear No. 1 |
| 3 | Taper roller bearing | 13 | Thrust washer | 23 | Snap ring |
| 4 | Taper roller bearing | 14 | Carrier pin No. 2 | 24 | Thrust plate |
| 5 | Ring nut | 15 | Spring pin | 25 | Sleeve |
| 6 | Lock plate | 16 | Sun gear No. 2 | 26 | O-ring |
| 7 | Hexagon bolt | 17 | Carrier No. 1 | 27 | Oil seal |
| 8 | Casing | 18 | Planetary gear No. 1 | 30 | Socket plug |
| 9 | Socket bolt | 19 | Needle bearing | 31 | Parallel pin |
| 10 | Carrier No. 2 | 20 | Thrust washer | 32 | Thrust washer |

2) DISASSEMBLY

- (1) Remove the swing motor, and then place swing reduction gear on the bench.



125LCR8SM60

- (2) Disassemble sun gear No.1 (22).



125LCR8SM61

- (3) Disassemble carrier No.1 sub assembly.



125LCR8SM62

Carrier No.1 sub assy disassembly

- (4) Put carrier No.1 sub assembly on the bench, then remove the snap ring (23).



125LCR8SM63

(5) Disassemble thrust washer (upper) (32).(3 pcs)



125LCR8SM64

(6) Disassemble planetary gear No.1 (18). (3 pcs)



125LCR8SM65

(7) Disassemble thrust plate (24).



125LCR8SM66

(8) Disassemble needle bearing (19). (3 pcs)



125LCR8SM67

(9) Disassemble thrust washer (lower) (20). (3 pcs)



125LCR8SM68

(10) After placing spring pin (15) to center of carrier pin No.1 (21) with a jig, disassemble it. (3 pcs)

※ Do not reuse spring pin, carrier and carrier pin.



125LCR8SM69

(11) Disassemble sun gear No.2 (16).



125LCR8SM70

(12) Disassemble carrier No.2 sub assembly.



125LCR8SM71

Carrier No.2 sub assy disassembly

(13) After placing spring pin (15) to center of carrier pin No.2 (14) with a press machine, disassemble it.(3 pcs)

※ Do not reuse spring pin.



125LCR8SM72

(14) Disassemble planetary gear No.2.(3 pcs)



125LCR8SM73

(15) Disassemble thrust plate (24).



125LCR8SM74

(16) Disassemble thrust washer No.2 (13).(6 pcs)



125LCR8SM75

(17) Disassemble needle bearing (12). (3 pcs)



125LCR8SM76

(18) Separate ring gear (1) from casing (8).



125LCR8SM77

(19) Loosen bolt (7) (4 pcs), and disassemble lock plate (6).



125LCR8SM78

(20) Disassemble ring nut (5) by using the jig.



125LCR8SM79

Drive shaft sub assy disassembly

(21) Separate drive shaft sub assembly from casing (8).



125LCR8SM80

(22) Disassemble taper roller bearing (3) and oil seal (27) by using a press machine.



125LCR8SM81

(23) Disassemble sleeve (25) and O-ring (26).



125LCR8SM82

(24) Disassemble the outer ring of taper roller bearing (3) in casing (8) by using the jig.



125LCR8SM83

3) ASSEMBLY

※ Even though assembly is accomplished by reversing disassembly steps, be careful of the following.

- ① Repair the damaged part when disassembling and prepare parts for exchange in advance.
- ② All parts should be cleaned with cleaner, dried with compressed air.
- ③ Sliding surface, O-ring, bearing and oil seal should be lubricated with clean hydraulic oil, prior to final assembly.
- ④ Replacement of O-ring and oil seal with new parts is generally recommended.
- ⑤ Use a torque wrench to make sure that assembly fasteners are tightened to specified values.
- ⑥ When assembling bolt, spread loctite.

Carrier No.1 sub assembly

- (1) After heating the carrier No.1 (17), assemble carrier pin No.1 (21) to the side without the hole.




125LCR8SM84

- (2) After drilling $\varnothing 6$ hole, assemble spring pin (15).(3 pcs)



125LCR8SM85

- (3) Caulking is performed on the assembled spring pin unit.
- ※ To cover pins, implement the caulking in two places that are located direction of 180 degrees around assembled spring pin.



125LCR8SM86

- (4) Assemble thrust washer (20). (3 pcs)



125LCR8SM87

- (5) Assemble needle bearing (19).(3 pcs)



125LCR8SM88

- (6) Assemble thrust plate (24).



125LCR8SM89

- (7) Assemble planetary gear No.1 (18) of which groove is faced downward.(3 pcs)



125LCR8SM90

- (8) Assemble thrust washer (upper) (32). (3 pcs)



125LCR8SM91

- (9) Assemble snap ring (23) (3 pcs), complete carrier No.1 sub assembly.

※ Gear rotation state should be smooth.



125LCR8SM92

Carrier No.2 sub assy assembly

- (10) Assemble needle bearing (12) in the planetary gear No.2 (11).



125LCR8SM93

- (11) After spreading grease on thrust washer (13), assemble it on both upper side and lower side of planetary gear No.2.



125LCR8SM94

- (12) Assemble thrust plate (24).



125LCR8SM95

- (13) Assemble planetary gear No.2 in the carrier No.2 (10).(3 pcs)
※ Thrust washer should not separated.



125LCR8SM96

- (14) Assemble carrier pin No.2 (14) to match the pin hole of the carrier No.2.(3 pcs)



125LCR8SM97


(15) Assemble spring pin (15).(3 pcs)



125LCR8SM98

(16) Caulking is performed on the assembled spring pin unit.

- ※ To cover pins, implement the caulking in two places that are located direction of 180 degrees around assembled spring pin.



125LCR8SM99

Drive shaft sub assy assembly

(17) After heating sleeve (25), assemble O-ring (26) to groove of inside diameter in it.



125LCR8SM100

(18) Shrink fit the sleeve on drive shaft (2).

- ※ Be careful of fully seat at the bottom.



125LCR8SM101

- (19) Shrink fit taper roller bearing (3) on drive shaft, complete drive shaft sub assembly.



125LCR8SM102

Casing assembly

- (20) Press outer ring of the taper roller bearing in the casing (8) by using the jig.



125LCR8SM103

- (21) Press in oil seal (27) by using the jig.
※ Be careful of the direction of the assembly.



125LCR8SM104

- (22) Assemble drive shaft sub assembly.
※ Be careful of damage of oil seal.



125LCR8SM105

(23) After fixing drive shaft so that it does not fall, and then turn it over, press taper bearing (4).



125LCR8SM106

(24) Assemble nut ring (5) by using the jig.

※ Tightening torque : 3.5 ± 0.4 kgf · m
(25.3 ± 2.9 lbf · ft)



125LCR8SM107

(25) Place lock plate (6) on the nut ring.



125LCR8SM108

(26) After spreading loctite #242, assemble the bolt (7) (4 pcs).

※ Tightening torque : 2.5 ± 0.25 kgf · m
(18.1 ± 1.8 lbf · ft)




125LCR8SM109

(27) Press parallel pin (31) by using press machine.



125LCR8SM110

(28) Spread the loctite #515 on the casing with reference to the right detail view.
※ Loctite should not flow into casing.



125LCR8SM111

(29) Assemble ring gear (1) in accordance with a pin hole on casing.
※ Be careful of damage of the ring gear.




125LCR8SM112

(30) Assemble carrier No.2 sub assembly.



125LCR8SM113

(31) Assemble sun gear No.2 (16).




125LCR8SM114

(32) Assemble carrier No.1 sub assembly.



125LCR8SM115

(33) Assemble sun gear No.1 (22) of which grinding surface is faced downward.



125LCR8SM116

(34) Fill with gear oil 3.5 liter.



125LCR8SM117

GROUP 6 TRAVEL DEVICE (STD, TYPE 1)

1. REMOVAL AND INSTALL

1) REMOVAL

- (1) Swing the work equipment 90° and lower it completely to the ground.
- (2) Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping.
- (3) Loosen the breather slowly to release the pressure inside the hydraulic tank.

▲ Escaping fluid under pressure can penetrate the skin causing serious injury.

※ When pipes and hoses are disconnected, the oil inside the piping will flow out, so catch it in oil pan.

- (4) Remove the track shoe assembly.
For details, see **removal of track shoe assembly**.

- (5) Remove the cover.

- (6) Remove the hose.

※ Fit blind plugs to the disconnected hoses.

- (7) Remove the bolts and the sprocket.
 - Tightening torque : 29.7 ± 3.0 kgf · m
(215 ± 21.7 lbf · ft)

- (8) Sling travel device assembly (1).

- (9) Remove the mounting bolts (2), then remove the travel device assembly.

· Weight : 139 kg (306 lb)

· Tightening torque : 25.7 ± 3.0 kgf · m
(186 ± 21.7 lbf · ft)

2) INSTALL

- (1) Carry out installation in the reverse order to removal.

- (2) Bleed the air from the travel motor.

① Remove the air vent plug.


② Pour in hydraulic oil until it overflows from the port.

③ Tighten plug lightly.



④ Start the engine, run at low idling, and check oil come out from plug.

⑤ Tighten plug fully.

- (3) Confirm the hydraulic oil level and check the hydraulic oil leak or not.



2. TRAVEL MOTOR



- | | | | | |
|----------------------|--------------------|-----------------------------|------------------------|---------------------------|
| 1 Casing | 19 Parking piston | 37 Spring seat | 55 Restrictor | 73 Needle bearing |
| 2 Plug | 20 O-ring | 38 Relief valve assy | 56 Restrictor | 74 Inner race No. 1 |
| 3 Oil seal | 21 Back up ring | 39 O-ring | 57 Name plate | 75 Thrust plate |
| 4 Piston | 22 O-ring | 40 Spool | 58 Rivet | 76 Hexagon head bolt |
| 5 Piston seal | 23 Back up ring | 41 Plug | 59 Ring gear | 77 Countersunk head screw |
| 6 Shaft | 24 Valve plate | 42 Spring seat | 60 Bearing | 78 Sun gear No.1 |
| 7 Front ball bearing | 25 Spring pin | 43 Parallel pin | 61 Floating seal assy | 79 O-ring |
| 8 Rear ball bearing | 26 Spring | 44 Spring | 62 Nut ring | 80 Cover |
| 9 Steel ball | 27 O-ring | 45 Connector | 63 Lock plate | 81 Hex socket head bolt |
| 10 Pivot | 28 Spring pin | 46 O-ring | 64 Hexagon head bolt | 82 Plug |
| 11 Swash plate | 29 Parallel pin | 47 Hexagon socket head bolt | 65 Thrust plate | 83 O-ring |
| 12 Cylinder block | 30 Rear cover | 48 Hexagon socket head bolt | 66 Planetary gear No.2 | 84 Name plate |
| 13 Spring | 31 Main spool assy | 49 Hexagon socket head bolt | 67 Needle bearing | 85 Rivet |
| 14 Ball guide | 32 Cover | 50 Check valve | 68 Inner race No. 2 | 86 Rubber cap |
| 15 Retainer plate | 33 Spring | 51 Spring | 69 Thrust washer | 87 Rubber cap |
| 16 Piston assy | 34 Restrictor | 52 Plug | 70 Sun gear No.2 | 88 Plain washer |
| 17 Friction plate | 35 Spring | 53 O-ring | 71 Carrier No.1 | 89 Hexagon bolt |
| 18 Separated plate | 36 O-ring | 54 Plug | 72 Planetary gear No.1 | 90 Thrust plate |

130ZF2TM21


2) DISASSEMBLY

- (1) Choose a clean place, remove contaminants (dust, etc) and cleans motor before placing it on worktable.
 - ※ Lay the rubber plate on worktable and take care not to damage the component.




125LCR8TM02

- (2) Remove the connector (45) using 21 mm socket wrench.




125LCR8TM03

- (3) Remove plug (41) using 21 mm socket wrench.



125LCR8TM04

- (4) Disassemble parallel pin (43) and spring (44).
 - ※ Do not lose spring.
 - ※ Do not mix spring with other springs.



125LCR8TM05

(5) Remove spring seat (42) and spool (40).




125LCR8TM06

(6) Disassemble relief valve assembly (38) using 26 mm socket wrench. (2 sets)



125LCR8TM07

(7) Disassemble cover (32) using 41 mm socket wrench.




125LCR8TM08

(8) Disassemble spring seat (37) and spring (33). (2 sets)



125LCR8TM09

(9) Separate main spool assembly (31) from rear cover.



125LCR8TM10

(10) Unscrew socket bolt (47) (1EA), (48) (3EA), (49) (6EA) from rear cover.



125LCR8TM11

(11) Remove parallel pin (29).



125LCR8TM12

(12) From rear cover, disassemble valve plate (24) and O-ring (27).

※ Take care not to damage assembly surface of rear cover.



125LCR8TM13

(13) Disassemble restrictor (55, 56) (2EA).

- ※ Mark the number on restrictor and its hole to avoid confusing (55) and (56).



125LCR8TM14


(14) Remove plug (52).



125LCR8TM15


(15) Remove restrictor (34) and spring (35). (2 sets)

- ※ Do not confuse restrictor (34) and check valve (50).
- ※ Do not confuse spring (35) and spring (51).
- ※ Do not lose spring.
- ※ Do not mix spring with other springs.



125LCR8TM16


(16) Remove plug (52) using 5 mm hexagon wrench.



125LCR8TM17

(17) Remove check valve (50) and spring (51). (2 sets)

- ※ Do not confuse restrictor (34) and check valve (50).
- ※ Do not confuse spring (35) and spring (51).
- ※ Do not lose spring.
- ※ Do not mix spring with other springs.



125LCR8TM18

(18) From parking piston, remove spring (26) (12ea).

- ※ Do not lose spring.
- ※ Do not mix spring with other springs.



125LCR8TM19

(19) Disassemble parking piston (19) using air gun or jig.



125LCR8TM20

(20) From parking piston, separate O-ring (22) and back-up ring (23).



125LCR8TM21

(21) From parking piston separate O-ring (20) and back-up ring (21).



125LCR8TM22

(22) Lay casing down horizontally and remove cylinder block assembly, friction plate (17) (3EA) and separator plate (18) (4EA).



125LCR8TM23

(23) Separate retainer plate (15) and piston assembly (16).

※ Take care not to damage sliding surface of each component.




125LCR8TM24

(24) Disassemble ball guide (14) and spring (13) (9EA).

※ Do not lose spring.


※ Do not mix spring with other springs.



125LCR8TM25

(25) Disassemble swash plate (11) and pivot (10).

※ Take care not to damage sliding surface.



125LCR8TM26

(26) Disassemble shaft (6) and ball bearing (7).

※ Do not remove ball bearing unless malfunction is detected, since it is mounted by shrink fit.



125LCR8TM27

(27) Disassemble 1, 2 speed piston (4) and steel ball (9) using air gun.



125LCR8TM28

(28) Disassemble piston seal (5).



125LCR8TM29

(29) Turn casing (1) upside down and remove oil seal (3) using jig.



125LCR8TM30

3) ASSEMBLY

※ Even though assembly is accomplished by reversing disassembly steps, be careful of the following.

- ① Repair the damaged part when disassembling and prepare parts for exchange in advance.
- ② All parts should be cleaned with cleaner, dried with compressed air.
- ③ Sliding surface, O-ring, bearing and oil seal should be lubricated with clean hydraulic oil, prior to final assembly.
- ④ Replacement of O-ring and oil seal with new parts is generally recommended.
- ⑤ Use a torque wrench to make sure that assembly fasteners are tightened to specified values shown table 1.
- ⑥ When assembling bolt, spread Loctite.

(1) Put casing (1) on the worktable.



125LCR8TM31

(2) After applying grease on the external diameter of oil seal (3), insert oil seal in casing.



125LCR8TM32

- (3) After applying grease on pivot (10), insert steel ball in casing.



125LCR8TM33

- (4) After assembling piston seal (5) and steel ball (9) in 1, 2 speed piston (4), insert piston in hole of casing.

- ※ Check whether piston sticks in hole.
- ※ Use piston seal jig.



125LCR8TM34

- (5) Mount ball bearing (7) on shaft (6) by shrink fit. Insert shaft in casing.

- ※ Take care not to damage oil seal.



125LCR8TM35

- (6) Assemble swash plate (11) by matching its hole and steel ball.

- ※ Take care not to damage sliding surface.



125LCR8TM36

- (7) Assemble spring (13) (9ea) and ball guide (14) in cylinder block (12) in that order.



125LCR8TM37

- (8) Insert piston assembly (16) in retainer plate (15) and assemble them in cylinder block.
※ Spread hydraulic oil on piston assembly.
※ Take care not to damage each component.
※ Check cylinder block and piston assembly runs properly.




125LCR8TM38

- (9) Lay casing down horizontally and assemble cylinder block assembly by matching its spline with shaft.
※ Make sure swash plate stays in place.
※ Check the assembling status of cylinder block by pressing it.



125LCR8TM39

- (10) Assemble separator plate (18) (4EA) and friction plate (17) (3EA) alternately.



125LCR8TM40

(11) Insert back-up ring & O-ring in parking piston.



125LCR8TM41

(12) Align the pin hole of parking piston (19) with oil hole of casing, assemble them using jig.
※ Spread grease on O-ring and back-up ring.
※ Take care not to damage components.



125LCR8TM42

(13) Insert spring (26) (12EA) in parking piston.



125LCR8TM43

(14) Insert parallel pin (29) (2EA) in casing.



125LCR8TM44

(15) Assemble check valve (50) and spring (51) in order.

※ Do not confuse check valve (50) and restrictor (34).


※ Do not confuse spring (51) and spring (35)



125LCR8TM45

(16) Clamp plug (52) using 5 mm hexagon wrench.

※ Tightening torque : $3.0 \pm 0.3 \text{ kgf} \cdot \text{m}$
($21.7 \pm 2.2 \text{ lbf} \cdot \text{ft}$)




125LCR8TM46

(17) Assemble restrictor (34) and spring (35) in order.

※ Do not confuse check valve (50) and restrictor (34).

※ Do not confuse spring (51) and spring (35).



125LCR8TM47

(18) Clamp plug (52).

※ Tightening torque : $3.0 \pm 0.3 \text{ kgf} \cdot \text{m}$
($21.7 \pm 2.2 \text{ lbf} \cdot \text{ft}$)



125LCR8TM48

(19) Clamp plug (54).


- ※ Tightening torque : $4.5 \pm 0.5 \text{ kgf} \cdot \text{m}$
($32.5 \pm 3.6 \text{ lbf} \cdot \text{ft}$)



125LCR8TM49

(20) Assemble restrictor (55) and (56) in rear cover.

- ※ Check whether the restrictor is placed in exact hole.
- ※ Do not confuse (55) and (56).



125LCR8TM50

(21) Assemble ball bearing (8) in rear cover using jig.



125LCR8TM51

(22) Insert spring pin (25) (2ea) and (28) in rear cover using jig.



125LCR8TM52

(23) After spreading grease sufficiently to the bottom side of valve plate (24), assemble valve plate in rear cover by matching its holes with pins.

- ※ Take care not to damage sliding surface.
- ※ Pay attention to the assembly direction.



125LCR8TM53

(24) Assemble O-ring (27) in rear cover.

- ※ Spread grease on O-ring.



125LCR8TM54


(25) Put rear cover upon casing, paying attention to the location of pin and hole. And tighten bolt (47), (48) and (49).

- ※ Tightening torque : $17.5 \pm 1.8 \text{ kgf} \cdot \text{m}$
($127 \pm 13.0 \text{ lbf} \cdot \text{ft}$)
- ※ Make sure valve plate stays in place.
- ※ Check bolt position.



125LCR8TM55


(26) Assemble main spool assembly (31), spring seat (37) and spring (33) in rear cover.



125LCR8TM56

(27) Settle cover (32).


- ※ Tightening torque : 15 ± 1.5 kgf · m
(108 ± 10.8 lbf · ft)



125LCR8TM57

(28) Insert relief valve (38) in rear cover.


- ※ Tightening torque : 15 ± 1.8 kgf · m
(108 ± 13.0 lbf · ft)



125LCR8TM58


(29) After clamping connector (45) to rear cover, assemble spool (40).

- ※ Tightening torque : 5.5 ± 0.5 kgf · m
(39.8 ± 3.6 lbf · ft)



125LCR8TM59


(30) After inserting parallel pin (43), assemble seat-spring (42).



125LCR8TM60

(31) After assembling spring (44) in order, clamp plug (41).

※ Tightening torque : $5.5 \pm 0.5 \text{ kgf} \cdot \text{m}$
($39.8 \pm 3.6 \text{ lbf} \cdot \text{ft}$)



125LCR8TM61

3. TRAVEL REDUCTION GEAR DISASSEMBLY

1) While travel reduction gear is tilted to one side disassemble PF3/8 plug (82), remove gear oil and place motor side to the bench.



125LCR8TM70

2) Disassemble cover (80) by unscrewing the M10 bolts (81) (12 pcs).



125LCR8TM71

3) Disassemble sun gear No.1 (78).



125LCR8TM72

4) Disassemble carrier No.1 assembly.



125LCR8TM73

Carrier No. 1 sub assy disassembly

5) Disassemble M8 bolt (76) from the carrier assembly. (3 pcs)



125LCR8TM74

6) Disassemble thrust plate No.1 (75) from the carrier assembly.



125LCR8TM75

7) Disassemble planetary gear No.1 (72).(3 pcs)



125LCR8TM76

8) Disassemble needle bearing (73).(3 pcs)

※ Do not disassemble inner race in the absence of abnormalities.



125LCR8TM77

9) Disassemble Sun gear No.2 (70).



125LCR8TM78

10) Disassemble M10 bolt (64).(4 pcs)



125LCR8TM79

11) Disassemble thrust washer (65).(4 pcs)



125LCR8TM80

12) Disassemble planetary gear No.2 (66).(4 pcs)



125LCR8TM81

13) Disassemble needle bearing (67).(4 pcs)



125LCR8TM82

14) Disassemble thrust plate (69).(4 pcs)

※ Do not disassemble inner race in the absence of abnormalities.



125LCR8TM83

15) Disassemble M10 bolt (89), plain washer (88) and M8 screw (77).



125LCR8TM84

16) Disassemble lock plate (63).



125LCR8TM85

17) Disassemble nut ring (62) by using the jig.



125LCR8TM86

18) Disassemble ring gear assembly (59) from motor assembly.



125LCR8TM87

19) Disassemble floating seal assembly (61) from ring gear assembly and motor assembly.



125LCR8TM88

20) Disassemble bearing (60) (2ea) from ring gear assembly.

※ Do not disassemble bearing in the absence of abnormalities.



125LCR8TM89

4. TRAVEL REDUCTION GEAR ASSEMBLY

※ Even though assembly is accomplished by reversing disassembly steps, be careful of the following.

- ① Repair the damaged part when disassembling and prepare parts for exchange in advance.
- ② All parts should be cleaned with cleaner, dried with compressed air.
- ③ Sliding surface, O-ring, bearing and oil seal should be lubricated with clean hydraulic oil, prior to final assembly.
- ④ Replacement of O-ring and oil seal with new parts is generally recommended.
- ⑤ Use a torque wrench to make sure that assembly fasteners are tightened to specified values.
- ⑥ When assembling bolt, spread loctite.

1) Put carrier No.1 (71) on the jig, and shrink-fit inner race No.1 (74) to carrier pin.(3 places)

※ Do not tilt inner race to one side.

※ Match inner race and end of carrier pin.



125LCR8TM90

2) Assemble needle bearing No.1 (73).(3 pcs)



125LCR8TM91

3) Assemble planetary gear No.1 (72) of which groove is faced downward. (3 places)



125LCR8TM92

4) Assemble thrust plate (75).



125LCR8TM93

5) After spreading loctite #242, assemble the M8 bolt (76).(3 pcs)

※ Tightening torque : $2.7 \pm 0.3 \text{ kgf} \cdot \text{m}$

※ After the assembly, instantly check the noise and interference by rotatong the gear.



125LCR8TM94

6) First, place bearing (60) on the ring gear (59), then put jig on it, then press it with press machine.




125LCR8TM95

- 7) After turning ring gear over, assemble bearing the same way.
※ Be care of nick and safety when turn ring gear over.



125LCR8TM96

- 8) Assemble folating seal assembly (61) by using the jig.
※ After assembling, wipe steel-lined section with alcohol.
※ Flatness deviation has to be less than 1 mm.



125LCR8TM97

- 9) Place folating seal assembly on the motor assembly then assemble it.
※ After assembling, wipe steel-lined section with alcohol.
※ Flatness deviation has to be less than 1 mm.



125LCR8TM98

- 10) After arriving safely ring gear assembly in the motor assembly, press it with press machine.
※ After press-fitting, clamp ring gear to fix it.
※ When using the press pay attention to bearing damage.



125LCR8TM99

14) Shrink fit the inner race No.2 (68).(4 pcs)



125LCR8TM104

15) Assemble thrust plate (69).(4 pcs)



125LCR8TM105

16) Assemble needle bearing (67).(4 pcs)



125LCR8TM106

17) Assemble planetary gear No.2 (66).(4 pcs)

※ Grooves of planetary gear will be facing up.



125LCR8TM107

18) Assemble thrust washer (65).(4 pcs)



125LCR8TM108

19) After spreading loctite #242, assemble the M10 bolt (64).(4 pcs)

※ Tightening torque : $5.5 \pm 0.6 \text{ kgf} \cdot \text{m}$
($39.8 \pm 4.3 \text{ lbf} \cdot \text{ft}$)



125LCR8TM109

20) Assemble sun gear No.2 (70).



125LCR8TM110

21) Assemble carrier No.1 assembly.




125LCR8TM111

22) Assemble sun gear No.1 (72).



125LCR8TM112

23) Spread the loctite #515 on the cover (80) with reference to the right detail view.



125LCR8TM114

24) Place cover (80) to fit the bolt holes.



125LCR8TM115


25) After spreading loctite #242, assemble the M10 bolt (81).(12 pcs)

※ Tightening torque : $6.3 \pm 0.7 \text{ kgf} \cdot \text{m}$
($45.6 \pm 5.1 \text{ lbf} \cdot \text{ft}$)



125LCR8TM116

26) Inject the 2.3 ± 0.3 liter gear oil to PF3/8 tap section.



125LCR8TM117

27) After assembling the O-ring (83) to the plug (82), assemble it to the cover. (3 pcs)

※ Tightening torque : 5.5 ± 0.5 kgf · m
(39.8 ± 3.6 lbf · ft)



125LCR8TM118

TRAVEL DEVICE (HIGH WALKER, TYPE2)


1. REMOVAL AND INSTALL

1) REMOVAL

- (1) Swing the work equipment 90 ° and lower it completely to the ground.
- (2) Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping.
- (3) Loosen the breather slowly to release the pressure inside the hydraulic tank.

▲ Escaping fluid under pressure can penetrate the skin causing serious injury.

- ※ When pipes and hoses are disconnected, the oil inside the piping will flow out, so catch it in oil pan.
- (4) Remove the track shoe assembly.
For details, see **removal of track shoe assembly**.
 - (5) Remove the cover.
 - (6) Remove the hose.
 - ※ Fit blind plugs to the disconnected hoses.
 - (7) Remove the bolts and the sprocket.
 - Tightening torque : 29.7±3.0 kgf · m
(215±21.7 lbf · ft)
 - (8) Sling travel device assembly (1).
 - (9) Remove the mounting bolts (2), then remove the travel device assembly.
 - Weight : 300 kg (660 lb)
 - Tightening torque : 25.7±4.0 kgf · m
(166±28.9 lbf · ft)





2) INSTALL

- (1) Carry out installation in the reverse order to removal.
- (2) Bleed the air from the travel motor.
 - ① Remove the air vent plug.
 - ② Pour in hydraulic oil until it overflows from the port.
 - ③ Tighten plug lightly.
 - ④ Start the engine, run at low idling, and check oil come out from plug.
 - ⑤ Tighten plug fully.
- (3) Confirm the hydraulic oil level and check the hydraulic oil leak or not.

2. TRAVEL MOTOR

1) STRUCTURE




| | | | | | |
|-------------------|-------------------|----------------------|----------------|--------------------------|--------------------------|
| 1 Shaft casing | 20 Separate plate | 39 Spool | 58 Plug | 77 Shim | 91-1 Carrier No.1 |
| 2 Plug | 21 Parking piston | 40 Steel ball | 59 Spool | 81 Housing | 91-2 Sun-gear No.2 |
| 3 Oil seal | 22 O-ring | 41 Spring | 60 Orifice | 82 Main bearing | 91-3 Retaining ring |
| 4 Swash piston | 23 Back up ring | 42 Plug | 61 Orifice | 83 Floating seal | 91-4 Planetary gear No.1 |
| 5 Piston ring | 24 O-ring | 43 Spring seat | 62 Plug | 84 Shim | 91-5 Needle bearing |
| 6 Shaft | 25 Back up ring | 44 O-ring | 63 O-ring | 85 Retainer | 91-6 Thrust washer |
| 7 Bearing | 26 Orifice | 45 Wrench bolt | 64 Plug | 86 Hex head bolt | 91-7 Pin No.1 |
| 8 Steel ball | 27 O-ring | 46 Relief valve assy | 65 Pin | 87 Parallel pin | 91-8 Spring pin |
| 9 Swash plate | 28 O-ring | 47 Spool | 66 Pin | 88 Ring gear | 91-9 Spring pin |
| 10 Cylinder block | 29 Rear cover | 48 Guide | 67 Spring | 89 Coupling | 92 Sun gear No.1 |
| 11 Spring seat | 30 Spool | 49 O-ring | 68 Spring | 90 Carrier assy No.2 | 93 Cover |
| 12 Spring | 31 Check | 50 Back up ring | 69 Bearing | 90-1 Carrier No.2 | 94 Pad |
| 13 End plate | 32 Spring | 51 O-ring | 70 Valve plate | 90-2 Planetary gear No.2 | 95 Hex socket head bolt |
| 14 Snap ring | 33 Plug | 52 Back up ring | 71 Wrench bolt | 90-3 Needle bearing | 96 Hex socket Screw |
| 15 Pin | 34 O-ring | 53 Snap ring | 72 Plug | 90-4 Thrust washer | 97 Hydraulic plug |
| 16 Ball guide | 35 Spring seat | 54 plug | 73 Name plate | 90-5 Pin No.2 | 98 O-ring |
| 17 Set plate | 36 Spring | 55 O-ring | 74 Rivet | 90-6 Spring pin | 99 Name plate |
| 18 Piston assy | 37 Cover | 56 Spring | 75 Seal kit | 90-7 Thrust ring | |
| 19 Friction plate | 38 Spring | 57 Spring seat | 76 Orifice | 91 Carrier assy No.1 | |

16092TM02

2) TOOLS AND TIGHTENING TORQUE

(1) Tools

| Tool name | | Remark | |
|-----------------------------------|--------|--|---|
| Allen wrench | | 2, 5, 4, 6, 10 |  |
| Socket for socket wrench, spanner | Socket | 8, 14, 24, 27 | |
| Torque wrench | | Capable of tightening with the specified torques | |
| Pliers | | - | |
| Plastic and iron hammer | | Wooden hammer allowed. Normal 1 or so | |
| Monkey wrench | | - | |
| Oil seal inserting jig | | - | |
| Bearing pliers | | - | |
| Seal tape | | - | |
| Eye bolt | | M10, M12, M14 | |
| Press (0.5 ton) | | - | |
| Oil stone | | - | |
| Bearing assembling jig | | - | |

(2) Tightening torque

| Part name | Item | Size | Torque | |
|----------------------|------|-----------|-----------|-----------|
| | | | kgf · m | lbf · ft |
| Plug | 2 | NPT 1/16 | 1 ± 0.1 | 7.2 ± 0.7 |
| Orifice | 26 | M5 | 0.7 ± 0.1 | 5 ± 0.7 |
| Wrench bolt | 45 | M12 × 40 | 10 ± 1.0 | 72 ± 7.0 |
| Relief valve | 46 | HEX 27 | 18 ± 1.0 | 130 ± 7.0 |
| Plug | 54 | PF 1/2 | 8.5 ± 1.0 | 61 ± 7.0 |
| Plug | 58 | HEX 24 | 5 ± 1.0 | 36 ± 7.0 |
| Plug | 62 | PF 1/4 | 5 ± 1.0 | 36 ± 7.0 |
| Wrench bolt | 71 | M12 × 35 | 10 ± 1.0 | 72 ± 7.0 |
| Hex head bolt | - | M12 × 25 | 11 ± 1.5 | 79 ± 10 |
| Hex socket head bolt | - | M12 × 155 | 11 ± 1.5 | 79 ± 10 |
| Hex socket head plug | - | PF 3/4 | 19 ± 1 | 137 ± 7.0 |


3. OUTLINE OF DISASSEMBLING

1) GENERAL SUGGESTIONS

- (1) Select a clean place for dismantling.
Spread a rubber plate on a working table in order to prohibit the damage of parts.
- (2) Clean a deceleration equipment and a motor part, washing out dirt and unnecessary substances.
- (3) Without any damage of O-ring, oil seal, the adhered surface of other seals, a gear, a pin, the adhered surface of other bearings, and the surface of moisturized copper, treat each parts.
- (4) Numbers written in the parenthesis, (), next to the name of a part represent the part numbers of a cross-sectional view annexed with a drawing.
- (5) The side of a pipe in a motor can be written as a rear side; the side of out-put as a front side.
- (6) Using and combining a liquid gasket, both sides must be dried completely before spraying a liquid gasket.
- (7) In case of bonding bolts, combine a standard torque by torque wrench after spraying loctite 262 on the tab parts. (It can be dealt as assembling NPTF screws and an acceleration equipment.)

2) DISASSEMBLING

- (1) Unloosing wrench bolt and disassemble cover (37).
※ Wrench bolt = M12 × 40L-8 EA
(purchasing goods)




21078TM21

- (2) Disassemble parts related to counterbalance valve.




21078TM22

- (3) Unloosing wrench bolt (M12×35L, 16 EA) and disassemble rear cover assembly from motor assembly.




21078TM23




21078TM24

- (4) Dismantle packing piston (21) using compressed air.



21078TM25

- (5) Disassembly rotary kit from motor assembly (cylinder block assembly, piston assembly, ball guide, set plate, friction plate, steel plate...)



21078TM26

- (6) Using a jig, disassemble swash plate (9) from shaft casing.



21078TM27

- (7) Using compressed air, disassemble piston swash (4) piston ring (5), respectively.




21078TM28



21078TM29

- (8) Using a hammer, disassemble shaft (6) from shaft casing (1).



21078TM30

■ Disassemble cylinder sub.

- (9) Disassemble cylinder block assembly, piston assembly (9) and seat plate (M).



21078TM31



21078TM32

- (10) Disassemble ball guide (16), ring and pin (15) from cylinder block, respectively.



21078TM33



21078TM34



21078TM35

(11) Pushing spring (12) by an assembling jig, disassemble snap ring (14), spring seat (13), spring (12) and spring seat (11), respectively.




21078TM36



21078TM37

■ Disassemble valve casing sub.

(12) Using an hexagon wrench, unloosing wrench bolt (45) and disassemble cover (37), spring (38), spool (39), spring seat (43), spring (36) and spring seat (35), respectively.
(same balance on both sides)




21078TM38



21078TM39

(13) Disassemble spool (59), spool (47), O-ring (51), guide (48) and snap ring (53) on rear cover, respectively.




21078TM40



21078TM41

(14) Using a torque wrench, disassemble relief valve assembly (46) on rear cover.



21078TM42

4. OUTLINE FOR ASSEMBLING

1) GENERAL SUGGESTIONS

- (1) After washing each parts cleanly, dry it with compressed air.
Provided that you do not wash friction plate with treated oil.
- (2) In bonding each part, fasten bond torque.
- (3) When using a hammer, do not forget to use a plastic hammer.

2) ASSEMBLING

■ Assemble the sub of turning axis

- (1) Using a jig, assemble oil seal (3) into shaft casing (1)



21078TM43

- (2) Have a bearing (8) thermal reacted into shaft (6).



21078TM44



21078TM45



21078TM46

- (3) Using a jig, assemble shaft assembly into shaft casing (1).



21078TM47

- (4) After spreading grease on steel ball (8) assemble into shaft casing (1).




21078TM48

- (5) Assemble swash piston assembly (4, 5) into shaft casing (1).



21078TM49

- (6) Assemble swash plate (9) into shaft casing (1).




21078TM50

■ Assemble cylinder block sub.

- (7) Assemble spring seat (13), spring (12), spring seat (11) into cylinder block (10) respectively, pushing spring (12) using by a jig, assemble snap ring (14) with a snap ring (14).



21078TM51



21078TM52

(8) Assemble ring, pin (15) on cylinder block (10) ball guide (16) respectively.



21078TM53



21078TM54




21078TM55

(9) Assemble cylinder block assembly, piston assembly (9), seat plate (17).




21078TM56



21078TM57

(10) Assemble cylinder block assembly (9) into shaft casing (1).




21078TM58

(11) Assemble friction plate (19) and plate (20) into shaft casing (1) respectively, prepare 6 set.



21078TM59




21078TM59-1

(12) Assemble O-ring (22, 23) into packing piston (21).



21078TM60



21078TM60-1

(13) After spreading grease on packing piston (21) bond wrench bolt and assemble shaft casing (1).



21078TM61

■ Assemble rear cover sub.

(14) Using a jig, assemble bearing (69) into rear cover (29).




21078TM62


- (15) After assembling spool (59), spool (47), O-ring (51), guide (48) and snap ring (53) respectively into rear cover (29). Using torque wrench, assemble it.



21078TM63



21078TM64




21078TM65


(16) Assemble spring seat (35), spring (36), spring seat (43), spool (39), spring (38), cover (37) respectively and assemble wrench bolt (45).
(same balance on both sides)



21078TM66



21078TM67



21078TM67-1

(17) Assemble plug (2).


※ Plug (NPT1/16) - 11 EA



21078TM68



21078TM69




21078TM70



21078TM71


(18) Assemble plug (64).

※ Plug (PT3/8) - 11 EA




21078TM72

(19) Assemble plug (62, 63) into rear cover (29) and assemble relief valve assembly.



21078TM73



21078TM74

(20) Put spring (67, 68) together into rear cover (29), prepare 6 set.




21078TM75




21078TM76

(21) Assemble valve plate (70) into rear cover (29).




21078TM77

(22) After assembling shaft casing (1) and rear cover (29).
Assemble spool assembly (30), spring (38), spool (39), cover (37) after then complete assembly with wrench bolt (45).



21078TM78

(23) Finish assembly.



21078TM79

5. DISASSEMBLING REDUCTION UNIT


1) PREPARATION FOR DISASSEMBLING

- (1) The reduction units removed from excavator are usually covered with mud. Wash outside of propelling unit and dry it.
- (2) Locate reducer in order for drain port to be at the lowest level loosen taper screw plug of drain port, and drain oil from reduction gear.
 - ※ While oil is still hot, inside of the unit may be pressurized.

▲ Take care of the hot oil gushing out of the unit when loosening the plug.

(3) Mark for mating

Put marks on each mating parts when disassembling so as to reassemble correctly as before.



21078TM80

2) SETTING REDUCTION UNIT (OR WHOLE PROPELLING UNIT) ON WORK STAND FOR DISASSEMBLING

- (1) Remove M12 hexagon socket head bolts (95) at 3 places from cover (93) almost equally apart each other, and then install M12×155L eye bolts. Lift up the unit using them and place it on work stand with cover upward.


▲ Take great care not to pinch your hand between parts while disassembling nor let fall parts on your foot while lifting them.



21078TM81

3) REMOVING COVER

- (1) Remove the rest of M12 hexagon socket head bolts (95) that securing gear and housing. Loosen all the socket bolts and then, disassemble cover.
- (2) As the cover (93) is adhered to ring gear (88), disassemble ring gear (88) and cover (93) by lightly hammering slantwise upward using sharpened punch inserted between the cover and ring gear.



21078TM82

4) REMOVING NO.1 CARRIER SUB ASSEMBLY

- (1) Screw three M10 eye-bolt in No.1 carrier and lift up and remove No.1 carrier Assy.



21078TM83

- (2) Remove No.1 sun gear

- ※ Be sure to maintain it vertical with the ground when disassembling No.1 sun gear.



21078TM84

5) REMOVING NO.2 CARRIER SUB ASSEMBLY

- (1) Screw three M10 eye-bolt in No.2 carrier and lift up and remove No.2 carrier Assy.



21078TM85

- (2) Remove No.2 sun gear


- ※ Be sure to maintain it vertical with the ground when disassembling No.2 sun gear.



21078TM86

6) REMOVING RING GEAR


- (1) As the ring gear (88) is adhered to housing (81), disassemble ring gear (88) and housing (81) by lightly hammering slantwise upward using sharpen punch inserted between the ring gear and housing.
 - ※ Carefully disassembling ring gear not to make scratch on it.
- (2) Screw M14 eye-bolt in ring gear and lift up and remove it.



21078TM87

7) REMOVING COUPLING


- (1) Remove coupling.



21078TM88

8) REMOVING RETAINER & SHIM

- (1) Remove M12 hexagon socket head bolts that secure retainer and motor.
- (2) Remove retainer & shim.



21078TM89

9) REMOVING HOUSING SUB ASSEMBLY

- (1) Screw M12 eye bolt in housing and lift up housing assembly including angular bearing and floating seal.



21078TM90

10) REMOVING FLOATING SEAL


- (1) Lift up a piece of floating seal of motor side.



21078TM91

11) DISASSEMBLING HOUSING ASSEMBLY

- (1) After turning housing, lift up a piece of floating seal from housing and then remove it.
- ※ Don't disassemble angular bearing.



21078TM92

12) DISASSEMBLING NO.1 CARRIER

- (1) Remove thrust ring (90-7) from carrier.
- (2) Knock spring pin (91-8) fully into No.1 pin (91-7).
- (3) Remove planetary, thrust washer, No.1 pin, bearing from carrier.



21078TM93



21078TM94



21078TM95

13) DISASSEMBLING NO.2 CARRIER

- (1) Disassemble No.2 carriers, using the same method for No.1 carrier assembly.



21078TM96



21078TM97

6. ASSEMBLY REDUCTION GEAR

1) GENERAL NOTES

Clean every part by kerosene and dry them by air blow.

Surfaces to be applied by locktite must be decreased by solvent.

Check every part for any abnormalities.

Each hexagon socket head bolt should be used with locktite No. 262 applied on its threads.

Apply gear oil slightly on each part before assembling.

Take great care not to pinch your hand between parts or tools while assembling nor let fall parts on your foot while lifting them.

Inspection before reassembling

Thrust washer

- Check if there are seizure, abnormal wear or uneven wear.
- Check if wear is over the allowable limit.

Gears

- Check if there are pitting or seizure on the tooth surface.
- Check if there are cracks on the root of tooth by die check.

Bearings

- Rotate by hand to see if there are something unusual such as noise or uneven rotation.

Floating seal

- Check flaw or score on sliding surfaces or O-ring.



21078TM98


2) ASSEMBLING NO.1 CARRIER

- (1) Put No.1 carrier (91-1) on a flat place.
- (2) Install No.1 needle bearing (91-5) into No.1 planetary gear (91-4), put 2 EA of No.1 thrust washer (91-6) on both sides of bearing, and then, install it into carrier.



21078TM99

- (3) Install No.1 pin (91-5) into No.1 carrier where the holes for No.1 pin (91-5) are to be in line with those of No.1 carrier, and then, install spring pins into the holes.



21078TM100


- (4) Caulk carrier holes as shown on the picture.
 (5) Assemble thrust ring (90-7) into carrier.



21078TM101

3) ASSEMBLING NO.2 CARRIER

- (1) Put No.2 carrier (90-1) on a flat place.
 (2) Install No.2 needle bearing (90-3) into No.2 planetary gear (90-2), put 2 EA of No.2 thrust washer (90-4) on both sides of bearing, and then, install it into carrier.



21078TM102

- (3) Install No.2 pin (90-5) into No.2 carrier where the holes for No.2 pin (90-5) are to be in line with those of No.2 carrier, and then, install spring pins into the holes.



21078TM103

- (4) Caulk carrier holes as shown on the picture.
- (5) Assembly thrust ring (90-7) into carrier.



21078TM104

4) ASSEMBLING FLOATING SEAL (83) AND MAIN BEARING (82)

- (1) Assemble floating seal into motor by use of pressing jig. Grease the contact parts for floating seal which is assembled into motor.
- (2) Heat bearing at 60~70°C and then, put into the motor side.



21078TM105


- ※ Be sure to maintain it vertical with the ground when assembling bearing and floating seal.



21078TM106

5) ASSEMBLING HOUSING

- (1) Heat housing at 60~70°C while clearing it out and then, assemble floating seal into housing by use of pressing jig.
- ※ Be sure to maintain it vertical with the ground when assembling floating seal.



21078TM705

6) INSTALLING HOUSING ASSEMBLY

- (1) Install 2 EA of M12 eye-bolt into housing assembly.
 - (2) Assemble housing into motor by use of hoist and eye-bolt.
- ※ Be sure to tighten eye-bolt deep enough.



21078TM108

7) INSTALLING MAIN BEARING (82)


- (1) Heat main bearing at 60~70 °C and then, install.
- ※ Be sure to maintain it vertical with the ground when assembling bearing.



21078TM109

8) INSTALLING RETAINER (85) AND SHIM (84)


- (1) Measure clearance between main bearing and retainer by use of jig to decide the thickness of shim and select an appropriate shim, and then, assemble retainer.
- (2) Apply locktite (#262) on M12 hexagon head bolt, and then, bolt.



21078TM110

9) INSTALLING COUPLING


- (1) Install coupling on spline of the motor.




21078TM111

10) INSTALLING RING GEAR

- (1) Apply three bone #1104 (loctite #515) on housing for ring gear without gap.
- (2) Insert lock pin into housing hole.
- (3) Install M14 eye-bolt on the tap of ring gear.
- (4) Lift ring gear and then, assemble into housing in order for hole of ring gear and parallel pin of housing to be in line.
- (5) Temporarily secure 4EA of M12 hexagon socket bolt and shim with cover thickness having appropriate torque.



21078TM112A



21078TM113

11) INSTALLING NO.2 CARRIER SUB ASSEMBLY

- (1) Install M10 eye-bolt on No.2 carrier assembly.
- (2) Lift No.2 carrier assembly and then, slowly put it down on ring gear.
- (3) Rotate planetary gear by hands and install on ring gear.



21078TM114


12) INSTALLING NO.2 SUN GEAR (91-2)

- (1) Install No.2 sun gear on the spline of No.2 carrier and No.2 planetary gear, matching teeth of them.



21078TM115

- (2) Install No.2 sun gear on the spline of No.2 carrier and No.2 planetary gear, matching teeth of them.



21078TM116

13) INSTALLING NO.1 CARRIER SUB ASSEMBLY

- (1) Install M10 eye-bolt on No.2 carrier assembly.
- (2) Lift No.1 carrier assembly and then, slowly put it down on ring gear.
- (3) Rotate planetary gear by hands and install on ring gear.



21078TM117

14) INSTALLING NO.1 SUN GEAR (92)


- (1) Put down No.1 sun gear on No.1 carrier, maintaining it vertical with spline of coupling.
- (2) Install No.1 sun gear on No.1 planetary gear, matching their teeth.



21078TM118

15) INSTALLING COVER (93)

- (1) Beat pad (94) with plastic hammer, and press it into the center of cover.
- (2) Apply three bond #1104, loctite (#515) on the ring gear for cover without gap.
- (3) Put cover on ring gear, apply loctite (#262) on M12 hexagon socket head bolt, and then, bolt.



21078TM119

- (4) Fill gear oil (5.8 liter) into drain port.
- (5) Apply gear oil on PF3/4 hydraulic plug (97) and then, bolt.



21078TM120

GROUP 7 RCV LEVER

1. REMOVAL AND INSTALL

1) REMOVAL


- (1) Lower the work equipment to the ground and stop the engine.
- (2) Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping.
- (3) Loosen the breather slowly to release the pressure inside the hydraulic tank.

▲ Escaping fluid under pressure can penetrate the skin causing serious injury.

- (4) Loosen the socket bolt (1).
Tightening torque : $1.05 \pm 0.2 \text{ kgf} \cdot \text{m}$
($7.6 \pm 1.45 \text{ lbf} \cdot \text{ft}$)
- (5) Remove the cover of the console box.
- (6) Disconnect pilot line hoses (3).
- (7) Remove the pilot valve assembly (2).
※ When removing the pilot valve assembly, check that all the hoses have been disconnected.


2) INSTALL

- (1) Carry out installation in the reverse order to removal.
- (2) Confirm the hydraulic oil level and check the hydraulic oil leak or not.



2. DISASSEMBLY AND ASSEMBLY

1) STRUCTURE




- 1 Case
- 2 Bushing
- 3 Spool
- 4 Shim
- 5 Spring
- 6 Spring seat
- 7 Spring
- 8 Plug
- 9 Push rod
- 10 O-ring
- 11 Rod seal
- 12 Spacer
- 13 Spacer
- 14 Boot
- 15 Joint assembly
- 16 Swash plate
- 17 Adjusting nut
- 18 Bushing
- 19 Plug
- 20 Handle assembly
- 21 Handle bar
- 22 Nut
- 23 Boot
- 24 Last guard filter
- 25 Connector
- 26 Connector
- 27 Connector pin
- 28 Connector pin
- 29 Connector pin
- 30 Connector pin
- 32 Connector
- 34 Connector

210S2RL06

2) TOOLS AND TIGHTENING TORQUE

(1) Tools

| Tool name | Remark | |
|---------------|--|---|
| Allen wrench | 6 |  |
| Spanne | 22 | |
| | 27 | |
| (+) Driver | Length 150 | |
| (-) Driver | Width 4~5 | |
| Torque wrench | Capable of tightening with the specified torques | |


(2) Tightening torque

| Part name | Item | Size | Torque | |
|---------------|------|------|----------|----------|
| | | | kgf · m | lbf · ft |
| Joint | 15 | M14 | 3.8 | 27.5 |
| Swash plate | 16 | M14 | 7.0±0.40 | 50.6±2.9 |
| Adjusting nut | 17 | M14 | 7.0±0.40 | 50.6±2.9 |
| Lock nut | 22 | M14 | 5.0±0.35 | 36.2±2.5 |


3) DISASSEMBLY

※ Procedures are based on the type M1.


- (1) Clean pilot valve with kerosene.
 - ※ Put blind plugs into all ports
- (2) Fix pilot valve in a vise with copper (or lead) sheets.
- (3) Remove end of boot (23) from case (1) and take it out upwards.




※ For valve with switch, remove cord also through hole of casing.





- (4) Loosen lock nut (22) and adjusting nut (17) with spanners on them respectively, and take out handle section as one body.



- (5) Remove the boot (14).





- (6) Loosen adjusting nut (17) and swash plate (16) with spanners on them respectively, and remove them.




- (7) Turn joint anticlockwise to loosen it, utilizing jig (Special tool).

- ※ When return spring (7) is strong in force, plate (12), plug (8) and push rod (9) will come up on loosening joint. Pay attention to this.




(8) Remove plate (12).




(9) When return spring (7) is weak in force, plug (8) stays in casing because of sliding resistance of O-ring.

- ※ Take it out with minus screwdriver. Take it out, utilizing external periphery groove of plug and paying attention not to damage it by partial loading.
- ※ During taking out, plug may jump up due to return spring (7) force. Pay attention to this.




(10) Remove reducing valve subassembly and return spring (7) out of casing.

- ※ Record relative position of reducing valve subassembly and return springs.




(11) Separate spool (3), spring seat (6), spring (5) and shim (4) individually.



- ※ Pay attention not to damage spool surface.
- ※ Record original position of spring seat (6).
- ※ Until being assembled, they should be handled as one subassembly group.





(12) Take push rod (9) out of plug (8).



(13) Remove O-ring (10) and seal (11) from plug (8).
Use small minus screwdriver or so on to remove this seal.



(14) Remove lock nut (22) and then boot (23).



(15) Cleaning of parts


- ① Put all parts in rough cleaning vessel filled with kerosene and clean them (rough cleaning).
 - ※ If dirty part is cleaned with kerosene just after putting it in vessel, it may be damaged. Leave it in kerosene for a while to loosen dust and dirty oil.
 - ※ If this kerosene is polluted, parts will be damaged and functions of reassembled valve will be degraded.
Therefore, control cleanliness of kerosene fully.
- ② Put parts in final cleaning vessel filled with kerosene, turning it slowly to clean them even to their insides (finish cleaning).
 - ※ Do not dry parts with compressed air, since they will be damaged and/or rusted by dust and moisture in air.

(16) Rust prevention of parts


- Apply rust-preventives to all parts.
- ※ If left as they are after being cleaned, they will be rusted and will not display their functions fully after being reassembled.

4) ASSEMBLY


- (1) Put shim (4), springs (5) and spring seat (6) onto spool (3) in this order.




- (2) Assemble spring (7) into casing (1).
Assemble reducing valve subassembly into casing.
※ Assemble them to their original positions.




- (3) Assemble O-ring (10) onto plug (8).




- (4) Assemble seal (11) to plug (8).
※ Assemble seal in such lip direction as shown below.




- (5) Assemble push rod (9) to plug (8).
※ Apply working oil on push-rod surface.



- (6) Assemble plug subassembly to casing.
※ When return spring is weak in force, subassembly stops due to resistance of O-ring.




- (7) When return spring is strong in force, assemble 4 sets at the same time, utilizing plate (12), and tighten joint (15) temporarily.




- (8) Fit plate (12).

- (9) Tighten joint (15) with the specified torque to casing, utilizing jig.




(10) Assemble swash plate (16) to joint (15).

- ※ Screw it to position that it contacts with 4 push rods evenly.
- ※ Do not screw it over.




(11) Assemble adjusting nut (17), apply spanner to width across flat of plate (16) to fix it, and tighten adjusting nut to the specified torque.



- ※ During tightening, do not change position of disk.




(12) Fit boot (14) to plate.



(13) Fit boot (23) and lock nut (22), and handle subassembly is assembled completely.




(14) Pull out cord and tube through adjusting nut hole provided in direction 60 ° to 120 ° from casing hole.




(15) Assemble bushing (18) to plate and pass cord and tube through it.


※ Provide margin necessary to operation.



(16) Determine handle direction, tighten lock nut (22) to specified torque to fix handle.




(17) Apply grease to rotating section of joint and contacting faces of disk and push rod.



(18) Assemble lower end of bellows to casing.

(19) Inject volatile rust-preventives through all ports and then put blind plugs in ports.



GROUP 8 TURNING JOINT

1. REMOVAL AND INSTALL

1) REMOVAL


- (1) Lower the work equipment to the ground and stop the engine.
- (2) Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping.
- (3) Loosen the breather slowly to release the pressure inside the hydraulic tank.

▲ **Escaping fluid under pressure can penetrate the skin causing serious injury.**

※ When pipes and hoses are disconnected, the oil inside the piping will flow out, so catch it in oil pan.


- (4) Disconnect all hoses.
- (5) Sling the turning joint assembly (1) and remove the mounting bolt (2).
 - Weight : 56 kg (123 lb)
 - Tightening torque : $12.8 \pm 3.0 \text{ kgf} \cdot \text{m}$
($92.6 \pm 21.7 \text{ lbf} \cdot \text{ft}$)

- (6) Remove the turning joint assembly.
 - ※ When removing the turning joint, check that all the hoses have been disconnected.




2) INSTALL

- (1) Carry out installation in the reverse order to removal.
 - ※ Take care of turning joint direction.
 - ※ Assemble hoses to their original positions.
 - ※ Confirm the hydraulic oil level and check the hydraulic oil leak or not.



2. DISASSEMBLY AND ASSEMBLY

1) STRUCTURE




14098TJ03

- | | | | | | |
|---|--------|----|---------------|----|---------------|
| 1 | Hub | 7 | Slipper seal | 13 | Socket plug |
| 2 | Shaft | 8 | O-ring | 14 | Socket plug |
| 3 | Cover | 9 | O-ring | 15 | Hexagon bolt |
| 4 | Spacer | 10 | O-ring | 16 | Spring washer |
| 5 | Shim | 11 | Wear ring | | |
| 6 | Shim | 12 | Retainer ring | | |

2) DISASSEMBLY


※ Before the disassembly, clean the turning joint.

(1) Remove bolts (14), washer (15) and cover (3).



(2) Remove shim (6) and O-ring (10).


(3) Remove retainer ring (12), spacer (4) and shim (5).




(4) Place hub (1) on a V-block and by using a wood buffer at the shaft end, hit out shaft (2) to about 1/2 from the body with a hammer.

※ Take care not to damage the shaft (2) when remove hub (1) or rest it sideways.

※ Put a fitting mark on hub (1) and shaft (2).




(5) Remove six slipper seals (7) and O-ring (9), two wear ring (11) from hub (1).




3) ASSEMBLY

- ※ Clean all parts.
- ※ As a general rule, replace oil seals and O-ring.
- ※ Coat the sliding surfaces of all parts with engine oil or grease before installing.


- (1) Fix seven slipper seal (7) and O-ring (9), two wear ring (11) to hub (1).
- (2) Fit O-ring (8) to shaft (2).




- (3) Set shaft (2) on block, tap hub (1) with a plastic hammer to install.



- (4) Fit shim (5), spacer (4) and retainer ring (12) to shaft (2).
- (5) Fit O-ring (10) to hub (1).
- (6) Fit shim (6) to shaft (2).



- (7) Install cover (3) to body (1) and tighten bolts (14).
- Torque : 10~12.5 kgf · m
(72.3~90.4 lbf · ft)




GROUP 9 BOOM, ARM AND BUCKET CYLINDER

1. REMOVAL AND INSTALL


1) BUCKET CYLINDER

(1) Removal


- ※ Expand the arm and bucket fully, lower the work equipment to the ground and stop the engine.
 - ※ Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping.
 - ※ Loosen the breather slowly to release the pressure inside the hydraulic tank.
 - ▲ **Escaping fluid under pressure can penetrate the skin causing serious injury.**
 - ※ Fit blind plugs in the hoses after disconnecting them, to prevent dirt or dust from entering.
- ① Set block between bucket cylinder and arm.




- ② Remove bolt (2), nut (3) and pull out pin (1).
- ※ Tie the rod with wire to prevent it from coming out.
 - Tightening torque (2) : $29.7 \pm 4.5 \text{ kgf} \cdot \text{m}$
($215 \pm 32.5 \text{ lbf} \cdot \text{ft}$)



- ③ Disconnect bucket cylinder hoses (4), grease line hose (7) and put plugs (5) on cylinder pipe.



- ④ Sling bucket cylinder assembly (8) and remove bolt (6) then pull out pin (5).
- ⑤ Remove bucket cylinder assembly (8).
 - Weight : 104 kg (229 lb)
 - Tightening torque (6) : 29.7 ± 4.5 kgf · m
(215 ± 32.5 lbf · ft)



(2) Install

- ① Carry out installation in the reverse order to removal.
- ▲ When aligning the mounting position of the pin, do not insert your fingers in the pin hole.**
- ※ Bleed the air from the bucket cylinder.
 - ※ Confirm the hydraulic oil level and check the hydraulic oil leak or not.


2) ARM CYLINDER

(1) Removal


- ※ Expand the arm and bucket fully, lower the work equipment to the ground and stop the engine.
- ※ Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping.
- ※ Loosen the breather slowly to release the pressure inside the hydraulic tank.

▲ Escaping fluid under pressure can penetrate the skin causing serious injury.


- ※ Fit blind plugs in the hoses after disconnecting them, to prevent dirt or dust from entering.
- ① Set block between arm cylinder and boom.




- ② Disconnect grease line hose (9).
 - ③ Remove bolt (2) and pull out pin (1).
- ※ Tie the rod with wire to prevent it from coming out.
 - Tightening torque (2) : $29.7 \pm 4.5 \text{ kgf} \cdot \text{m}$
($215 \pm 32.5 \text{ lbf} \cdot \text{ft}$)



- ④ Disconnect arm cylinder hoses (4) and put plugs on cylinder pipe.
- ⑤ Disconnect greasing pipings (5).



- ⑥ Sling arm cylinder assembly(8) and remove bolt (7) then pull out pin (6).
 - Tightening torque (7) : $29.7 \pm 4.5 \text{ kgf} \cdot \text{m}$
($215 \pm 32.5 \text{ lbf} \cdot \text{ft}$)
- ⑦ Remove arm cylinder assembly (8).
 - Weight : 145 kg (320 lb)



(2) Install

- ① Carry out installation in the reverse order to removal.
- ▲ When aligning the mounting position of the pin, do not insert your fingers in the pin hole.**
- ※ Bleed the air from the arm cylinder.
 - ※ Confirm the hydraulic oil level and check the hydraulic oil leak or not.


3) BOOM CYLINDER

(1) Removal


- ※ Expand the arm and bucket fully, lower the work equipment to the ground and stop the engine.
- ※ Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping.
- ※ Loosen the breather slowly to release the pressure inside the hydraulic tank.

▲ Escaping fluid under pressure can penetrate the skin causing serious injury.


- ※ Fit blind plugs in the hoses after disconnecting them, to prevent dirt or dust from entering.
- ① Disconnect greasing hoses (1).
 - ② Sling boom cylinder assembly.




- ③ Remove bolt (4), stopper (5) and pull out pin (2).
- ※ Tie the rod with wire to prevent it from coming out.
 - Tightening torque (4) : $29.7 \pm 4.5 \text{ kgf} \cdot \text{m}$
($215 \pm 32.5 \text{ lbf} \cdot \text{ft}$)




- ④ Lower the boom cylinder assembly (6) on a stand.



- ⑤ Disconnect boom cylinder hoses (7) and put plugs on cylinder pipe.



- ⑥ Remove bolt (9) and pull out pin (8).
· Tightening torque (9) : 29.7 ± 4.5 kgf · m
(215 ± 32.5 lbf · ft)
- ⑦ Remove boom cylinder assembly (6).
· Weight : 119 kg (262 lb)




(2) Install

- ① Carry out installation in the reverse order to removal.
- ▲ When aligning the mounting position of the pin, do not insert your fingers in the pin hole.**
- ※ Bleed the air from the boom cylinder.
 - ※ Confirmed the hydraulic oil level and check the hydraulic oil leak or not.


2. DISASSEMBLY AND ASSEMBLY

1) STRUCTURE

(1) Bucket cylinder




Internal detail




145WF8CY01

| | | | | | |
|----|---------------|----|--------------|----|--------------------------|
| 1 | Tube assembly | 11 | O-ring | 21 | Hexagon socket set screw |
| 2 | Rod assembly | 12 | Back up ring | 22 | Hexagon socket head bolt |
| 3 | Gland | 13 | Cushion ring | 23 | Pin bushing |
| 4 | DD2 bushing | 14 | Piston | 24 | Pin bushing |
| 5 | Snap ring | 15 | Piston seal | 25 | Dust seal |
| 6 | Rod seal | 16 | Wear ring | 26 | Band assembly |
| 7 | Back up ring | 17 | Dust ring | 27 | Pipe assembly-R |
| 8 | Buffer ring | 18 | O-ring | 28 | Pipe assembly-B |
| 9 | Dust wiper | 19 | Back up ring | 29 | O-ring |
| 10 | Snap ring | 20 | Lock nut | 30 | Hexagon socket head bolt |

(2) Arm cylinder




Internal detail




145WF8CY02

| | | | | | |
|----|---------------|----|--------------------------|----|--------------------------|
| 1 | Tube assembly | 12 | Back up ring | 23 | Hexagon socket head bolt |
| 2 | Rod assembly | 13 | Cushion ring | 24 | Pin bushing |
| 3 | Gland | 14 | Piston | 25 | Dust seal |
| 4 | DD2 bushing | 15 | Piston seal | 26 | Check valve |
| 5 | Snap ring | 16 | Wear ring | 27 | Coil spring |
| 6 | Rod seal | 17 | Dust ring | 28 | O-ring |
| 7 | Back up ring | 18 | O-ring | 29 | Plug |
| 8 | Buffer ring | 19 | Back up ring | 30 | Band assembly |
| 9 | Dust wiper | 20 | Lock nut | 31 | Pipe assembly-R |
| 10 | Snap ring | 21 | Hexagon socket set screw | 32 | O-ring |
| 11 | O-ring | 22 | O-ring | 33 | Hexagon socket head bolt |

(3) Boom cylinder




Internal detail



145WF8CY03

- | | | | | | |
|----|---------------|----|--------------|----|--------------------------|
| 1 | Tube assembly | 11 | O-ring | 21 | Hexagon socket set screw |
| 2 | Rod assembly | 12 | Back up ring | 22 | Hexagon socket head bolt |
| 3 | Gland | 13 | Cushion ring | 23 | Pin bushing |
| 4 | DD2 bushing | 14 | Piston | 24 | Dust seal |
| 5 | Snap ring | 15 | Piston seal | 25 | Band assembly |
| 6 | Rod seal | 16 | Wear ring | 26 | Pipe assembly-R |
| 7 | Back up ring | 17 | Dust ring | 27 | Pipe assembly-B |
| 8 | Buffer ring | 18 | O-ring | 28 | O-ring |
| 9 | Dust wiper | 19 | Back up ring | 29 | Hexagon socket head bolt |
| 10 | Snap ring | 20 | Lock nut | 30 | Socket plug |

(4) Dozer cylinder




145ZF8CY05

| | | | | | |
|----|---------------|----|---------------|----|--------------------------|
| 1 | Tube assembly | 11 | Back up ring | 21 | Hexagon socket head bolt |
| 2 | Rod assembly | 12 | O-ring | 22 | O-ring |
| 3 | Gland | 13 | Piston | 23 | Check valve assembly |
| 4 | Dust wiper | 14 | Piston seal | 24 | O-ring |
| 5 | Retainer ring | 15 | Wear ring | 25 | Hexagon socket head bolt |
| 6 | Rod seal | 16 | O-ring | 26 | Hexagon socket head bolt |
| 7 | Back up ring | 17 | Back up ring | 27 | Pin bushing |
| 8 | Buffer ring | 18 | Steel ball | 28 | Dust seal |
| 9 | Dry bearing | 19 | Set screw | 29 | Dust ring |
| 10 | O-ring | 20 | Pipe assembly | | |

2) TOOLS AND TIGHTENING TORQUE

(1) Tools

| Tool name | Remark | | |
|---------------|--|---|--|
| Allen wrench | 6 |  | |
| | 8 | | |
| | 14 | | |
| | 17 | | |
| Spanner | 7 | | |
| | 8 | | |
| (-) Driver | Small and large sizes | | |
| Torque wrench | Capable of tightening with the specified torques | | |

(2) Tightening torque

| Part name | Item | Size | Torque | | |
|---------------------------------------|----------------------|------|---------|------------|------------|
| | | | kgf · m | lbf · ft | |
| Socket head bolt | Bucket cylinder (★1) | 22 | M14 | 15 ± 2.0 | 108 ± 14.5 |
| | Boom cylinder (★1) | 22 | M14 | 15 ± 2.0 | 108 ± 14.5 |
| | Arm cylinder (★1) | 23 | M16 | 23 ± 2.0 | 166 ± 14.5 |
| Check valve mounting socket head bolt | Dozer cylinder | 25 | M10 | 5.4 ± 0.5 | 39.1 ± 3.6 |
| Pipe mounting socket head bolt | Bucket | 30 | M10 | 5.4 ± 0.5 | 39.1 ± 3.6 |
| | Boom | 29 | M8 | 2.7 ± 0.3 | 19.6 ± 2.2 |
| | Arm | 33 | M10 | 5.4 ± 0.5 | 39.1 ± 3.6 |
| | Dozer cylinder | 21 | M8 | 2.7 ± 0.3 | 19.5 ± 2.2 |
| Lock nut | Bucket cylinder | 20 | M45 | 100 ± 10.0 | 723 ± 72.3 |
| | Boom cylinder | 20 | M52 | | |
| | Arm cylinder | 20 | M56 | | |
| Piston | Bucket cylinder | 14 | - | 150 ± 15.0 | 1085 ± 109 |
| | Boom cylinder | 14 | | | |
| | Arm cylinder | 14 | | | |
| | Dozer cylinder | 13 | M52 | | |
| Gland | Dozer cylinder | 3 | M105 | 85 ± 8.5 | 615 ± 61.5 |
| Set screw | Bucket cylinder | 21 | M8 | 2.7 ± 0.3 | 19.5 ± 2.2 |
| | Boom cylinder | 21 | M8 | 2.7 ± 0.3 | 19.5 ± 2.2 |
| | Arm cylinder | 21 | M8 | 2.7 ± 0.3 | 19.5 ± 2.2 |
| | Dozer cylinder | 19 | M8 | 2.7 ± 0.3 | 19.5 ± 2.2 |

※ Apply loctite #243 (★1) on the thread before tightening.

3) DISASSEMBLY


(1) Remove cylinder head and piston rod

※ Procedures are based on the bucket cylinder.

① Hold the clevis section of the tube in a vise.


※ Use mouth pieces so as not to damage the machined surface of the cylinder tube. Do not make use of the outside piping as a locking means.

② Pull out rod assembly (2) about 200mm (7.1in). Because the rod assembly is rather heavy, finish extending it with air pressure after the oil draining operation.




③ Loosen and remove socket bolts (22) of the gland in sequence.

※ Cover the extracted rod assembly (2) with rag to prevent it from being accidentally damaged during operation.




④ Draw out cylinder head and rod assembly together from tube assembly (1).

※ Since the rod assembly is heavy in this case, lift the tip of the rod assembly (2) with a crane or some means and draw it out. However, when rod assembly (2) has been drawn out to approximately two thirds of its length, lift it in its center to draw it completely.




Note that the plated surface of rod assembly (2) is to be lifted. For this reason, do not use a wire sling and others that may damage it, but use a strong cloth belt or a rope.

- ⑤ Place the removed rod assembly on a wooden V-block that is set level.
- ※ Cover a V-block with soft rag.




(2) Remove piston and cylinder head

- ① Remove set screw (21).
- ※ Since set screw (21) and lock nut (20) is tightened to a high torque, use a hydraulic and power wrench that utilizes a hydraulic cylinder, to remove the lock set screw (21) and lock nut (20).
- ② Remove piston assembly (14), back up ring (19), and O-ring (18).




- ③ Remove the cylinder head assembly from rod assembly (2).
- ※ If it is too heavy to move, move it by striking the flanged part of cylinder head with a plastic hammer.
- ※ Pull it straight with cylinder head assembly lifted with a crane. Exercise care so as not to damage the lip of rod bushing (4) and packing (5,6,7,8,9,10) by the threads of rod assembly (2).




(3) Disassemble the piston assembly

- ① Remove wear ring (16).
 - ② Remove dust ring (17) and piston seal (15).
- ※ Exercise care in this operation not to damage the grooves.



(4) Disassemble cylinder head assembly

- ① Remove back up ring (12) and O-ring (11).
 - ② Remove snap ring (10), dust wiper (9).
 - ③ Remove back up ring (7), rod seal (6) and buffer ring (8).
- ※ Exercise care in this operation not to damage the grooves.
- ※ Do not remove seal and ring, if does not damaged.
- ※ Do not remove bushing (4).




3) ASSEMBLY

(1) Assemble cylinder head assembly

※ Check for scratches or rough surfaces if found smooth with an oil stone.


① Coat the inner face of gland (3) with hydraulic oil.



② Coat dust wiper (9) with grease and fit dust wiper (9) to the bottom of the hole of dust wiper.

At this time, press a pad metal to the metal ring of dust wiper.


③ Fit snap ring (10) to the stop face.



④ Fit back up ring (7), rod seal (6) and buffer ring (8) to corresponding grooves, in that order.


※ Coat each packing with hydraulic oil before fitting it.

※ Insert the backup ring until one side of it is inserted into groove.




※ Rod seal (6) has its own fitting direction. Therefore, confirm it before fitting them.

※ Fitting rod seal (6) upside down may damage its lip. Therefore check the correct direction that is shown in fig.




- ⑤ Fit back up ring (12) to gland (3).
- ※ Put the backup ring in the warm water of 30~50°C.
- ⑥ Fit O-ring (11) to gland (3).




(2) Assemble piston assembly


- ※ Check for scratches or rough surfaces. If found smooth with an oil stone.
- ① Coat the outer face of piston (14) with hydraulic oil.



- ② Fit piston seal (15) to piston.
- ※ Put the piston seal in the warm water of 60~100°C for more than 5 minutes.
- ※ After assembling the piston seal, press its outer diameter to fit in.




- ③ Fit wear ring (16) and dust ring (17) to piston (14).




(3) Install piston and cylinder head


- ① Fix the rod assembly to the work bench.
- ② Apply hydraulic oil to the outer surface of rod assembly (2), the inner surface of piston and cylinder head.
- ③ Insert cylinder head assembly to rod assembly.



- ④ Insert cushion ring (13) to rod assembly.
- ※ Note that cushion ring (13) has a direction in which it should be fitted.




- ⑤ Fit piston assembly to rod assembly.
- Tightening torque : $150 \pm 15 \text{ kgf} \cdot \text{m}$
($1085 \pm 108 \text{ lbf} \cdot \text{ft}$)





- ⑥ Fit lock nut (20) and tighten the set screw (21).
- Tightening torque :

| Item | | kgf · m | lbf · ft |
|------|--------|---------------|----------------|
| 20 | Bucket | 100 ± 10 | 723 ± 72.3 |
| | Boom | | |
| | Arm | | |
| 21 | | 2.7 ± 0.3 | 19.6 ± 2.2 |



(3) Overall assemble

- ① Place a V-block on a rigid work bench.
Mount the tube assembly (1) on it and fix the assembly by passing a bar through the clevis pin hole to lock the assembly.
- ② Insert the rod assembly in to the tube assembly, while lifting and moving the rod assembly with a crane.
 - ※ Be careful not to damage piston seal by thread of tube assembly.
- ③ Match the bolt holes in the cylinder head flange to the tapped holes in the tube assembly and tighten socket bolts to a specified torque.
 - ※ Refer to the table of tightening torque.



GROUP 10 UNDERCARRIAGE

1. TRACK LINK

1) REMOVAL

(1) Move track link until master pin is over front idler in the position put wooden block as shown.

(2) Loosen tension of the track link.

※ If track tension is not relieved when the grease valve is loosened, move the machine backwards and forwards.

※ Unscrew the grease nipple after release the tension by pushing the poppet only when necessarily required.



Grease leaking hole is not existing. So, while unscrew the grease nipple, grease is not leaking until the grease nipple is completely coming out. If the tension is not released in advance, the grease nipple can be suddenly popped out by pressurized grease.

(3) Push out master pin by using a suitable tool.

(4) Move the machine slowly in reverse, and lay out track link assembly (1).

※ Jack up the machine and put wooden block under the machine.


※ Don't get close to the sprocket side as the track shoe plate may fall down on your feet.



2) INSTALL

(1) Carry out installation in the reverse order to removal.


※ Adjust the tension of the track link.




2. UPPER ROLLER

1) REMOVAL


- (1) Loosen tension of the track link.



- (2) Jack up the track link height enough to permit upper roller removal.



- (3) Loosen the lock nut (1).
 - Tightening torque : $29.7 \pm 4.4 \text{ kgf} \cdot \text{m}$
($215 \pm 31.8 \text{ lbf} \cdot \text{ft}$)
- (4) Open bracket(2) with a screwdriver, push out from inside, and remove upper roller assembly.
 - Weight : 19 kg (42 lb)




2) INSTALL

- (1) Carry out installation in the reverse order to removal.


3. LOWER ROLLER

1) REMOVAL


- (1) Loosen tension of the track link.



- (2) Using the work equipment, push up track frame on side which is to be removed.
※ After jack up the machine, set a block under the unit.



- (3) Remove the mounting bolt (1) and draw out the lower roller (2).
 - Weight : 35 kg (77 lb)
 - Tightening torque : 29.6 ± 3.2 kgf · m
(214 ± 23.1 lbf · ft)




2) INSTALL

- (1) Carry out installation in the reverse order to removal.


4. IDLER AND RECOIL SPRING

1) REMOVAL


- (1) Remove the track link.
For detail, see removal of track link.



- (2) Sling the recoil spring (1) and pull out idler and recoil spring assembly from track frame, using a pry.
· Weight : 199 kg (439 lb)




- (3) Remove the bolts (2), washers (3) and separate idler from recoil spring.
· Tightening torque : 29.7 ± 4.5 kgf · m
(215 ± 32.5 lbf · ft)




2) INSTALL

- (1) Carry out installation in the reverse order to removal.
※ Make sure that the boss on the end face of the recoil cylinder rod is in the hole of the track frame.



3) DISASSEMBLY AND ASSEMBLY OF IDLER

(1) Structure



21078DA43


- 1 Shell
- 2 Shaft
- 3 Seal set

- 4 Bushing
- 5 Bracket
- 6 O-ring


- 7 Spring pin
- 8 Plug

(2) Disassembly


- ① Remove plug (8) and drain oil.
- ② Draw out the spring pin (7), using a press.



- ③ Pull out the shaft (2) with a press.
- ④ Remove seal set (3) from idler (1) and bracket (5).
- ⑤ Remove O-ring (6) from shaft.




- ⑥ Remove the bushing (4) from idler, using a special tool.
Only remove bushing if replacement is necessary.




(3) Assembly


- ※ Before assembly, clean the parts.
- ※ Coat the sliding surfaces of all parts with oil.
- ① Cool up bushing (4) fully by some dry ice and press it into shell (1).
Do not press it at the normal temperature, or not knock in with a hammer even after the cooling.




- ② Coat O-ring (6) with grease thinly, and install it to shaft (2).
- ③ Insert shaft (2) into bracket (5) and drive in the spring pin (7).




- ④ Install seal set (3) to shell (1) and bracket (5).




- ⑤ Install shaft (2) to shell (1).




- ⑥ Install bracket (5) attached with seal set (3).



- ⑦ Knock in the spring pin (7) with a hammer.




- ⑧ Lay bracket (5) on its side.
Supply engine oil to the specified level,
and tighten plug (8).



4) DISASSEMBLY AND ASSEMBLY OF RECOIL SPRING

(1) Structure




R210UCG01

- | | | | | | |
|---|----------|----|---------------|----|--------------|
| 1 | Body | 6 | Lock plate | 11 | Dust seal |
| 2 | Tie bar | 7 | Bolt | 12 | Adjust rod |
| 3 | Spring | 8 | Spring washer | 13 | Grease valve |
| 4 | Bracket | 9 | Rod seal | | |
| 5 | Lock nut | 10 | Back up ring | | |


(2) Disassembly

- ① Apply pressure on spring (3) with a press.
 - ※ The spring is under a large installed load. This is dangerous, so be sure to set properly.
 - Spring set load : 11132 kg (24542 lb)
- ② Remove bolt (7), spring washer (8) and lock plate (6).
- ③ Remove lock nut (5).


Take enough notice so that the press which pushes down the spring, should not be slipped out in its operation.
- ④ Lighten the press load slowly and remove bracket (4) and spring (3).



- ⑤ Remove rod (12) from body (1).
- ⑥ Remove grease valve (13) from rod (12).




- ⑦ Remove rod seal (9), back up ring (10) and dust seal (11).



(3) Assembly

Install dust seal (11), back up ring (10) and rod seal (9) to body (1).

- ※ When installing dust seal (11) and rod seal (9), take full care so as not to damage the lip.




- ② Pour grease into body (1), then push in rod (12) by hand.

After take grease out of grease valve mounting hole, let air out.

- ※ If air letting is not sufficient, it may be difficult to adjust the tension of crawler.

- ③ Fit grease valve (13) to rod (12).

- Tightening torque : $13 \pm 1.0 \text{ kgf} \cdot \text{m}$
($94 \pm 7.2 \text{ lbf} \cdot \text{ft}$)




- ④ Install spring (3) and bracket (4) to body (1).


- ⑤ Apply pressure to spring (3) with a press and tighten lock nut (5).

- ※ Apply sealant before assembling.

- ※ During the operation, pay attention specially to prevent the press from slipping out.





- ⑥ Lighten the press load and confirm the set length of spring (3).
- ⑦ After the setting of spring (3), install lock plate (6), spring washer (8) and bolt (7).




16078UC08

GROUP 11 WORK EQUIPMENT


1. STRUCTURE



SECTION A



SECTION B



SECTION C


220A8WE10

2. REMOVAL AND INSTALL


1) BUCKET ASSEMBLY

(1) Removal


- ① Lower the work equipment completely to ground with back of bucket facing down.



- ② Remove nut (1), bolt (2) and draw out the pin (B).
 - Tightening torque (2) : $29.7 \pm 4.5 \text{ kgf} \cdot \text{m}$
($215 \pm 32.5 \text{ lbf} \cdot \text{ft}$)




- ③ Remove nut (3), bolt (4) and draw out the pin (A) then remove the bucket assembly.
 - Weight : 439 kg (968 lb)
 - Tightening torque (4) : $29.7 \pm 4.5 \text{ kgf} \cdot \text{m}$
($215 \pm 32.5 \text{ lbf} \cdot \text{ft}$)



(2) Install

- ① Carry out installation in the reverse order to removal.
- ▲** When aligning the mounting position of the pin, do not insert your fingers in the pin hole.
- ※ Adjust the bucket clearance.
For detail, see operation manual.



2) ARM ASSEMBLY

(1) Removal

※ Loosen the breather slowly to release the pressure inside the hydraulic tank.

▲ Escaping fluid under pressure can penetrate the skin causing serious injury.

① Remove bucket assembly.

For details, see removal of bucket assembly.

② Disconnect bucket cylinder hose (1).

▲ Fit blind plugs (5) in the piping at the chassis end securely to prevent oil from spurting out when the engine is started.

③ Sling arm cylinder assembly, remove spring, pin stopper and pull out pin.

※ Tie the rod with wire to prevent it from coming out.

④ For details, see removal of arm cylinder assembly.




Place a wooden block under the cylinder and bring the cylinder down to it.

⑤ Remove bolt (2), plate (3) and pull out the pin (4) then remove the arm assembly.

· Weight : 450 kg (992 lb)

· Tightening torque (2) : 12.8 ± 3.0 kgf·m
(92.6 ± 21.7 lbf·ft)

※ When lifting the arm assembly, always lift the center of gravity.



(2) Install

① Carry out installation in the reverse order to removal.

▲ When lifting the arm assembly, always lift the center of gravity.

※ Bleed the air from the cylinder.

