

GROUP 4 MAIN CONTROL VALVE

1. REMOVAL AND INSTALL

1) REMOVAL

- (1) Lower the work equipment to the ground and stop the engine.
- (2) Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping.
- (3) Loosen the breather slowly to release the pressure inside the hydraulic tank.




▲ Escaping fluid under pressure can penetrate the skin causing serious injury.

※ When pipes and hoses are disconnected, the oil inside the piping will flow out, so catch it in oil pan.


- (4) Remove the wirings for the pressure sensor and so on.
- (5) Remove bolts and disconnect pipe.
- (6) Disconnect pilot line hoses.
- (7) Disconnect pilot piping.
- (8) Sling the control valve assembly and remove the control valve mounting bolt.
 - MCV 1 weight : 450 kg (990 lb)
 - MCV 2 weight : 160 kg (350 lb)
- (9) Remove the control valve assembly.
When removing the control valve assembly, check that all the piping have been disconnected.

2) INSTALL

- (1) Carry out installation in the reverse order to removal.
- (2) Bleed the air from below items.
 - ① Cylinder (boom, arm, bucket)
 - ② Swing motor
 - ③ Travel motor※ See each item removal and install.
- (3) Confirm the hydraulic oil level and recheck the hydraulic oil leak or not.




2. STRUCTURE (MCV 1, 1/5)



120098MC04

| | | | | | | | |
|----|--------------|----|--------------|----|--------------|-----|--------|
| 1 | Housing | 16 | Plunger | 31 | Spring | 68 | Cap |
| 2 | Plunger assy | 17 | Plunger | 32 | Check | 69 | O-ring |
| 3 | Plunger assy | 18 | Plunger | 33 | Spacer | 70 | Cap |
| 4 | Plunger assy | 19 | Cap | 34 | Cap | 72 | Cap |
| 5 | Plunger assy | 20 | Spring guide | 35 | O-ring | 80 | O-ring |
| 6 | Plunger assy | 21 | Spring | 36 | Socket bolt | 85 | Cap |
| 7 | O-ring | 22 | Spring | 37 | Washer | 92 | Plug |
| 9 | Cover | 23 | Check | 39 | O-ring | 98 | Cap |
| 10 | Cover | 24 | Spring | 42 | Check | 106 | Cap |
| 11 | Socket bolt | 25 | Spacer | 43 | Spring | 107 | Cap |
| 12 | O-ring | 26 | O-ring | 48 | Check | 108 | Spring |
| 13 | Cover | 27 | Back up ring | 49 | Back up ring | 109 | Spool |
| 14 | Plunger | 28 | Cap | 50 | Cap | | |
| 15 | Plunger | 30 | Orifice | 64 | Cap | | |


STRUCTURE (MCV1, 2/5)



120098MC05

| | | | | | | | |
|----|------------------------|-----|--------------|-----|--------------|-----|--------------|
| 7 | O-ring | 101 | O-ring | 122 | Spring | 160 | Mainfold |
| 8 | Foot relief valve assy | 102 | O-ring | 123 | Poppet | 161 | O-ring |
| 26 | O-ring | 103 | Plug | 124 | Back up ring | 162 | Cover |
| 34 | Cap | 104 | Cap | 125 | Piston | 163 | Socket bolt |
| 35 | O-ring | 105 | O-ring | 126 | Check | 164 | Pisotn |
| 55 | O-ring | 106 | Cap | 127 | Spring | 165 | Spring |
| 64 | Cap | 110 | Cover assy | 128 | Cover | 166 | Plate |
| 69 | O-ring | 111 | Lock washer | 129 | Socket bolt | 167 | Back up ring |
| 80 | O-ring | 112 | Cap | 130 | Cap | 168 | O-ring |
| 81 | Make up assy | 113 | Spring | 131 | Spring | 169 | Spring |
| 82 | O-ring | 114 | Piston | 132 | Spool | 170 | Spring guide |
| 83 | Back up ring | 115 | Sleeve | 147 | Socket bolt | 171 | Sleeve |
| 91 | Overload relief valve | 116 | Back up ring | 154 | Cover | 172 | Poppet |
| 93 | Cap | 117 | O-ring | 155 | Spring | 173 | Check |
| 94 | Back up ring | 118 | Poppet | 156 | Spool | 174 | Spring |
| 95 | O-ring | 119 | Spring | 157 | Back up ring | 175 | Cap |
| 96 | Spring | 120 | Cap | 158 | O-ring | 176 | O-ring |
| 97 | Check | 121 | O-ring | 159 | Poppet | 177 | Back up ring |
| 99 | Socket bolt | | | | | | |


STRUCTURE (MCV1, 3/5)



120098MC06

| | | | | | | | |
|----|--------------|----|--------------|-----|--------------|-----|------------------------|
| 7 | O-ring | 59 | Socket bolt | 77 | Back up ring | 141 | O-ring |
| 26 | O-ring | 60 | Socket bolt | 78 | Seat | 142 | Sleeve |
| 29 | Manifold | 61 | O-ring | 86 | Cap | 143 | O-ring |
| 37 | Washer | 62 | O-ring | 87 | Back up ring | 144 | Back up ring |
| 39 | O-ring | 63 | O-ring | 88 | O-ring | 145 | Pisotn |
| 40 | Back up ring | 64 | Cap | 89 | Check | 146 | Cap |
| 41 | O-ring | 65 | O-ring | 90 | Spring | 148 | Boost check valve |
| 42 | Check | 66 | Back up ring | 135 | Sleeve | 149 | Main relief valve assy |
| 43 | Spring | 67 | O-ring | 136 | Spring | 150 | Back up ring |
| 55 | O-ring | 73 | Spring guide | 137 | Spring | 151 | O-ring |
| 56 | Cap | 74 | Spring | 138 | O-ring | 152 | O-ring |
| 57 | O-ring | 75 | Check | 139 | Spool | 153 | Cap |
| 58 | O-ring | 76 | O-ring | 140 | Back up ring | | |


STRUCTURE (MCV1, 4/5)



120098MC07

| | | | | | | | |
|----|--------------|----|--------------|-----|--------------|-----|--------------|
| 4 | Plunger assy | 25 | Spacer | 69 | O-ring | 117 | O-ring |
| 6 | Plunger assy | 26 | O-ring | 79 | Plug | 118 | Poppet |
| 9 | Cover | 27 | Back up ring | 80 | O-ring | 119 | Spring |
| 10 | Cover | 28 | Cap | 99 | Socket bolt | 120 | Cap |
| 11 | Socket bolt | 35 | O-ring | 100 | Flange | 122 | Spring |
| 12 | O-ring | 44 | Housing | 101 | O-ring | 123 | Poppet |
| 13 | Cover | 45 | Plunger assy | 105 | O-ring | 124 | Back up ring |
| 16 | Plunger | 46 | Plunger assy | 106 | Cap | 125 | Piston |
| 18 | Plunger | 47 | Plunger assy | 110 | Cover assy | 126 | Check |
| 19 | Plunger cap | 51 | Plunger | 111 | Lock washer | 127 | Spring |
| 20 | Spring guide | 52 | Plunger | 112 | Cap | 128 | Cover |
| 21 | Spring | 53 | Plunger | 113 | Spring | 129 | Socket bolt |
| 22 | Spring | 54 | Spring | 114 | Piston | 130 | Cap |
| 23 | Check | 64 | Cap | 115 | Sleeve | 133 | Spring |
| 24 | Spring | 68 | Cap | 116 | Back up ring | 134 | Spool |


STRUCTURE (MCV1, 5/5)



120098MC08

- | | | | | | |
|----|------------------------|----|-----------------------|-----|--------------|
| 7 | O-ring | 50 | Cap | 94 | Back up ring |
| 8 | Foot relief valve assy | 55 | O-ring | 95 | O-ring |
| 36 | Socket bolt | 71 | Check | 96 | Spring |
| 37 | Washer | 72 | Cap | 97 | Check |
| 38 | Cap | 80 | O-ring | 102 | O-ring |
| 39 | O-ring | 81 | Make up assy | 103 | Plug |
| 40 | Back up ring | 82 | O-ring | 104 | Cap |
| 41 | O-ring | 83 | Back up ring | 105 | O-ring |
| 42 | Check | 84 | Cap | 106 | Cap |
| 43 | Spring | 85 | Check | 107 | Cap |
| 48 | Check | 91 | Overload relief valve | 108 | Spring |
| 49 | Back up ring | 93 | Cap | 109 | Spool |


STRUCTURE (MCV2, 1/2)



120098MC09

- | | | | | | |
|----|------------------------|----|--------------|----|---------------|
| 1 | Housing | 40 | Sleeve | 54 | Pilot poppet |
| 8 | Main relief valve assy | 41 | Hex nut | 55 | Back up ring |
| 9 | Make up assy | 42 | Piston | 56 | O-ring |
| 10 | Check | 43 | O-ring | 57 | Poppet |
| 11 | Check | 44 | O-ring | 58 | Back up ring |
| 12 | O-ring | 45 | Pilot sheet | 59 | O-ring |
| 13 | Back up ring | 46 | Spring | 60 | Spring |
| 14 | Cap | 47 | Poppet | 61 | Relief sleeve |
| 15 | Spring | 48 | Sleeve | 62 | O-ring |
| 22 | Cap | 49 | Adjust screw | 63 | Back up ring |
| 23 | Cap | 50 | Hex nut | 64 | Cap |
| 24 | O-ring | 51 | O-ring | 65 | O-ring |
| 26 | Cap | 52 | Cap | 66 | Back up ring |
| 27 | Check | 53 | Spring | 67 | O-ring |

STRUCTURE (MCV2, 2/2)



120098MC10

- | | | | | | |
|----|--------------|----|------------------------|----|--------------|
| 2 | Plunger assy | 29 | Spring guide | 70 | Sleeve |
| 3 | Plunger assy | 30 | Spring | 71 | Poppet |
| 4 | Plunger assy | 31 | Plunger | 72 | O-ring |
| 5 | Plunger assy | 32 | Plunger | 73 | Back up ring |
| 6 | Cover | 33 | Plunger | 74 | Piston |
| 7 | Socket bolt | 34 | Plunger | 75 | Cover |
| 16 | Spring | 35 | Foot relief valve assy | 76 | Cap |
| 17 | Poppet | 36 | Manifold | 77 | O-ring |
| 18 | Plug | 37 | Socket bolt | 78 | O-ring |
| 19 | O-ring | 38 | O-ring | 79 | Socket bolt |
| 20 | Cover | 39 | O-ring | 80 | Lock washer |
| 21 | O-ring | 68 | Cap | 81 | Back up ring |
| 25 | Cover | 69 | Spring | 82 | O-ring |
| 28 | Cap | | | | |

3. DISASSEMBLY AND ASSEMBLY

1) GENERAL PRECAUTIONS

- (1) Hydraulic machinery precisely. Please make disassembly and assembly have a small gap at a place without the dust.
- (2) When remove it from an actual machine, wash a plumbing part and a plug, and dust and water do not enter.
- (3) Examine a structure figure before work, and prepare a part depending on a purpose. In addition, prepare by a parts list beforehand because there is a part of the need to change in sub-assembly.

(4) Disassembly

- ① Handle the components carefully not to drop them or bump them with each other as they are made with precision.
- ② Do not force the work by hitting or twisting as burred or damaged component may not be assembled or result in oil leakage or low performance.
- ③ When disassembled, tag the components for identification so that they can be reassembled correctly.
- ④ Once disassembled, O-ring and back-up rings are usually not to be used again. (Remove them using a wire with its end made like a shoehorn. Be careful not to damage the slot)
- ⑤ If the components are left disassembled or half-disassembled, they may get rust from moisture or dust. If the work has to be interrupted, take care to prevent rust and dust.

(5) Assembly

- ① Take the same precautions as for disassembly.
- ② When assembling the components, remove any metal chips or foreign objects and check them for any burrs or dents. Remove nurrns and dents with oil-stone, if any.
- ③ O-rings and back-up rings are to be replaced with new ones, as a rule.
- ④ When installing O-ring and back-up rings, be careful not to damage them. (Apply a little amount of grease for smoothness)
- ⑤ Tighten the bolts and caps with specified torque.


2) TOOLS

(1) Before disassembling the control valve, prepare the following tools beforehand.

① Holder

| Item | ∅ D | L | B | H |
|----------------------------|-----|----|----|----|
| Main plunger | 36 | 90 | 50 | 25 |
| Priority valve poppet assy | 25 | 30 | 35 | 20 |


※ Material : Brass



120098MC11

② Arm regeneration valves sleeve pull out device


※ Material : Steel




120098MC12

3) MOUNTING AND DISMOUNTING VALVES


· Straight travel side valve (MCV 1)




Option side valve (MCV 1)



· Manifold assembly (MCV 1)



· Swing side valve (MCV 2)




(1) Main plunger

- ※ Reassembly in the reverse order to disassembly.
- ※ Attach an identification tag immediately after disassembly.


① Remove hexagon socket bolts (1) then remove cover (2).

- ※ Hexagon socket bolt
Width across flat : 10 mm
Tightening torque : 10 kgf · m (72.3 lbf · ft)
- ※ When reassembly
Install cover (2) after making sure that O-ring is placed on the edge of the valve hole.



② Pull out plunger sub-assembly.


- ※ Do not pull out the plunger all at once.
Pull slowly while confirming the fitness with the housing hole.
- ※ When reassembly
AM, BM, and BKT match the key groove of the cover.



③ Place the plunger between holders and loosen the plunger cap (3) by using vise.

- Plunger cap
Width across flat : 10 mm
Tightening torque : 10 kgf · m
(72.3 lbf · ft)

- ※ Put the plunger between the holders and clamp them by a vise after degreasing the plunger and holders as a special tool.




④ Remove the plunger cap (3), spring guide (4), spring (5).

※ Spring is different according to the plunger.

※ AM-2 plunger only.

The spacer (A) is built in.




⑤ BM-1, AM-1 plunger only.

Remove cap (6), spacer (7), spring (8), and check (9).

· Cap

Width across flat : 10 mm

Tightening torque : 8.2 kgf · m
(59.3 lbf · ft)



(2) Foot relief valve

※ Reassembly in the reverse order to disassembly.


※ Attach an identification tag immediately after disassembly.

① Remove cap (1) and pull out spring (2) and poppet (3).

· Cap

Width across flat : 36 mm

Tightening torque : 25.5 kgf · m
(184 lbf · ft)



(3) Check valve (Arm dump summation)


- ※ Reassembly in the reverse order to disassembly.
- ※ Attach an identification tag immediately after disassembly.

- ① Remove cap (1) and pull out spring (2) and check (3).

· Cap

Width across flat : 41 mm

Tightening torque : 18.4 kgf · m
(133 lbf · ft)



(4) Center bypass valve (Opt summation)


- ※ Reassembly in the reverse order to disassembly.
- ※ Attach an identification tag immediately after disassembly.

- ① Remove cap (1) and pull out spool (3) and spring (2).

· Cap


Width across flat : 46 mm

Tightening torque : 25.5 kgf · m
(184 lbf · ft)




(5) Check valve

- ※ Reassembly in the reverse order to disassembly.
- ※ Attach an identification tag immediately after disassembly.




AM-2L, TL, BKT-3




BKT-1, AM-1, AM-3

CAP : The squeezing diameter is different



BM-1, BM-2, BM-3
SW, OPT, OTHER




(TR) CHECK : Outer orifice

120098MC25

- It explains with BKT-1.
- ① Remove cap (1) and pull out check (4), spring (2) and check (3).

- Cap
 - Width across flat : 14 mm
 - Tightening torque : 35.7 kgf · m
(258 lbf · ft)



120098MC26


(6) Cover assy

- ※ Reassembly in the reverse order to disassembly.
- ※ Attach an identification tag immediately after disassembly.

① Remove hexagon socket bolts (1) then remove cover assy (2).


- ※ Hexagon socket bolt
Width across flat : 10 mm
Tightening torque : 10 kgf · m (72.3 lbf · ft)
- ※ When reassembly
Install cover (2) after making sure that O-ring is placed on the edge of the valve hole.

The direction of the installation of the cover is noted.



② Remove plug (3).

- Plug
Width across flat : 8 mm
Tightening torque : 8.2 kgf · m
(59.3 lbf · ft)



(7) Make up valve

- ※ Reassembly in the reverse order to disassembly.
- ※ Attach an identification tag immediately after disassembly.


① Loosen sleeve (1) and remove make-up valve.

- Sleeve

Width across flat : 41 mm

Tightening torque : 10 kgf · m

(72.3 lbf · ft)




② Remove cap (2) and pull out spring (3) and poppet (4).

- Cap

Width across flat : 36 mm

Tightening torque : 10 kgf · m

(72.3 lbf · ft)



(8) Overload relief valve

- ※ Reassembly in the reverse order to disassembly.
- ※ Attach an identification tag immediately after disassembly.


① Loosen sleeve (1) and remove relief valve.

- Sleeve

Width across flat : 41 mm

Tightening torque : 10 kgf · m

(72.3 lbf · ft)



② Loosen and remove relief seat (2) sub-assembly and remove spring (3), (4), piston (5) and main poppet (6).


- Relief sleeve

Width across flat : 36 mm

Tightening torque : 10 kgf · m

(72.3 lbf · ft)

- ※ Do not disassemble adjusting screw. It's impossible to readjust setting pressure exactly on the machine.





(9) Arm semi para valve

- ※ Reassembly in the reverse order to disassembly.
- ※ Attach an identification tag immediately after disassembly.

① Loosen hexagon socket bolts (1) and remove cover assembly.


- Hexagon socket bolt
Width across flat : 8 mm
Tightening torque : 6.12 kgf · m
(44.3 lbf · ft)

- ※ When reassembly
Install cover assy after making sure that O-ring is placed on the edge of the cover hole.



② Remove cap (2) and pull out spool (4) and spring (3).

- Cap
Width across flat : 41 mm
Tightening torque : 10 kgf · m
(72.3 lbf · ft)





(10) Holding valve (Arm 1, Boom 1)

- ※ Reassembly in the reverse order to disassembly.
- ※ Attach an identification tag immediately after disassembly.


① Loosen hexagon socket bolts (1) and remove cover assembly.

- Hexagon socket bolt
Width across flat : 12 mm
Tightening torque : 18.4 kgf · m
(133 lbf · ft)

- ※ When reassembly
Install cover assy after making sure that O-ring is placed on the edge of the cover hole.



② Remove spring (2) and poppet (3).





③ Cover assembly

- a. Remove cap (4) and pull out spring (5), and piston (6).

· Cap
Width across flat : 19 mm
Tightening torque : 3.1 kgf · m
(22.4 lbf · ft)

- b. Remove cap (7) and pull out spring (8), and check (9).

· Cap
Width across flat : 6 mm
Tightening torque : 3.1 kgf · m
(22.4 lbf · ft)





- c. Remove cap (10) and piston (11).

· Cap
Width across flat : 10 mm
Tightening torque : 6.1 kgf · m
(44.1 lbf · ft)


- d. Remove cap (12) and pull out spring (13), and poppet (14).

· Cap
Width across flat : 8 mm
Tightening torque : 5.1 kgf · m
(36.9 lbf · ft)



※ There is a case where the poppet cannot be taken by the seat edge.

e. It begins to beat the sleeve with the pipe lightly.



(11) Check valve (Arm semi para, Boom priority)

- ※ Reassembly in the reverse order to disassembly.
- ※ Attach an identification tag immediately after disassembly.



① Remove cap (1) and pull out spring (2), and check (3).

· Cap

Width across flat : 12 mm

Tightening torque : 15.3 kgf · m

(111 lbf · ft)



(12) Center bypass valve



- ※ Reassembly in the reverse order to disassembly.
- ※ Attach an identification tag immediately after disassembly.

- ① Remove cap (1) and pull out spool (3), and spring (2).

· Cap

Width across flat : 46 mm

Tightening torque : 25.5 kgf · m
(184.4 lbf · ft)



(13) Boom priority valve 1

- ※ Reassembly in the reverse order to disassembly.
- ※ Attach an identification tag immediately after disassembly.

- ① Loosen hexagon socket bolts (1) and remove cover assembly.


· Hexagon socket bolt

Width across flat : 8 mm

Tightening torque : 6.1 kgf · m
(44.1 lbf · ft)

- ※ When reassembly

Install cover assy after making sure that O-ring is placed on the edge of the cover hole.




- ② Remove cap (2) and pull out spool (4), and spring (3).


· Cap

Width across flat : 41 mm

Tightening torque : 10 kgf · m
(72.3 lbf · ft)



120098MC49



120098MC50

(14) Boom priority valve 2

- ※ Reassembly in the reverse order to disassembly.
- ※ Attach an identification tag immediately after disassembly.

- ① Loosen hexagon socket bolts (1) and remove cover assembly (2).


· Hexagon socket bolt

Width across flat : 12 mm

Tightening torque : 18.4 kgf · m
(133 lbf · ft)


※ When reassembly

Install cover assy (2) after making sure that O-ring and back-up ring is placed on the edge of the valve hole.



120098MC51

- ② Remove spring (3), spring guide (4), sleeve (5) and poppet sub-assembly (6).



- ③ Place the poppet between holders and loosen the cap (7) by using vise.


Remove cap (7), spring (8) and check (9).

· Cap

Width across flat : 6 mm

Tightening torque : 3.6 kgf · m
(26 lbf · ft)

- ※ Put the poppet between the holders and clamp them by a vise after degreasing the poppet and holders as a special tool.



- ④ Cap (10) removed and a plate (11) is extracted by the press.



Remove spring (12) and piston (13).

· Cap

Width across flat : 5 mm

Tightening torque : 21 kgf · m
(14.5 lbf · ft)

- ※ It takes care that to not fly, when a plate (11) with spring anti-power separates.



(15) Check valve (Travel straight)

- ※ Reassembly in the reverse order to disassembly.
- ※ Attach an identification tag immediately after disassembly.



- ① Remove cap (1) and pull out spacer (2), spring (3) and check (4).

· Cap

Width across flat : 5 mm

Tightening torque : 21 kgf · m

(14.5 lbf · ft)




(16) Load holding valve (Boom 2)

- ※ Reassembly in the reverse order to disassembly.
- ※ Attach an identification tag immediately after disassembly.


① Loosen hexagon socket bolts (1) and remove cover assembly.

- Hexagon socket bolt
Width across flat : 12 mm
Tightening torque : 18.6 kgf · m
(134.5 lbf · ft)

- ※ When reassembly
Install cover assy after making sure that O-ring is placed on the edge of the cover hole.



② Remove spring (3) and poppet (4).




③ Cover assembly

Remove cap (5) and pull out spring (6), and spool (7).


· Cap

Width across flat : 6 mm

Tightening torque : 3.1 kgf · m
(22.4 lbf · ft)



120098MC60



120098MC61

(17) Check valve (Opt summation, main relief valve passage)

※ Reassembly in the reverse order to disassembly.


※ Attach an identification tag immediately after disassembly.

① Remove cap (1) and pull out spool (2) and check (3).


· Cap

Width across flat : 41 mm

Tightening torque : 18.4 kgf · m
(133 lbf · ft)



120098MC62



120098MC63

(18) Arm regeneration valve



- ※ Reassembly in the reverse order to disassembly.
- ※ Attach an identification tag immediately after disassembly.

- ① Remove cap (1) and pull out spring (2) and spool (3).


· Cap

Width across flat : 41 mm

Tightening torque : 18.4 kgf · m
(133 lbf · ft)



- ② Sleeve (4) is pull out with a special tool.
Remove piston (5), spring (6) and check (7).




- ③ Remove cap (8) and pull out spring guide (9).

· Cap

Width across flat : 12 mm

Tightening torque : 10 kgf · m
(72.3 lbf · ft)



(19) Boom boost check valve


- ※ Reassembly in the reverse order to disassembly.
- ※ Attach an identification tag immediately after disassembly.

① Remove cap (1) and pull out spring (2) and poppet (3).


· Cap

Width across flat : 46 mm

Tightening torque : 18.4 kgf · m
(133 lbf · ft)



120098MC68




120098MC69

(20) Main relief valve

· **Disassembly**



- ① Loosen nut (2) while holding adjusting screw (1).
- ② Loosen nut (3) while holding cap (4).
- ③ Remove main relief valve from valve body.





- ④ Pull out main poppet sub assy (A) and remove main poppet (7) and spring (8) from sleeve (6).

Width across flat

- 1 Adjust screw : 22 mm
- 2 Hexagon nut : 30 mm
- 3 Hexagon nut : 41 mm
- 4 Cap : 41 mm
- 5 Sleeve : 27 mm




- ⑤ Remove adjusting sub-assy (B) then remove spring (9) and pilot poppet (10).
- ※ Do not disassembly pilot seat (C). (Press fitting)




• **Reassembly**


- ① Screw low pressure adjusting screw (1) until piston (D) touches "Z" face, in this position, relief setting pressure is high level.



- ② Install pilot poppet (10), spring (9) and adjusting screw sub-assy (B). Set adjusting screw sub-assy (B) temporarily in the position that pilot poppet (10) contacts to pilot seat (C). Then pressure adjusting spring (9) begins to be effective.



- ③ Assemble main poppet sub-assy (A), and install the main relief valve which is set temporarily in main body. Tighten cap (4) with a torque wrench.



· **Resetting relief pressure**

① **High pressure**


Set the prescribed pressure correctly adjusting sleeve (5), while reading the pressure gauge. Tighten lock nut (3) with torque wrench holding sleeve (5).

- ※ One quarter turn of sleeve (5) equals about 4.5 MPa.

② **Low pressure**

Set the prescribed pressure correctly adjusting screw (1), while reading the pressure gauge. Tighten lock nut (2) with torque wrench holding adjusting screw (1).

- ※ One quarter turn of adjusting screw (1) equals about 4.5 MPa.



Tightening torque

- 1 Adjust screw : -
- 2 Hexagon nut : 6.1 kgf · m (44.1 lbf · ft)
- 3 Hexagon nut : 10 kgf · m (72.3 lbf · ft)
- 4 Cap : 10 kgf · m (72.3 lbf · ft)
- 5 Sleeve : -



(21) Check valve (Boom up summation)

- ※ Reassembly in the reverse order to disassembly.
- ※ Attach an identification tag immediately after disassembly.


※ There is a necessity for separating housing and manifold. (refer to page 8-66)

① It begins to beat the check with the pipe lightly.

Remove seat (1), check (2), spring (3) and spring guide (4).



(22) Separation/union of valve



120098MC81

① Separation

1-1. Loosen hexagon socket bolts (1), (2), (3) and remove OPT side valve.

1-2. Loosen hexagon socket bolts (4), (5) and remove TS side valve.

· Hexagon socket bolt

Width across flat : 14 mm

※ Remove check assemble of the manifold earlier. (refer to page 8-67)

② Union

2-1. Installation respect is made smooth.

2-2. United at TS side valve earlier.

2-3. United at OPT side valve.

· Hexagon socket bolt

Tightening torque : 25.5 kgf · m (184.4 lbf · ft)

※ Install valve assy after making sure that O-ring is placed on the edge of the manifold hole.

(23) Check valve (Boom summation)



- ※ Reassembly in the reverse order to disassembly.
- ※ Attach an identification tag immediately after disassembly.

① Remove cap (1) and pull out check (2) and spring (3).

· Cap

Width across flat : 32 mm

Tightening torque : 10 kgf · m
(72.3 lbf · ft)



(24) Load holding valve (Arm 3, Boom 3)

- ※ Reassembly in the reverse order to disassembly.
- ※ Attach an identification tag immediately after disassembly.

① Loosen hexagon socket bolts (1) and remove cover assembly (2).


· Hexagon socket bolt

Width across flat : 12 mm


Tightening torque : 18.4 kgf · m
(133 lbf · ft)

※ When reassembly

Install cover assy after making sure that O-ring is placed on the edge of the cover hole.



② Remove spring (3) and poppet (4).



③ Cover assembly


- a. Remove cap (5) and pull out spring (6), and poppet (7).

· Cap

Width across flat : 10 mm

Tightening torque : 5.1 kgf · m
(36.9 lbf · ft)

※ There is a case where the poppet cannot be taken by the seat edge.




- b. Remove cap (8) and piston (9).

· Cap

Width across flat : 10 mm

Tightening torque : 5.1 kgf · m
(36.9 lbf · ft)



- c. It begins to beat the sleeve with the pipe lightly.

