

## SECTION 8 DISASSEMBLY AND ASSEMBLY

Group 1 Precaution .....	8-1
Group 2 Tightening Torque .....	8-4
Group 3 Pump Device .....	8-7
Group 4 Main Control Valve .....	8-32
Group 5 Swing Device .....	8-46
Group 6 Travel Device .....	8-79
Group 7 RCV Lever .....	8-111
Group 8 Turning Joint .....	8-125
Group 9 Boom, Arm and Bucket Cylinder .....	8-130
Group 10 Undercarriage .....	8-148
Group 11 Work Equipment .....	8-160


# SECTION 8 DISASSEMBLY AND ASSEMBLY

## GROUP 1 PRECAUTIONS

### 1. REMOVAL WORK

- 1) Lower the work equipment completely to the ground.  
If the coolant contains antifreeze, dispose of it correctly.
- 2) After disconnecting hoses or tubes, cover them or fit blind plugs to prevent dirt or dust from entering.
- 3) When draining oil, prepare a container of adequate size to catch the oil.
- 4) Confirm the match marks showing the installation position, and make match marks in the necessary places before removal to prevent any mistake when assembling.
- 5) To prevent any excessive force from being applied to the wiring, always hold the connectors when disconnecting the connectors.
- 6) Fit wires and hoses with tags to show their installation position to prevent any mistake when installing.
- 7) Check the number and thickness of the shims, and keep in a safe place.
- 8) When raising components, be sure to use lifting equipment of ample strength.
- 9) When using forcing screws to remove any components, tighten the forcing screws alternately.
- 10) Before removing any unit, clean the surrounding area and fit a cover to prevent any dust or dirt from entering after removal.
- 11) When removing hydraulic equipment, first release the remaining pressure inside the hydraulic tank and the hydraulic piping.
- 12) If the part is not under hydraulic pressure, the following corks can be used.

Nominal number	Dimensions		
	D	d	L
06	6	5	8
08	8	6.5	11
10	10	8.5	12
12	12	10	15
14	14	11.5	18
16	16	13.5	20
18	18	15	22
20	20	17	25
22	22	18.5	28
24	24	20	30
27	27	22.5	34



## 2. INSTALL WORK

- 1) Tighten all bolts and nuts (sleeve nuts) to the specified torque.
- 2) Install the hoses without twisting or interference.
- 3) Replace all gaskets, O-rings, cotter pins, and lock plates with new parts.
- 4) Bend the cotter pin or lock plate securely.
- 5) When coating with adhesive, clean the part and remove all oil and grease, then coat the threaded portion with 2-3 drops of adhesive.
- 6) When coating with gasket sealant, clean the surface and remove all oil and grease, check that there is no dirt or damage, then coat uniformly with gasket sealant.
- 7) Clean all parts, and correct any damage, dents, burrs, or rust.
- 8) Coat rotating parts and sliding parts with engine oil.
- 9) When press fitting parts, coat the surface with antifriction compound (LM-P).
- 10) After installing snap rings, check that the snap ring is fitted securely in the ring groove (Check that the snap ring moves in the direction of rotation).
- 11) When connecting wiring connectors, clean the connector to remove all oil, dirt, or water, then connect securely.
- 12) When using eyebolts, check that there is no deformation or deterioration, and screw them in fully.
- 13) When tightening split flanges, tighten uniformly in turn to prevent excessive tightening on one side.
- 14) When operating the hydraulic cylinders for the first time after repairing and reassembling the hydraulic cylinders, pumps, or other hydraulic equipment or piping, always bleed the air from the hydraulic cylinders as follows:
  - (1) Start the engine and run at low idling.
  - (2) Operate the control lever and actuate the hydraulic cylinder 4-5 times, stopping 100mm before the end of the stroke.
  - (3) Next, operate the piston rod to the end of its stroke to relieve the circuit. (The air bleed valve is actuated to bleed the air.)
  - (4) After completing this operation, raise the engine speed to the normal operating condition.
    - ※ If the hydraulic cylinder has been replaced, carry out this procedure before assembling the rod to the work equipment.
    - ※ Carry out the same operation on machines that have been in storage for a long time after completion of repairs.

### **3. COMPLETING WORK**

- 1) If the coolant has been drained, tighten the drain valve, and add water to the specified level. Run the engine to circulate the water through the system. Then check the water level again.
- 2) If the hydraulic equipment has been removed and installed again, add engine oil to the specified level. Run the engine to circulate the oil through the system. Then check the oil level again.
- 3) If the piping or hydraulic equipment, such as hydraulic cylinders, pumps, or motors, have been removed for repair, always bleed the air from the system after reassembling the parts.
- 4) Add the specified amount of grease (molybdenum disulphied grease) to the work equipment related parts.

## GROUP 2 TIGHTENING TORQUE

### 1. MAJOR COMPONENTS

No.	Descriptions	Bolt size	Torque		
			kgf · m	lbf · ft	
1	Engine	Engine mounting bolt (engine-bracket)	M12 × 1.75	12.3 ± 1.2	89 ± 8.7
2		Engine mounting bolt (rubber, fan side)	M20 × 2.5	55 ± 3.5	398 ± 25.3
3		Engine mounting bolt (rubber, flywheel side)	M20 × 2.5	52.1 ± 5.0	377 ± 36.2
4		Radiator mounting bolt	M16 × 2.0	29.7 ± 4.5	215 ± 32.5
5		Coupling mounting socket bolt	M18 × 2.5	32 ± 1.0	231 ± 7.2
6		Main pump housing mounting bolt	M10 × 1.5	6.5 ± 0.7	47 ± 5.1
7	Hydraulic system	Main pump mounting socket bolt	M16 × 2.0	22 ± 1.5	159 ± 10.8
8		Main control valve mounting bolt	M12 × 1.75	12.2 ± 1.3	88.2 ± 9.4
9		Fuel tank mounting bolt	M20 × 2.5	45 ± 1.0	325 ± 7.2
10		Hydraulic oil tank mounting bolt	M20 × 2.5	45 ± 1.0	325 ± 7.2
11		Turning joint mounting bolt, nut	M12 × 1.75	12.3 ± 1.3	88.9 ± 9.4
12	Power train system	Swing motor mounting bolt	M16 × 2.0	29.6 ± 3.2	214 ± 23.1
13		Swing bearing upper part mounting bolt	M18 × 2.5	41.3 ± 4.0	299 ± 28.9
14		Swing bearing lower part mounting bolt	M16 × 1.5	29.7 ± 3.0	215 ± 21.7
15		Travel motor mounting bolt	M16 × 2.0	23 ± 2.5	166 ± 18.1
16		Sprocket mounting bolt	M16 × 2.0	29.7 ± 3.0	215 ± 21.7
17	Under carriage	Carrier roller mounting bolt, nut	M16 × 2.0	29.7 ± 3.0	215 ± 21.7
18		Track roller mounting bolt	M16 × 2.0	29.7 ± 3.0	215 ± 21.7
19		Track tension cylinder mounting bolt	M16 × 2.0	29.7 ± 3.0	215 ± 21.7
20		Track shoe mounting bolt, nut	M16 × 1.5	25.5 ± 2.5	184 ± 18.1
21		Track guard mounting bolt	M16 × 2.0	29.6 ± 3.2	214 ± 23.1
22	Others	Counterweight mounting bolt	M36 × 3.0	308 ± 46	2228 ± 333
23		Cab mounting bolt	M12 × 1.75	12.8 ± 3.0	92.6 ± 21.7
24		Operator's seat mounting bolt	M 8 × 1.25	4.05 ± 0.8	29.3 ± 5.8

※ For tightening torque of engine and hydraulic components, see engine maintenance guide and service manual.

## 2. TORQUE CHART

Use following table for unspecified torque.

### 1) BOLT AND NUT

#### (1) Coarse thread

Bolt size	8T		10T	
	kgf · m	lbf · ft	kgf · m	lbf · ft
M 6 × 1.0	0.85 ~ 1.25	6.15 ~ 9.04	1.14 ~ 1.74	8.2 ~ 12.6
M 8 × 1.25	2.0 ~ 3.0	14.5 ~ 21.7	2.73 ~ 4.12	19.7 ~ 29.8
M10 × 1.5	4.0 ~ 6.0	28.9 ~ 43.4	5.5 ~ 8.3	39.8 ~ 60
M12 × 1.75	7.4 ~ 11.2	53.5 ~ 79.5	9.8 ~ 15.8	71 ~ 114
M14 × 2.0	12.2 ~ 16.6	88.2 ~ 120	16.7 ~ 22.5	121 ~ 167
M16 × 2.0	18.6 ~ 25.2	135 ~ 182	25.2 ~ 34.2	182 ~ 247
M18 × 2.5	25.8 ~ 35.0	187 ~ 253	35.1 ~ 47.5	254 ~ 343
M20 × 2.5	36.2 ~ 49.0	262 ~ 354	49.2 ~ 66.6	356 ~ 482
M22 × 2.5	48.3 ~ 63.3	350 ~ 457	65.8 ~ 98.0	476 ~ 709
M24 × 3.0	62.5 ~ 84.5	452 ~ 611	85.0 ~ 115	615 ~ 832
M30 × 3.5	124 ~ 168	898 ~ 1214	169 ~ 229	1223 ~ 1655
M36 × 4.0	174 ~ 236	1261 ~ 1703	250 ~ 310	1808 ~ 2242

#### (2) Fine thread

Bolt size	8T		10T	
	kgf · m	lbf · ft	kgf · m	lbf · ft
M 8 × 1.0	2.17 ~ 3.37	15.7 ~ 24.3	3.04 ~ 4.44	22.0 ~ 32.0
M10 × 1.25	4.46 ~ 6.66	32.3 ~ 48.2	5.93 ~ 8.93	42.9 ~ 64.6
M12 × 1.25	7.78 ~ 11.58	76.3 ~ 83.7	10.6 ~ 16.0	76.6 ~ 115
M14 × 1.5	13.3 ~ 18.1	96.2 ~ 130	17.9 ~ 24.1	130 ~ 174
M16 × 1.5	19.9 ~ 26.9	144 ~ 194	26.6 ~ 36.0	193 ~ 260
M18 × 1.5	28.6 ~ 43.6	207 ~ 315	38.4 ~ 52.0	278 ~ 376
M20 × 1.5	40.0 ~ 54.0	289 ~ 390	53.4 ~ 72.2	386 ~ 522
M22 × 1.5	52.7 ~ 71.3	381 ~ 515	70.7 ~ 95.7	512 ~ 692
M24 × 2.0	67.9 ~ 91.9	491 ~ 664	90.9 ~ 123	658 ~ 890
M30 × 2.0	137 ~ 185	990 ~ 1338	182 ~ 248	1314 ~ 1795
M36 × 3.0	192 ~ 260	1389 ~ 1879	262 ~ 354	1893 ~ 2561

**2) PIPE AND HOSE (FLARE TYPE)**

Thread size (PF)	Width across flat (mm)	kgf · m	lbf · ft
1/4"	19	4	28.9
3/8"	22	5	36.2
1/2"	27	9.5	68.7
3/4"	36	18	130.2
1"	41	21	151.9
1-1/4"	50	35	253.2

**3) PIPE AND HOSE (ORFS TYPE)**

Thread size (UNF)	Width across flat (mm)	kgf · m	lbf · ft
9/16-18	19	4	28.9
11/16-16	22	5	36.2
13/16-16	27	9.5	68.7
1-3/16-12	36	18	130.2
1-7/16-12	41	21	151.9
1-11/16-12	50	35	253.2

**4) FITTING**

Thread size	Width across flat (mm)	kgf · m	lbf · ft
1/4"	19	4	28.9
3/8"	22	5	36.2
1/2"	27	9.5	68.7
3/4"	36	18	130.2
1"	41	21	151.9
1-1/4"	50	35	253.2

## GROUP 3 PUMP DEVICE



### 1. REMOVAL AND INSTALL

#### 1) REMOVAL

- (1) Lower the work equipment to the ground and stop the engine.
- (2) Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping
- (3) Loosen the breather slowly to release the pressure inside the hydraulic tank.

**▲ Escaping fluid under pressure can penetrate the skin causing serious injury.**

- (4) Loosen the drain plug under the hydraulic tank and drain the oil from the hydraulic tank.
  - Hydraulic tank quantity : 79 l (20.9 U.S. gal)
- (5) Remove socket bolts (11) and disconnect hoses (1,2).
- (6) Disconnect pilot line hoses (5, 6, 7, 8, 9, 10).
- (7) Remove socket bolts (12) and disconnect pump suction pipe (4).
  - ※ When pump suction tube is disconnected, the oil inside the piping will flow out, so catch it in oil pan.
- (8) Sling the pump assembly and remove the pump mounting bolts.
  - Weight : 90 kg (200 lb)
  - ※ Pull out the pump assembly from housing. When removing the pump assembly, check that all the hoses have been disconnected.






## 2) INSTALL

- (1) Carry out installation in the reverse order to removal.
- (2) Remove the suction strainer and clean it.
- (3) Replace return filter with new one.
- (4) Remove breather and clean it.
- (5) After adding oil to the hydraulic tank to the specified level.
- (6) Bleed the air from the hydraulic pump.
  - ① Remove the air vent plug (2EA).
  - ② Tighten plug lightly.
  - ③ Start the engine, run at low idling, and check oil come out from plug.
  - ④ Tighten plug.
- (7) Start the engine, run at low idling (3~5 minutes) to circulate the oil through the system.
- (8) Confirm the hydraulic oil level and check the hydraulic oil leak or not.

## 2. MAIN PUMP (1/3)


### 1) STRUCTURE



140Z92MP02

111	Drive shaft (F)	272	Pump casing (R)	711	O-ring
113	Drive shaft (R)	312	Valve block	717	O-ring
116	1st Gear	313	Valve plate (R)	723	O-ring
123	Roller bearing	314	Valve plate (L)	724	O-ring
124	Needle bearing	401	Hexagon socket bolt	728	O-ring
127	Bearing spacer	402	Hexagon socket bolt	732	O-ring
141	Cylinder block	406	Hexagon socket bolt	733	O-ring
151	Piston	415	Hexagon socket bolt	734	O-ring
152	Shoe	466	Plug	774	Oil seal
153	Set plate	467	plug	789	Back up ring
156	Bushing	468	Plug	792	Back up ring
157	Cylinder spring	490	Plug	806	Nut
211	Shoe plate	531	Tilting pin	808	Hexagon head nut
212	Swash plate	532	Servo piston	824	Snap ring
214	Bushing	533	Plug	886	Spring pin
251	Support	534	Stopper (L)	901	Eye bolt
255	Lock pin	535	Stopper (S)	953	Set screw
261	Seal cover (F)	548	Pin	954	Set screw
263	Seal cover (R)	702	O-ring	981	Plate
271	Pump casing (F)	710	O-ring	983	Pin

## MAIN PUMP (2/3)





140Z92MP03

04	Gear pump	128	Bearing spacer	711	O-ring
115	Shaft	262	Cover	728	O-ring
117	Gear No. 2	326	Gear case	825	Retainer ring
118	Gear No. 3	414	Hexagon socket bolt	826	Retainer ring
125	Ball bearing	435	Flange socket bolt	885	Spring pin
126	Roller bearing	468	Plug	886	Pin

## 2) TOOLS AND TIGHTENING TORQUE

### (1) Tools

The tools necessary to disassemble/reassemble the pump are shown in the follow list.


Tool name & size		Part name			
Name	B	Hexagon socket head bolt	PT plug (PT thread)	ROH/VP/UNF plug (PF screw)	Hexagon socket head setscrew
Allen wrench 	4	M 5	BP-1/16	-	M 8
	5	M 6	BP-1/8	-	M10
	6	M 8	BP-1/4	PF-1/4	M12, M14
	8	M10	BP-3/8	PF-3/8	M16, M18
	10	M12	BP-1/2	PF-1/2	M20
	14	M16, M18	BP-3/4	PF-3/4	-
	17	M20, M22	BP-1	PF-1	-
Double ring spanner, socket wrench, double (single) open end spanner 	-	Hexagon bolt	Hexagon nut	VP plug (PF screw)	
	19	M12	M12	PF-1/4	
	24	M16	M16	-	
	27	M18	M18	PF-1/2	
	30	M20	M20	-	
	41	-	-	-	PF-1
Adjustable angle wrench		Medium size, 1 set			
Screw driver		Minus type screw driver, Medium size, 2 sets			
Hammer		Plastic hammer, 1 set			
Pliers		For snap ring, TSR-160			
Steel bar		Steel bar of key material approx. 10 × 8 × 200			
Torque wrench		Capable of tightening with the specified torques			

**(2) Tightening torque**

Part name	Bolt size	Torque		Wrench size	
		kgf · m	lbf · ft	in	mm
Hexagon socket head bolt (material : SCM435)	M 5	0.7	5.1	0.16	4
	M 6	1.2	8.7	0.20	5
	M 8	3.0	21.7	0.24	6
	M10	5.8	42.0	0.31	8
	M12	10.0	72.3	0.39	10
	M14	16.0	116	0.47	12
	M16	24.0	174	0.55	14
	M18	34.0	246	0.55	14
PT Plug (material : S45C) ※ Wind a seal tape 1.5 to 2 turns round the plug	PT1/16	0.7	5.1	0.16	4
	PT 1/8	1.05	7.59	0.20	5
	PT 1/4	1.75	12.7	0.24	6
	PT 3/8	3.5	25.3	0.31	8
	PT 1/2	5.0	36.2	0.39	10
PF Plug (material : S45C)	PF 1/4	3.0	21.7	0.24	6
	PF 3/8	7.55	54.6	0.31	8
	PF 1/2	10.0	72.3	0.39	10
	PF 3/4	15.0	109	0.55	14
	PF 1	19.0	137	0.67	17
	PF 1 1/4	27.0	195	0.67	17
	PF 1 1/2	28.0	203	0.67	17

### 3) DISASSEMBLY

- (1) Select place suitable to disassembling.
  - ※ Select clean place.
  - ※ Spread rubber sheet, cloth or so on overhaul workbench top to prevent parts from being damaged.
- (2) Remove dust, rust, etc, from pump surfaces with cleaning oil or so on.
- (3) Remove drain port plug (468) and drain oil pump casing (271, 272).
- (4) Remove hexagon socket head bolts (412, 413) and remove regulator.



140Z98MP11

- (5) Place pump horizontally on workbench with its regulator fitting surface down, and remove flange socket (435) and remove PTO unit (05).
  - ※ Be careful about the attaching direction of the PTO unit (05).
  - ※ Before bringing regulator fitting surface down, spread rubber sheet on workbench without fail to prevent this surface from being damaged.



140Z98MP12

- (6) In case the pump is provided without the PTO unit (05), remove the cover (262) with the hexagon socket head cap screws (414).



140Z98MP13

- (7) Remove flange socket (435) and remove gear pump (04).



140Z98MP14


- (8) Loosen hexagon socket head bolt (401) which tighten pump casing (271, 272) and valve block (312).



140Z98MP15

- (9) Place pump horizontally on workbench with its regulator fitting surface down, and separate pump casing (271,272) from valve block (312).


- ※ Remove 1st gear (116) when separating pump casing from valve block (312) too.



140Z98MP16

- (10) Pull out cylinder (141), pistons (151), set screw (153), spherical bush (156) and cylinder springs (157) simultaneously from pump casing (271, 272) straightly over drive shaft (111, 113).

- ※ Take care not to damage sliding surface of cylinder (141), spherical bush (156), shoes (152), swash plate (212), etc.



140Z98MP17



(11) Remove hexagon socket head bolts (406) and then seal cover (F, 261).

※ In the case removing it is difficult, and hooking pull thin rod into notch, and the cover can be removed easily.

※ Since oil seal is fitted on seal cover (F) (261), take care not to damage it at removing the cover.



140Z98MP18

(12) Tapping shaft ends of drive shaft (111, 113) lightly with plastic hammer, remove it from pump casing (271, 272).



140Z98MP19

(13) Remove shoe plate (211) and swash plate (212) from pump casing (271, 272).



140Z98MP20

(14) Insert thin steel bar into the hole and remove the lock pin (255) from pump casing (271, 272).

※ When holding with thin steel bar, do not confuse the unlocking hole with the arc shaped oil passage.




140Z98MP21



(15) Remove valve plate (313, 314) from valve block (312).

※ These may be removed in Work 8.



140Z98MP22

If necessary, remove stopper (L) (534), Qmin. plug (533), servo piston (532) and tilting pin (531) from pump casing (271, 272), and needle bearing (124) from valve block.

- ※ When removing tilting pin, use a protector to prevent pin head from being damaged.
- ※ Since lock tight is applied to fitting areas of tilting pin (531) and servo piston (532), take care not to damage servo piston (532).
- ※ Do not remove needle bearing (124) as far as possible, except the case that considered to be out of its life span.
- ※ Do not loosen hexagon nuts of valve block (312) and Qmin. plug (533).  
If loosened, flow setting will be changed.

#### 4) ASSEMBLY

(1) For reassembling reverse the disassembling procedures, paying attention to the following items.

- ① Do not fail to repair the parts damaged during disassembling, and repair replacement parts in advance.
- ② Clean each part fully with cleaning oil and dry it with compressed air.
- ③ Do not fail to apply clean working oil to sliding sections, bearings, etc. before assembling them.
- ④ In principle, replace seal parts, such as O-rings, oil seals, etc.
- ⑤ For fitting bolts, plug, etc., prepare a torque wrench or so on, and tighten them with torques shown in page 8-11, 12.
- ⑥ For the double-pump, take care not to mix up parts of the front pump with those of the rear pump.

(2) Insert the lock pin (255) after the swash plate support (251) into the pump casing (271, 272), and fit the lock pin (255) into the hole of the swash plate support (251).

- ※ In case the servo piston, tilting pin, stopper (L), stopper (S), and Qmin. plug have been removed, attached then to the pump casing in advance.
- ※ In the tightening work of the servo piston and the tilting pin, use the tool not to damaged the head of the tilting pin and the feed back pin. Besides, apply loctite (of medium strength) to the thread portion.



140Z98MP23


(3) Fit tilting bush (214) of swash plate (212) to tilting pin (531), and fit swash plate (212) with shoe plate (211) to swash plate support (251) correctly.

- ※ Confirm with fingers of both hands that swash plate can be removed smoothly.
- ※ Apply grease to sliding sections of swash plate (212) and swash plate support (251), and drive shaft (111, 113) can be fitted easily.
- ※ Take care not to damage shoe plate (211) surface.



140Z98MP24

(4) To pump casing (271, 272), fit drive shaft (111, 113) set with bearing (123), bearing spacer (127) and stop ring (824).



140Z98MP25

(5) In assemble of front pump, assemble seal cover (F) (261) to pump casing (271) and fix it with hexagon socket head bolt (406).

- ※ Apply grease lightly to oil seal in seal cover (F) (261).
- ※ For assemble oil seal (774), taking full care not to damage it.



140Z98MP26

(6) Assemble piston cylinder subassembly [cylinder (141), piston subassembly (151, 152), set plate (153), spherical bush (156) and cylinder spring (157)]. Fitting spline phases of cylinder, spherical bush (156) and drive shaft (111, 113), insert piston cylinder subassembly into pump casing (271, 272).



140Z98MP27

- (7) Fit valve plate (313, 314) to valve block (312), spring pin (886) into pin hole.  
※ Take care not to mistake suction/delivery direction of valve plate (312).



140Z98MP28

- (8) Place pump horizontally on workbench with its regulator fitting surface down, and attach pump casing (271, 272) to valve block (312). Fit 1st gear (116) simultaneously.  
※ Before bringing regulator fitting surface down, spread rubber sheet on workbench without fail to prevent this surface from being damaged.  
※ Take care not to mistake direction of valve block (312). [Clockwise rotation (viewed from input shaft side)]. Fit the valve block (312) with suction flange left when regulator side below, viewed from front side.



140Z98MP29

- (9) Fix valve block (312) to pump casing (271, 272) with hexagon socket head bolts (401).



140Z98MP30

- (10) Fit gear pump (04) to pump casing (272) with hexagon socket head bolts (435).



140Z98MP31



- (11) Attach the PTO unit (05) by fastening the flange socket (435) to the valve block (312).



140Z98MP32

- (12) In case the pump is not provided with the PTO unit (05), attach the cover (262) with the hexagon socket head cap screw (414).



140Z98MP33

- (13) Putting feedback lever (611) of regulator into feedback pin (548) of tilting pin (531), fit regulator with hexagon socket head bolt (415).

※ Take care not to mix up regulator of front pump and that of rear pump.









140Z98MP34

- (14) Fit drain port plug (468).  
This is the end of reassembling procedures.


### 3. REGULATOR

#### 1) STRUCTURE (1/2)



140Z92MP04

## REGULATOR (3/3)





140Z92MP05

079 EPPR valve assembly	624 Spring seat (C)	708 O-ring
412 Hexagon socket screw	625 Outer spring	724 O-ring
413 Hexagon socket screw	626 Inner spring	725 O-ring
418 Hexagon socket screw	627 Adjust stem (C)	728 O-ring
437 Hexagon socket screw	628 Adjust screw (C)	730 O-ring
438 Hexagon socket screw	629 Cover (C)	734 O-ring
439 Hexagon socket screw	630 Lock nut	753 O-ring
466 Plug	631 Sleeve, Pf	755 O-ring
496 Plug	641 Pilot cover	757 O-ring
601 Casing	643 Pilot piston	801 Nut
611 Feed back lever	644 Spring seat (Q)	802 Nut
612 Lever (1)	645 Adjust stem (Q)	814 Snap ring
613 Lever (2)	646 Pilot spring	836 Snap ring
614 Center plug	651 Sleeve	874 Pin
615 Adjust plug	652 Spool	875 Pin
616 Plug	653 Spring seat	887 Pin
621 Compensator piston	654 Return spring	897 Pin
622 Piston case	655 Set spring	898 Pin
623 Compensator rod	656 Block cover	924 Set screw

## 2) TOOLS AND TIGHTENING TORQUE

### (1) Tools

The tools necessary to disassemble/reassemble the pump are shown in the follow list.

Tool name & size		Part name			
Name	B	Hexagon socket head bolt	PT plug (PT thread)	PO plug (PF thread)	Hexagon socket head setscrew
Allen wrench 	4	M5	BP-1/16	-	M 8
	5	M6	BP-1/8	-	M10
	6	M8	BP-1/4	PO-1/4	M12, M14
Double ring spanner, socket wrench, double (single) open end spanner 	-	Hexagon head bolt	Hexagon nut	VP plug (PF thread)	
	6	M 8	M 8	-	
Adjustable angle wrench		Small size, Max 36 mm			
Screw driver		Minus type screw driver, Medium size, 2 sets			
Hammer		Plastic hammer, 1 set			
Pliers		For snap ring, TSR-160			
Steel bar		4 × 100 mm			
Torque wrench		Capable of tightening with the specified torques			
Pincers		-			
Bolt		M4, Length : 50 mm			



**(2) Tightening torque**

Part name	Bolt size	Torque		Wrench size	
		kgf · m	lbf · ft	in	mm
Hexagon socket head bolt (material : SCM435)	M 5	0.7	5.1	0.16	4
	M 6	1.2	8.7	0.20	5
	M 8	3.0	21.7	0.24	6
	M10	5.8	42.0	0.31	8
	M12	10.0	72.3	0.39	10
	M14	16.0	116	0.47	12
	M16	24.0	174	0.55	14
	M18	34.0	246	0.55	14
	M20	44.0	318	0.67	17
PT Plug (material : S45C) ※ Wind a seal tape 1 1/2 to 2 turns round the plug	PT1/16	0.7	5.1	0.16	4
	PT 1/8	1.05	7.59	0.20	5
	PT 1/4	1.75	12.7	0.24	6
	PT 3/8	3.5	25.3	0.31	8
	PT 1/2	5.0	36.2	0.39	10
PF Plug (material : S35C)	PF 1/4	3.0	21.7	0.24	6
	PF 1/2	10.0	72.3	0.39	10
	PF 3/4	15.0	109	0.55	14
	PF 1	19.0	137	0.67	17
	PF 1 1/4	27.0	195	0.67	17
	PF 1 1/2	28.0	203	0.67	17

### 3) DISASSEMBLY

Since the regulator consists of small precision finished parts, disassembly and assembly are rather complicated.

For this reason, replacement of a regulator assembly is recommended, unless there is a special reason, but in case disassembly is necessary for an unavoidable reason, read through this manual to the end before starting disassembly.


(1) Choose a place for disassembly.

- ※ Choose a clean place.
- ※ Spread rubber sheet, cloth, or so on on top of work-bench to prevent parts from being damaged.

(2) Remove dust, rust, etc. from surfaces of regulator with clean oil.

(3) Remove hexagon socket head screw (412, 413) and remove regulator main body from pump main body.


- ※ Take care not to lose O-ring.



(210-7) REG01

(4) Remove hexagon socket head screw (438) and remove cover (C,629)

- ※ Cover (C) is fitted with adjusting screw (C, 628), adjusting ring (C, 627), lock nut (630), hexagon nut (801) and adjusting screw (924).
- ※ Do not loosen these screws and nuts. If they are loosened, adjusted pressure-flow setting will vary.




(210-7) REG02


- (5) After removing cover (C, 629) subassembly, take out outer spring (625), inner spring (626) and spring seat (C, 624) from compensating section.

Then draw out adjusting ring (Q, 645), pilot spring (646) and spring seat (644) from pilot section.

- ※ Adjusting ring (Q,645) can easily be drawn out with M4 bolt.




- (6) Remove hexagon socket head screws (436, 438) and remove pilot cover (641). After removing pilot cover, take out set spring (655) from pilot section.




- (7) Remove snap ring (814) and take out spring seat (653), return spring (654) and sleeve (651).


- ※ Sleeve (651) is fitted with snap ring (836).
- ※ When removing snap ring (814), return spring (654) may pop out. Take care not to lose it.




- (8) Remove prevention plug (616) and take out center plug (614) and adjusting plug (615).

- ※ Center plug (614) and adjusting plug (615) can easily be taken out with M6 bolt.







- (9) Remove lever (2, 613). Do not draw out pin (875).  
※ Work will be promoted by using pincers or so on.



- (10) Draw out pin (874) and remove feedback lever (611).  
Push out pin (874, 4 mm in dia.) from above with slender steel bar so that it may not interfere with lever (1, 612).



- (11) Remove lever (1, 612). Do not draw out pin (875).
  - (12) Draw out pilot piston (643) and spool (652).
  - (13) Draw out piston case (622), compensating piston (621) and compensating rod (623).
- ※ Piston case (622) can be taken out by pushing compensating rod (623) at opposite side of piston case.

This completes disassembly.

#### 4) ASSEMBLY

(1) For assembly, reverse disassembly procedures, but pay attention to the following items.


- ① Always repair parts that were scored at disassembly.
- ② Get replacement parts ready beforehand.  
Mixing of foreign matter will cause malfunction.  
Therefore, wash parts well with cleaning oil, let them dry with jet air and handle them in clean place.
- ③ Always tighten bolts, plugs, etc. to their specified torques.
- ④ Do not fail to coat sliding surfaces with clean hydraulic oil before assembly.
- ⑤ Replace seals such as O-ring with new ones as a rule.

(2) Put compensating rod (623) into compensating hole of casing (601).


(3) Put pin force-fitted in lever (1, 612) into groove of compensating rod and fit lever (1) to pin force-fitted in casing.

(4) Fit spool (652) and sleeve (651) into hole in spool of casing.


- ※ Confirm that spool and sleeve slide smoothly in casing without binding.
- ※ Pay attention to orientation of spool.




- (5) Fit feedback lever (611), matching its pin hole with pin hole in spool.  
Then insert pin (874).
- ※ Insert pin in feedback lever a little to ease operation.
  - ※ Take care not to mistake direction of feedback lever.




- (6) Put pilot piston (643) into pilot hole of casing.
- ※ Confirm that pilot piston slides smoothly without binding.
- (7) Put pin force-fitted in lever (2, 613) into groove of pilot piston.  
Then fix lever (2).



- (8) Fit center plug (614) so that pin force-fitted in center plug (614) can be put into pin hole of lever (2).  
Then install prevention plug (858).
- (9) Insert adjusting plug (615) and fit locking ring.
- ※ Take care not to mistake inserting holes for fulcrum plug and adjusting plug.
- At this point in time move feedback lever to confirm that it has no large play and is free from binding.




- (10) Fit return spring (654) and spring seat (653) into spool hole and attach snap ring (814).




- (11) Fit set spring (655) to spool hole and put compensating piston (621) and piston case (622) into compensating hole.

Fit pilot cover (641) and tighten it with hexagonal socket head screws (437, 438).




- (12) Put spring seat (644), pilot spring (646) and adjusting ring (Q, 645) into pilot hole. Then fix spring seat (624), inner spring (626) and outer spring (625) into compensating hole.

※ When fitting spring seat, take care not to mistake direction of spring seat.



- (13) Install cover (C, 629) fitted with adjusting screws (628), adjusting ring (C, 627), lock nut (630), hexagon nut (801) and adjusting screw (924).

Then tighten them with hexagonal socket head screws (438).



This completes assembly.



## GROUP 4 MAIN CONTROL VALVE




### 1. REMOVAL AND INSTALL OF MOTOR

#### 1) REMOVAL


- (1) Lower the work equipment to the ground and stop the engine.
- (2) Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping.
- (3) Loosen the breather slowly to release the pressure inside the hydraulic tank.
- ▲ **Escaping fluid under pressure can penetrate the skin causing serious injury.**
  - ※ When pipes and hoses are disconnected, the oil inside the piping will flow out, so catch it in oil pan.
- (4) Remove the wirings for the pressure sensor and so on.
- (5) Remove bolts and disconnect pipe.
- (6) Disconnect pilot line hoses.
- (7) Disconnect pilot piping.
- (8) Sling the control valve assembly and remove the control valve mounting bolt and bracket.
  - Weight : 140 kg (310 lb)
- (9) Remove the control valve assembly.  
When removing the control valve assembly, check that all the piping have been disconnected.

#### 2) INSTALL

- (1) Carry out installation in the reverse order to removal.
- (2) Bleed the air from below items.
  - ① Cylinder (Boom, arm, bucket)
  - ② Swing motor
  - ③ Travel motor
  - ※ See each item removal and install.
- (3) Confirm the hydraulic oil level and recheck the hydraulic oil leak or not.




## 2. STRUCTURE (1/4)



125LCR8MC04

- |    |                        |    |                    |    |                  |
|----|------------------------|----|--------------------|----|------------------|
| 1  | Housing-P1             | 26 | Lock valve kit B   | 51 | Pilot B1 cap     |
| 4  | Spool assy-travel (LH) | 27 | Regeneration block | 53 | Socket head bolt |
| 7  | Spool assy-boom 1      | 33 | Plug               | 56 | Plain washer     |
| 10 | Spool assy-arm 2       | 41 | Orifice            | 58 | O-ring           |
| 12 | Spool assy-arm regen   | 42 | Plug               | 59 | O-ring           |
| 14 | Spool assy-bucket      | 45 | Poppet             | 69 | O-ring           |
| 20 | Nega con relief valve  | 48 | Orifice            | 81 | Spring           |
| 22 | Bucket stroke limiter  | 49 | Coin type filter   | 82 | Pin              |
| 24 | Holding valve kit A1   | 50 | Pilot A cap        |    |                  |

# STRUCTURE (2/4)




125LCR6MC05

- 16 Main relief valve
- 17 Overload relief valve
- 28 Plug
- 29 Plug
- 31 Plug
- 32 Plug
- 35 Plug
- 38 Plug
- 39 Plug

- 42 Plug
- 43 Poppet 1
- 44 Poppet 2
- 59 O-ring
- 61 O-ring
- 62 O-ring
- 63 O-ring
- 66 O-ring
- 67 O-ring

- 71 O-ring
- 72 O-ring
- 74 Back up ring
- 75 Back up ring
- 76 Back up ring
- 79 Spring
- 80 Spring


# STRUCTURE (3/4)



125LCR8MC06

- |    |                            |    |                  |    |                  |
|----|----------------------------|----|------------------|----|------------------|
| 2  | Housing-P2                 | 26 | Lock valve kit B | 54 | Socket head bolt |
| 3  | Spool assy-straight travel | 29 | Plug             | 55 | Socket head bolt |
| 4  | Spool assy-travel(RH)      | 30 | Plug             | 56 | Plain washer     |
| 6  | Spool assy-swing           | 40 | Plug             | 57 | Spring washer    |
| 8  | Spool assy-swing priority  | 46 | Sleeve           | 59 | O-ring           |
| 9  | Spool assy-boom 2          | 47 | Piston           | 61 | O-ring           |
| 11 | Spool assy-arm 1           | 50 | Pilot A cap      | 63 | O-ring           |
| 13 | Spool assy-option B        | 51 | Pilot B1 cap     | 69 | O-ring           |
| 15 | Spool assy-option C        | 52 | Pilot B2 cap     | 75 | Back up ring     |
| 25 | Holding valve kit A2       | 53 | Socket head bolt |    |                  |

# STRUCTURE (4/4)



14098MC07

- |    |                       |    |                  |    |              |
|----|-----------------------|----|------------------|----|--------------|
| 17 | Overload relief valve | 36 | Plug             | 65 | O-ring       |
| 18 | Overload relief valve | 37 | Plug             | 67 | O-ring       |
| 19 | Overload relief valve | 43 | Poppet 1         | 68 | O-ring       |
| 21 | Swing logic valve     | 44 | Poppet           | 72 | O-ring       |
| 23 | ON/OFF valve-option   | 48 | Orifice          | 73 | O-ring       |
| 28 | Plug                  | 49 | Coin type filter | 77 | Back up ring |
| 29 | Plug                  | 60 | O-ring           | 78 | Back up ring |
| 30 | Plug                  | 61 | O-ring           | 79 | Spring       |
| 31 | Plug                  | 62 | O-ring           | 80 | Spring       |
| 32 | Plug                  | 63 | O-ring           |    |              |
| 34 | Plug                  | 64 | O-ring           |    |              |

### 3. DISASSEMBLY AND ASSEMBLY

#### 1) GENERAL PRECAUTIONS

- (1) All hydraulic components are manufactured to a high precision. Consequently, before disassembling and assembling them, it is essential to select an especially clean place.
- (2) In handling a control valve, pay full attention to prevent dust, sand, etc. from entering into it.
- (3) When a control valve is to be removed from the machine, apply caps and masking seals to all ports. Before disassembling the valve, recheck that these caps and masking seals are fitted completely, and then clean the outside of the assembly. Use a proper bench for working. Spread paper or a rubber mat on the bench, and disassemble the valve on it.
- (4) Support the body section carefully when carrying or transferring the control valve. Do not lift by the exposed spool, end cover section etc.
- (5) After disassembling and assembling of the component it is desired to carry out various tests (for the relief characteristics, leakage, flow resistance, etc.), but hydraulic test equipment is necessary for these tests. Therefore, even when its disassembling can be carried out technically, do not disassemble such components that cannot be tested, adjusted, and so on. Additionally one should always prepare clean cleaning oil, hydraulic oil, grease, etc. beforehand.

#### 2) TOOLS


Before disassembling the control valve, prepare the following tools beforehand.

Name of tool	Quantity	Size (mm)
Vice mounted on bench (soft jaws)	1 unit	
Hexagon wrench	Each 1 piece	5, 6, 10, 12 and 14
Socket wrench	Each 1 piece	27 and 32
Spanner	Each 1 piece	32 (main relief valve, overload relief valve, negative relief valve) 26 (holding valve)

### 3) DISASSEMBLY

#### (1) Disassembly of spools without holding valve (travel right, travel left)


- ① Loosen hexagon socket head bolts with washer.  
(hexagon wrench : 5 mm)
  - ② Remove the pilot cover.
- ※ Pay attention not to lose the O-ring under the pilot cover.
- ③ Remove the spool assembly from the body by hand slightly.
- ※ When extracting each spool from its body, pay attention not to damage the body.
  - ※ When extracting each spool assembly, it must be extracted from spring side only.
  - ※ When any abnormal parts are found, replace it with completely new spool assembly.
  - ※ When disassembled, tag the components for identification so that they can be reassembled correctly.



14098MC10

## (2) Disassembly of spools with holding valve (boom 1, Arm 1 spool)

- ① Loosen hexagon socket head bolts with washer.  
(hexagon wrench : 5 mm)
- ② Remove the pilot cover with internal parts.
  - ※ Pay attention not to lose the O-ring and the poppet under the pilot cover.
  - ※ Pay attention not to damage the "piston A" under pilot cover.
- ③ Remove the spool assembly from the body by hand slightly.
  - ※ When extracting each spool from its body, pay attention not to damage the body.
  - ※ When extracting each spool assembly, it must be extracted from spring side only.
  - ※ When any abnormal parts are found, replace it with completely new spool assembly.
  - ※ When disassembled, tag the components for identification so that they can be reassembled correctly.




125LCR8MC11



### (3) Disassembly of the holding valve


- ① Remove the pilot cover with the holding valve as described on previous page.
  - ※ Do not disassemble internal parts of the pilot cover.
- ② Loosen the poppet seat and remove the poppet, spring seat, spring and check.  
(spanner : 26 mm)
  - ※ Pay attention not to lose the poppet.
  - ※ Do not disassemble internal parts of the check.



125LCR8MC12

#### (4) Disassembly of the load check valve and the negative relief valve



- ① The load check valve
  - a. Fix the body to suitable work bench.
  - ※ Pay attention not to damage the body.
  - b. Loosen the plug (hexagon wrench : 10 mm).
  - c. Remove the spring and the load check valve with pincers or magnet.
- ② The negative relief valve
  - a. Loosen the socket (spanner : 32 mm).
  - b. Remove the spring, spring holder, piston and negative control poppet.



14W98MC13

## (5) Disassembly of the main and overload relief valve

- ① Fix the body to suitable work bench.
  - ② Remove the main relief valve.  
(spanner : 32 mm)
  - ③ Remove the overload relief valve.  
(spanner : 32 mm)
- ※ When disassembled, tag the relief valve for identification so that they can be reassembled correctly.
  - ※ Pay attention not to damage seat face.
  - ※ When any abnormal parts are found, replace it with completely new relief valve assembly.



14098MC14

## **(6) Inspection after disassembly**

Clean all disassembled parts with clean mineral oil fully, and dry them with compressed air. Then, place them on clean papers or cloths for inspection.

### **① Control valve**

- a. Check whole surfaces of all parts for burrs, scratches, notches and other defects.
- b. Confirm that seal groove faces of body and block are smooth and free of dust, dent, rust etc.
- c. Correct dents and damages and check seat faces within the body, if any, by lapping.  
※ Pay careful attention not to leave any lapping agent within the body.
- d. Confirm that all sliding and fitting parts can be moved manually and that all grooves and paths are free foreign matter.
- e. If any spring is broken or deformed, replace it with new one.
- f. When a relief valve does not function properly, repair it, following its the prescribed disassembly and assembly procedures.
- g. Replace all seals and O-rings with new ones.

### **② Relief valve**

- a. Confirm that all seat faces at ends of all poppets and seats are free of defects and show uniform and consistent contact faces.
- b. Confirm manually that main poppet and seat can slide lightly and smoothly.
- c. Confirm that outside face of main poppet and inside face of seat are free from scratches and so on.
- d. Confirm that springs are free from breakage, deformation, and wear.
- e. Confirm that orifices of main poppet and seat section are not clogged with foreign matter.
- f. Replace all O-rings with new ones.
- g. When any light damage is found in above inspections, correct it by lapping.
- h. When any abnormal part is found, replace it with a completely new relief valve assembly.

## 4) ASSEMBLY

### (1) General precaution

- ① In this assembly section, explanation only is shown.  
For further understanding, please refer to the figures shown in the previous structure & disassembly section.
- ② Pay close attention to keeping all seals free from handling damage and inspect carefully for damage before using them.
- ③ Apply clean grease or hydraulic oil to the seal so as to ensure it is fully lubricated before assembly.  
Do not stretch seals so much as to deform them permanently.
- ④ In fitting O-rings, pay close attention not to roll them into their final position in addition, a twisted
- ⑤ O-ring cannot easily untwist itself naturally and could thereby cause inadequate sealing and thereby both internal and external oil leakage.
- ⑥ Tighten fitting bolts for all sections with a torque wrench adjusted to the respective tightening torque.
- ⑦ Do not reuse removed O-rings and seals.

### (2) Load check valve

- ① Assemble the load check valve and spring.
- ② Put O-rings on to plug.
- ③ Tighten plug to the specified torque.
  - Hexagon wrench : 10 mm
  - Tightening torque : 6~7 kgf · m (43.4~50.6 lbf · ft)

### (3) Negative control relief valve

- ① Assemble the nega-con poppet, piston, spring holder and spring together into body.
- ② Put O-ring on to plug and tighten the latter to its specified torque.
  - Hexagon wrench : 12 mm
  - Tightening torque : 8~9 kgf · m (57.8~65.1 lbf · ft)

### (4) Main relief, overload relief valves

Install main relief valve, overload relief valve into the body and tighten to the specified torque.

Component	Tools	Tightening torque	
		kgf · m	lbf · ft
Main relief valve	Spanner 32 mm	8~9	57.8~65.1
Overload relief valve	Spanner 32 mm	8~9	57.8~65.1

### (5) Main spools

- ① Carefully insert the previously assembled spool assemblies into their respective bores within of body.
  - ※ Fit spool assemblies into body carefully and slowly. Do not under any circumstances push them forcibly in.

## **(6) Pilot covers**

- ① Fit spool covers to the non-spring assembly end of the spool, and tighten the hexagonal socket head bolts to the specified torque.
  - Hexagon wrench : 5 mm
  - Tightening torque : 1.0~1.1 kgf · m (7.2~7.9 lbf · ft)
- ※ Confirm that O-rings have been fitted.
- ② Fit spring covers to the spring end for the spools, and tighten hexagon socket head bolts to the specified torque.
  - Hexagon wrench : 5mm
  - Tightening torque : 1.0~1.1 kgf·m (7.2~7.9 lbf·ft)
- ※ Confirm that O-rings have been fitted.

## **(7) Holding valves**

- ① Assemble the check, spring seat and poppet together into body.
- ② Tighten the poppet seat to the specified torque.
  - Spanner : 26 mm
  - Tightening torque : 6~7 kgf · m (43.4~50.6 lbf · ft)
- ③ Fit the "piston A" under pilot cover with internal parts into hole on the poppet seat.
- ④ Tighten hexagon socket head bolt to specified torque.
  - Hexagon wrench : 5mm
  - Tightening torque : 1.0~1.1 kgf · m (7.2~7.9 lbf · ft)

## GROUP 5 SWING DEVICE

### 1. REMOVAL AND INSTALL OF MOTOR

#### 1) REMOVAL

- (1) Lower the work equipment to the ground and stop the engine.
- (2) Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping.
- (3) Loosen the breather slowly to release the pressure inside the hydraulic tank.

▲ Escaping fluid under pressure can penetrate the skin causing serious injury.

※ When pipes and hoses are disconnected, the oil inside the piping will flow out, so catch it in oil pan.



- (4) Disconnect hose assembly (2).
- (5) Disconnect pilot line hoses (3, 4, 5, 6, 7, 8).
- (6) Sling the swing motor assembly (1) and remove the swing motor mounting socket bolts (9).

· Motor device weight : 34 kg (75 lb)

- (7) Remove the swing motor assembly.  
※ When removing the swing motor assembly, check that all the piping have been disconnected.


#### 2) INSTALL

- (1) Carry out installation in the reverse order to removal.
- (2) Bleed the air from the swing motor.
  - ① Remove the air vent plug.
  - ② Pour in hydraulic oil until it overflows from the port.
  - ③ Tighten plug lightly.
  - ④ Start the engine, run at low idling and check oil come out from plug.
  - ⑤ Tighten plug fully.
- (3) Confirm the hydraulic oil level and check the hydraulic oil leak or not.



## 2. DISASSEMBLY AND ASSEMBLY OF SWING MOTOR

### 1) STRUCTURE



125LCR2SM22

1	Casing	17	Spring pin	33	Plug
2	Oil seal	18	O-ring	34	O-ring
3	Shaft	19	O-ring	35	O-ring
4	Snap ring	20	Valve plate	36	Time delay valve spool
5	Roller bearing	21	Spring pin	37	Spring seat
6	Roller bearing	22	Valve casing	38	Spring
7	Swash plate	23	Check valve	39	Restrictor
8	Cylinder block	24	Spring	40	O-ring
9	Spring	25	Plug	41	Level gauge assy
10	Ball guide	26	O-ring	42	Socket bolt
11	Retainer plate	27	Plug	43	Plug
12	Piston assy	28	O-ring	44	Expander
13	Friction plate	29	Plug	45	Expander
14	Separate plate	30	O-ring	46	Name plate
15	Parking piston	31	Relief valve assy	47	Rivet
16	Spring	32	Anti-rotating valve assy		



## 2) DISASSEMBLY

- (1) For easy assembly, put motor on worktable with the spline side of shaft (3) facing downwards.
  - ※ Lay rubber plate on worktable and take care not to damage the components.



125LCR8SM03

- (2) Remove snap ring (4) using snap ring plier.



125LCR8SM04

- (3) Disassemble level gauge assembly (41) using pipe wrench.



125LCR8SM05

- (4) Disassemble two sets of relief valve assembly (31) using 36 mm socket wrench.



125LCR8SM06

- (5) Unscrew socket bolt (42) (4EA) using 12 mm hexagon wrench.



125LCR8SM07

- (6) Remove valve plate (20) from valve casing.  
※ Take care not to drop the valve plate (20).




125LCR8SM08

- (7) Remove O-ring (18) from valve casing.




125LCR8SM09

- (8) Remove plug (33) using 10 mm hexagon wrench and take out anti-rotating valve assembly (32).  
(same for the set on opposite side)



125LCR8SM10

(9) Remove plug (29) (1EA), plug (27) (2EA) using 4 mm, 6 mm hexagon wrench.



125LCR8SM11


(10) Remove plug (25) using 32 mm socket wrench and separate spring ; spring (24) and check valve (23). (same for the set on opposite side)



125LCR8SM12


(11) Separate each one of O-ring (40) and spring (38).

- ※ Do not lose spring.
- ※ Do not mix spring with other springs.



125LCR8SM13

(12) Remove spool (36) and spring seat (37).



125LCR8SM14

(13) Remove spring (16) (24EA) from parking piston.



125LCR8SM15

(14) Disassemble parking piston (15) from casing using air gun.



125LCR8SM16

(15) Lay casing down horizontally and remove cylinder block assembly from shaft. And remove all friction plate (13) and separator plate (14).



125LCR8SM17

(16) Separate piston assembly (12), ball guide (10), retainer plate (11) and spring (9).



125LCR8SM18




(17) Remove O-ring (19) from casing.



125LCR8SM19

(18) Use a magnet to separate swash plate (7) from casing.

- ※ Sliding surface should be carefully treated to avoid scratches and damage.



125LCR8SM20

(19) Disassemble shaft (3) and cylindrical roller bearing (5).

- ※ Do not remove cylindrical roller bearing (5) unless malfunction is detected, since it is mounted by shrink fit.



125LCR8SM21

(20) Turn casing (1) upside down and remove oil seal (2) using jig.



125LCR8SM22

### 3) ASSEMBLY

※ Even though assembly is accomplished by reversing disassembly steps, be careful of the following.

- ① Repair the damaged part when disassembling and prepare parts for exchange in advance.
- ② All parts should be cleaned with cleaner, dried with compressed air.
- ③ Sliding surface, O-ring, bearing and oil seal should be lubricated with clean hydraulic oil, prior to final assembly.
- ④ Replacement of O-ring and oil seal with new parts is generally recommended.
- ⑤ Use a torque wrench to make sure that assembly fasteners are tightened to specified values.
- ⑥ When assembling bolt, spread loctite.

- (1) Put casing (1) on worktable.  
Press oil seal (2) using oil seal jig, until it reach the bottom.  
※ Spread grease on external diameter of oil seal.



125LCR8SM23

- (2) Mount cylindrical roller bearing (5, 6) on shaft  
(3) using shrink fitting method.



125LCR8SM24

- (3) Assemble shaft assembly in casing using urethane hammer.  
※ Take care not to damage oil seal.



125LCR8SM25

- (4) Insert swash plate (7).  
※ Take care not to damage sliding surface.



125LCR8SM26

- (5) After applying grease on O-ring (19), insert O-ring in casing (1).




125LCR8SM27

- (6) Assemble spring (9) (9EA) in cylinder block (8).



125LCR8SM28

- (7) Assemble ball guide (10) in cylinder block.  
※ Take care not to damage sliding surface of cylinder block.



125LCR8SM29

- (8) Insert piston assembly (12) in retainer plate (11).  
※ Do not mix piston with other piston (9EA/1set).  
※ Spread sufficient amount of hydraulic oil on piston assembly.



125LCR8SM30

- (9) Place all 9 pistons simultaneously into the holes of cylinder block.  
※ Take care not to damage sliding surface.



125LCR8SM31

- (10) Lay casing down horizontally and put cylinder block assembly in casing.  
※ Check whether cylinder block assembly rotates smoothly.



125LCR8SM32




(11) Put friction plate (13) in casing.



125LCR8SM33

(12) Put separator plate (14) in casing.

※ Put friction plate and separator plate alternately.



125LCR8SM34

(13) Assemble O-ring (18) in parking piston (15).

※ Apply grease on O-ring.



125LCR8SM35


(14) Assemble parking piston (15) in casing using jig.

※ Pay attention to the hole location of parking piston.



125LCR8SM36

(15) Put spring (16) (24EA) in each hole of parking piston.




125LCR8SM37

(16) Assemble restrictor (39) in spool (36).  
※ Spread loctite #242.




125LCR8SM38

(17) Place spool in casing.



125LCR8SM39

(18) Assemble spring (38) & spring seat (37) in casing.



125LCR8SM40

(19) Assemble plug (27) using 6 mm hexagon wrench.


※ Tightening torque : 4.5 kgf · m (32.5 lbf · ft)



125LCR8SM41


(20) Assemble plug (29) using 4 mm hexagon wrench.

※ Tightening torque : 3 kgf · m (21.7 lbf · ft)



125LCR8SM42


(21) Assemble anti-rotating valve assembly (32) in valve casing.



125LCR8SM43

(22) Assemble plug (33) using 32 mm hexagon wrench.

※ Tightening torque : 10 kgf · m (72.3 lbf · ft)



125LCR8SM44

(23) Caulk check valve (23) using jig. (same for the set on opposite side)



125LCR8SM45

(24) Assemble spring (24), plug (25). (in that order)  
(same for the set on opposite side)  
※ Tightening torque : 15 kgf · m (108 lbf · ft)



125LCR8SM46

(25) Assemble spring pin (21) in valve casing using jig.



125LCR8SM47

(26) Assemble O-ring (18) & cylindrical roller bearing (6) in valve casing.  
※ Use jig (press fit or cold shrink fit).



125LCR8SM48



(27) Apply grease on steel side of valve plate (20) to prevent plate from sliding.

Assemble valve plate with the copper side facing upwards.


- ※ Pay attention to the assembly direction.
- ※ Take care not to damage sliding surface.



125LCR8SM49

(28) Assemble valve casing by matching its holes and pins of casing and parking piston. And tighten bolt; socket (42) (4EA) using 12 mm hexagon wrench.

- ※ Tightening torque : 17.5 kgf · m (127 lbf · ft)
- ※ Make sure valve plate stays in place.
- ※ When tightening bolts, make sure mating surfaces between casing and valve casing maintain parallel to each other.



125LCR8SM50

(29) Assemble relief valve assembly (31) using 36 mm socket wrench in valve casing.

- ※ Spread grease on O-ring part of relief valve assembly.
- ※ Tightening torque : 18 kgf · m (130 lbf · ft)



125LCR8SM51

(30) Assemble snap ring (4) in shaft by using snap ring plier.



125LCR8SM52

(31) Wrap teflon tape 2 or 3 times around the tap part of level gauge assembly (41).  
And assemble it using pipe wrench.



125LCR6SM53

### 3. REMOVAL AND INSTALL OF REDUCTION GEAR


#### 1) REMOVAL

- (1) Remove the swing motor assembly.  
For details, see removal of swing motor assembly.
- (2) Sling reduction gear assembly (1) and remove mounting bolts (2).
- (3) Remove the reduction gear assembly.
  - Reduction gear device weight : 75 kg  
(165 lb)




#### 2) INSTALL

- (1) Carry out installation in the reverse order to removal.
  - Tightening torque : 17.5 kgf · m  
(126 lbf · ft)



## 4. DISASSEMBLY AND ASSEMBLY OF REDUCTION GEAR

### 1) STRUCTURE



125LCR2SM23

1	Ring gear	11	Planetary gear No. 2	21	Carrier pin No. 1
2	Drive shaft	12	Needle bearing No. 2	22	Sun gear No. 1
3	Bearing	13	Thrust washer No. 2	23	Snap ring
4	Bearing	14	Carrier pin No. 2	24	Thrust plate
5	Ring nut	15	Spring pin	25	Sleeve
6	Lock plate	16	Sun gear No. 2	26	O-ring
7	Hexagon bolt	17	Carrier No. 1	27	Oil seal
8	Casing	18	Planetary gear No. 1	30	Plug
9	Socket bolt	19	Needle bearing No. 1	31	Parallel pin
10	Carrier No. 2	20	Thrust washer No. 1	32	Thrust washer No. 1




## 2) DISASSEMBLY

- (1) Remove the swing motor, and then place swing reduction gear on the bench.



125LCR8SM60

- (2) Disassemble sun gear No.1 (22).



125LCR8SM61

- (3) Disassemble carrier No.1 sub assembly.



125LCR8SM62

### Carrier No.1 sub assy disassembly

- (4) Put carrier No.1 sub assembly on the bench, then remove the snap ring (23).



125LCR8SM63

- (5) Disassemble thrust washer No.1 (upper)  
(32).(3 pcs)



125LCR8SM64

- (6) Disassemble planetary gear No.1 (18).  
(3 pcs)



125LCR8SM65

- (7) Disassemble thrust plate (24).



125LCR8SM66

- (8) Disassemble needle bearing No.1 (19).  
(3 pcs)



125LCR8SM67

(9) Disassemble thrust washer No.1 (lower) (20).  
(3 pcs)



125LCR8SM68

(10) After placing spring pin (15) to center of carrier pin No.1 (21) with a jig, disassemble it.  
(3 pcs)  
※ Do not reuse spring pin, carrier and carrier pin.



125LCR8SM69

(11) Disassemble sun gear No.2 (16).



125LCR8SM70

(12) Disassemble carrier No.2 sub assembly.



125LCR8SM71

### Carrier No.2 sub assy disassembly

(13) After placing spring pin (15) to center of carrier pin No.2 (14) with a press machine, disassemble it.(3 pcs)

※ Do not reuse spring pin.



125LCR8SM72

(14) Disassemble planetary gear No.2.(3 pcs)



125LCR8SM73

(15) Disassemble thrust plate (24).



125LCR8SM74

(16) Disassemble thrust washer No.2 (13).(6 pcs)



125LCR8SM75



(17) Disassemble needle bearing No.2 (12).  
(3 pcs)




125LCR8SM76

(18) Separate ring gear (1) from casing (8).




125LCR8SM77

(19) Loosen a bolt (7) (4 pcs), and disassemble lock plate (6).



125LCR8SM78

(20) Disassemble nut ring (5) by using the jig.



140L8SM01



125LCR8SM79

### Drive shaft sub assy disassembly

(21) Separate drive shaft sub assembly from casing (8).



125LCR8SM80

(22) Disassemble taper bearing (3) and oil seal (27) by using a press machine.



125LCR8SM81

(23) Disassemble sleeve (25) and O-ring (26).



125LCR8SM82

(24) Disassemble the outer ring of taper bearing (3) in casing (8) by using the jig.



125LCR8SM83

### 3) ASSEMBLY

※ Even though assembly is accomplished by reversing disassembly steps, be careful of the following.

- ① Repair the damaged part when disassembling and prepare parts for exchange in advance.
- ② All parts should be cleaned with cleaner, dried with compressed air.
- ③ Sliding surface, O-ring, bearing and oil seal should be lubricated with clean hydraulic oil, prior to final assembly.
- ④ Replacement of O-ring and oil seal with new parts is generally recommended.
- ⑤ Use a torque wrench to make sure that assembly fasteners are tightened to specified values.
- ⑥ When assembling bolt, spread loctite.

#### Carrier No.1 sub assembly

- (1) After heating the carrier No.1 (17), assemble carrier pin No.1 (21) to the side without the hole.




125LCR8SM84

- (2) After drilling  $\varnothing 6$  hole, assemble spring pin (15).(3 pcs)



125LCR8SM85

- (3) Caulking is performed on the assembled spring pin unit.  
 ※ To cover pins, implement the caulking in two places that are located direction of 180 degrees around assembled spring pin.



125LCR8SM86

- (4) Assemble thrust washer No.1 (lower) (20).  
 (3 pcs)



125LCR8SM87

- (5) Assemble needle bearing No.1 (19).(3 pcs)



125LCR8SM88

- (6) Assemble thrust plate (24).



125LCR8SM89



- (7) Assemble planetary gear No.1 (18) of which groove is faced downward.(3 pcs)



125LCR8SM90

- (8) Assemble thrust washer No.1 (upper) (32).  
(3 pcs)



125LCR8SM91

- (9) Assemble snap ring (23) (3 pcs), complete carrier No.1 sub assembly.  
※ Gear rotation state should be smooth.



125LCR8SM92

### Carrier No.2 sub assy assembly

- (10) Assemble needle bearing No.2 (12) in the planetary gear No.2 (11).



125LCR8SM93

- (11) After spreading grease on thrust washer No.2 (13), assemble it on both upper side and lower side of planetary gear No.2.



125LCR8SM94

- (12) Assemble thrust plate (24).



125LCR8SM95

- (13) Assemble planetary gear No.2 in the carrier No.2 (10).(3 pcs)  
※ Thrust washer No.2 should not separated.



125LCR8SM96

- (14) Assemble carrier pin No.2 (14) to match the pin hole of the carrier No.2.(3 pcs)



125LCR8SM97


(15) Assemble spring pin (15).(3 pcs)



125LCR8SM98

(16) Caulking is performed on the assembled spring pin unit.

- ※ To cover pins, implement the caulking in two places that are located direction of 180 degrees around assembled spring pin.



125LCR8SM99

### Drive shaft sub assy assembly

(17) After heating sleeve (25), assemble O-ring (26) to groove of inside diameter in it.



125LCR8SM100

(18) Shrink fit the sleeve on drive shaft (2).

- ※ Be careful of fully seat at the bottom.



125LCR8SM101

- (19) Shrink fit taper bearing (3) on drive shaft, complete drive shaft sub assembly.



125LCR8SM102

### Casing assembly

- (20) Press outer ring of the taper bearing in the casing (8) by using the jig.



125LCR8SM103

- (21) Press in oil seal (27) by using the jig.  
※ Be careful of the direction of the assembly.



125LCR8SM104

- (22) Assemble drive shaft sub assembly.  
※ Be careful of damage of oil seal.



125LCR8SM105



(23) After fixing drive shaft so that it does not fall, and then turn it over, press taper bearing (4).



125LCR8SM106

(24) Assemble nut ring (5) by using the jig.  
※ Tightening torque :  $3.5 \pm 0.4$  kgf · m  
( $25.3 \pm 2.9$  lbf · ft)



125LCR8SM107

(25) Place lock plate (6) on the nut ring.



125LCR8SM108


(26) After spreading loctite #242, assemble the bolt (7) (4 pcs).

※ Tightening torque :  $2.5 \pm 0.25$  kgf · m  
( $18.1 \pm 1.8$  lbf · ft)




125LCR8SM109

(27) Press parallel pin (31) by using press machine.



125LCR8SM110

(28) Spread the loctite #515 on the casing with reference to the right detail view.  
※ Loctite should not flow into casing.



125LCR8SM111

(29) Assemble ring gear (1) in accordance with a pin hole on casing.  
※ Be careful of damage of the ring gear.



125LCR8SM112

(30) Assemble carrier No.2 sub assembly.



125LCR8SM113

(31) Assemble sun gear No.2 (16).



125LCR8SM114

(32) Assemble carrier No.1 sub assembly.



125LCR8SM115

(33) Assemble sun gear No.1 (22) of which grinding surface is faced downward.



125LCR8SM116

(34) Fill with gear oil 3.5 liter.



125LCR8SM117



## GROUP 6 TRAVEL DEVICE

### 1. REMOVAL AND INSTALL

#### 1) REMOVAL

- (1) Swing the work equipment 90° and lower it completely to the ground.
- (2) Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping.
- (3) Loosen the breather slowly to release the pressure inside the hydraulic tank.


**▲ Escaping fluid under pressure can penetrate the skin causing serious injury.**

※ When pipes and hoses are disconnected, the oil inside the piping will flow out, so catch it in oil pan.

- (4) Remove the track shoe assembly.  
For details, see **removal of track shoe assembly**.
- (5) Remove the cover.
- (6) Remove the hose.  
※ Fit blind plugs to the disconnected hoses.
- (7) Remove the bolts and the sprocket.
- (8) Sling travel device assembly (1).
- (9) Remove the mounting bolts (2), then remove the travel device assembly.  
· Weight : 140 kg (310 lb)



13031GE18





125LCR9A8TM01

#### 2) INSTALL

- (1) Carry out installation in the reverse order to removal.
- (2) Bleed the air from the travel motor.
  - ① Remove the air vent plug.
  - ② Pour in hydraulic oil until it overflows from the port.
  - ③ Tighten plug lightly.
  - ④ Start the engine, run at low idling, and check oil come out from plug.
  - ⑤ Tighten plug fully.
- (3) Confirm the hydraulic oil level and check the hydraulic oil leak or not.

## 2. TRAVEL MOTOR

### 1) STRUCTURE



- |                      |                    |                             |                        |                           |
|----------------------|--------------------|-----------------------------|------------------------|---------------------------|
| 1 Casing             | 18 Separated plate | 35 Spring                   | 52 Plug                | 69 Thrust washer No. 2    |
| 2 Plug               | 19 Parking piston  | 36 O-ring                   | 53 O-ring              | 70 Sun gear No.2          |
| 3 Oil seal           | 20 O-ring          | 37 Spring seat              | 54 Plug                | 71 Carrier No.1           |
| 4 Piston             | 21 Back up ring    | 38 Relief valve assy        | 55 Restrictor          | 72 Planetary gear No.1    |
| 5 Piston seal        | 22 O-ring          | 39 O-ring                   | 56 Restrictor          | 73 Needle bearing No.1    |
| 6 Shaft              | 23 Back up ring    | 40 Spool                    | 57 Name plate          | 74 Inner race No. 1       |
| 7 Front ball bearing | 24 Valve plate     | 41 Plug                     | 58 Rivet               | 75 Thrust plate No. 1     |
| 8 Rear ball bearing  | 25 Spring pin      | 42 Spring seat              | 59 Ring gear           | 76 Hexagon head bolt      |
| 9 Steel ball         | 26 Spring          | 43 Parallel pin             | 60 Bearing             | 77 Countersunk head screw |
| 10 Steel ball        | 27 O-ring          | 44 Spring                   | 61 Floating seal assy  | 78 Sun gear No.1          |
| 11 Swash plate       | 28 Spring pin      | 45 Connector                | 62 Nut ring            | 79 Steel ball             |
| 12 Cylinder block    | 29 Parallel pin    | 46 O-ring                   | 63 Lock plate          | 80 Cover                  |
| 13 Spring            | 30 Rear cover      | 47 Hexagon socket head bolt | 64 Hexagon head bolt   | 81 Hex socket head bolt   |
| 14 Ball guide        | 31 Main spool assy | 48 Hexagon socket head bolt | 65 Thrust plate No. 2  | 82 Plug                   |
| 15 Retainer plate    | 32 Cover           | 49 Hexagon socket head bolt | 66 Planetary gear No.2 | 83 O-ring                 |
| 16 Piston assy       | 33 Spring          | 50 Check valve              | 67 Needle bearing No.2 | 84 Name plate             |
| 17 Friction plate    | 34 Restrictor      | 51 Spring                   | 68 Inner race No. 2    | 85 Rivet                  |

125LCR2TM21


## 2) DISASSEMBLY

- (1) Choose a clean place, remove contaminants (dust, etc) and cleans motor before placing it on worktable.
  - ※ Lay the rubber plate on worktable and take care not to damage the component.




125LCR8TM02

- (2) Remove the connector (45) using 21 mm socket wrench.




125LCR8TM03

- (3) Remove plug (41) using 21 mm socket wrench.



125LCR8TM04

- (4) Disassemble parallel pin (43) and spring (44).
  - ※ Do not lose spring.
  - ※ Do not mix spring with other springs.




125LCR8TM05

(5) Remove spring seat (42) and spool (40).




125LCR8TM06

(6) Disassemble relief valve assembly (38) using 26 mm socket wrench. (2 sets)



125LCR8TM07

(7) Disassemble cover (32) using 41 mm socket wrench.



125LCR8TM08


(8) Disassemble spring seat (37) and spring (33). (2 sets)



125LCR8TM09



- (9) Separate main spool assembly (31) from rear cover.



125LCR8TM10

- (10) Unscrew socket bolt (47) (1EA), (48) (3EA), (49) (6EA) from rear cover.



125LCR8TM11

- (11) Remove parallel pin (29).



125LCR8TM12

- (12) From rear cover, disassemble valve plate (24) and O-ring (27).

※ Take care not to damage assembly surface of rear cover.



125LCR8TM13

(13) Disassemble restrictor (55, 56) (2EA).

- ※ Mark the number on restrictor and its hole to avoid confusing (55) and (56).



125LCR8TM14


(14) Remove plug (52).



125LCR8TM15


(15) Remove restrictor (34) and spring (35). (2 sets)

- ※ Do not confuse restrictor (34) and check valve (50).
- ※ Do not confuse spring (35) and spring (51).
- ※ Do not lose spring.
- ※ Do not mix spring with other springs.



125LCR8TM16

(16) Remove plug (52) using 5 mm hexagon wrench.




125LCR8TM17



(17) Remove check valve (50) and spring (51). (2 sets)

- ※ Do not confuse restrictor (34) and check valve (50).
- ※ Do not confuse spring (35) and spring (51).
- ※ Do not lose spring.
- ※ Do not mix spring with other springs.



125LCR8TM18

(18) From parking piston, remove spring (26) (12ea).

- ※ Do not lose spring.
- ※ Do not mix spring with other springs.



125LCR8TM19

(19) Disassemble parking piston (19) using air gun or jig.



125LCR8TM20

(20) From parking piston, separate O-ring (22) and back-up ring (23).



125LCR8TM21

(21) From parking piston separate O-ring (20) and back-up ring (21).



125LCR8TM22

(22) Lay casing down horizontally and remove cylinder block assembly, friction plate (17) (3EA) and separator plate (18) (4EA).



125LCR8TM23

(23) Separate retainer plate (15) and piston assembly (16).

- ※ Take care not to damage sliding surface of each component.



125LCR8TM24

(24) Disassemble ball guide (14) and spring (13) (9EA).


- ※ Do not lose spring.
- ※ Do not mix spring with other springs.



125LCR8TM25

(25) Disassemble swash plate (11) and steel ball (10).

※ Take care not to damage sliding surface.



125LCR8TM26

(26) Disassemble shaft (6) and ball bearing (7).

※ Do not remove ball bearing unless malfunction is detected, since it is mounted by shrink fit.



125LCR8TM27

(27) Disassemble 1, 2 speed piston (4) and steel ball (9) using air gun.



125LCR8TM28

(28) Disassemble piston seal (5).



125LCR8TM29

(29) Turn casing (1) upside down and remove oil seal (3) using jig.



125LCR8TM30

### 3) ASSEMBLY

※ Even though assembly is accomplished by reversing disassembly steps, be careful of the following.

- ① Repair the damaged part when disassembling and prepare parts for exchange in advance.
- ② All parts should be cleaned with cleaner, dried with compressed air.
- ③ Sliding surface, O-ring, bearing and oil seal should be lubricated with clean hydraulic oil, prior to final assembly.
- ④ Replacement of O-ring and oil seal with new parts is generally recommended.
- ⑤ Use a torque wrench to make sure that assembly fasteners are tightened to specified values shown table1.
- ⑥ When assembling bolt, spread Loctite.

(1) Put casing (1) on the worktable.



125LCR8TM31

(2) After applying grease on the external diameter of oil seal (3), insert oil seal in casing.



125LCR8TM32



- (3) After applying grease on steel ball (10), insert steel ball in casing.



125LCR8TM33

- (4) After assembling piston seal (5) and steel ball (9) in 1, 2 speed piston (4), insert piston in hole of casing.  
※ Check whether piston sticks in hole.  
※ Use piston seal jig.



125LCR8TM34

- (5) Mount ball bearing (7) on shaft (6) by shrink fit. Insert shaft in casing.  
※ Take care not to damage oil seal.



125LCR8TM35

- (6) Assemble swash plate (11) by matching its hole and steel ball.  
※ Take care not to damage sliding surface.



125LCR8TM36



- (7) Assemble spring (13) (9ea) and ball guide (14) in cylinder block (12) in that order.



125LCR8TM37

- (8) Insert piston assembly (16) in retainer plate (15) and assemble them in cylinder block.  
※ Spread hydraulic oil on piston assembly.  
※ Take care not to damage each component.  
※ Check cylinder block and piston assembly runs properly.




125LCR8TM38

- (9) Lay casing down horizontally and assemble cylinder block assembly by matching its spline with shaft.  
※ Make sure swash plate stays in place.  
※ Check the assembling status of cylinder block by pressing it.



125LCR8TM39

- (10) Assemble separator plate (18) (4EA) and friction plate (17) (3EA) alternately.



125LCR8TM40

(11) Insert back-up ring & O-ring in parking piston.



125LCR8TM41

(12) Align the pin hole of parking piston (19) with oil hole of casing, assemble them using jig.  
※ Spread grease on O-ring and back-up ring.  
※ Take care not to damage components.



125LCR8TM42

(13) Insert spring (26) (12EA) in parking piston.



125LCR8TM43

(14) Insert parallel pin (29) (2EA) in casing.



125LCR8TM44

(15) Assemble check valve (50) and spring (51) in order.

※ Do not confuse check valve (50) and restrictor (34).


※ Do not confuse spring (51) and spring (35)



125LCR8TM45

(16) Clamp plug (52) using 5 mm hexagon wrench.

※ Tightening torque : 1.5 kgf · m (10.9 lbf · ft)




125LCR8TM46

(17) Assemble restrictor (34) and spring (35) in order.

※ Do not confuse check valve (50) and restrictor (34).

※ Do not confuse spring (51) and spring (35).



125LCR8TM47

(18) Clamp plug (52).

※ Tightening torque : 1.5 kgf · m (10.9 lbf · ft)



125LCR8TM48



(19) Clamp plug (54).

※ Tightening torque : 3 kgf · m (21.7 lbf · ft)




125LCR8TM49

(20) Assemble restrictor (55) and (56) in rear cover.

※ Check whether the restrictor is placed in exact hole.

※ Do not confuse (55) and (56).



125LCR8TM50

(21) Assemble ball bearing (8) in rear cover using jig.



125LCR8TM51

(22) Insert spring pin (25) (2ea) and (28) in rear cover using jig.



125LCR8TM52

(23) After spreading grease sufficiently to the bottom side of valve plate (24), assemble valve plate in rear cover by matching its holes with pins.

- ※ Take care not to damage sliding surface.
- ※ Pay attention to the assembly direction.



125LCR8TM53

(24) Assemble O-ring (27) in rear cover.

- ※ Spread grease on O-ring.



125LCR8TM54


(25) Put rear cover upon casing, paying attention to the location of pin and hole. And tighten bolt (47), (48) and (49).

- ※ Tightening torque : 17.5 kgf · m (127 lbf · ft)
- ※ Make sure valve plate stays in place.
- ※ Check bolt position.



125LCR8TM55

(26) Assemble main spool assembly (31), spring seat (37) and spring (33) in rear cover.



125LCR8TM56

(27) Settle cover (32).


※ Tightening torque : 15 kgf · m (108 lbf · ft)



125LCR8TM57

(28) Insert relief valve (38) in rear cover.


※ Tightening torque : 15 kgf · m (108 lbf · ft)



125LCR8TM58


(29) After clamping connector (45) to rear cover, assemble spool (40).

※ Tightening torque : 5 kgf · m (36 lbf · ft)



125LCR8TM59

(30) After inserting parallel pin (43), assemble seat-spring (42).




125LCR8TM60



(31) After assembling spring (44) in order, clamp plug (41).

※ Tightening torque : 5 kgf · m (36 lbf · ft)



125LCR8TM61

### 3. TRAVEL REDUCTION GEAR DISASSEMBLY

1) While travel reduction gear is tilted to one side disassemble PF3/8 plug (24), remove gear oil and place motor side to the bench.



125LCR8TM70

2) Disassemble cover (22) by unscrewing the M10 bolts (23) (12 pcs).



125LCR8TM71

3) Disassemble sun gear No.1 (20) and steel ball (21).



125LCR8TM72

4) Disassemble carrier No.1 assembly.



125LCR8TM73

### Carrier No. 1 sub assy disassembly

- 5) Disassemble M8 bolt (18) from the carrier assembly. (3 pcs)



125LCR8TM74

- 6) Disassemble thrust plate No.1 (17) from the carrier assembly.



125LCR8TM75

- 7) Disassemble planetary gear No.1 (14).(3 pcs)



125LCR8TM76

- 8) Disassemble needle bearing (15).(3 pcs)  
※ Do not disassemble inner race in the absence of abnormalities.



125LCR8TM77

9) Disassemble sun gear No.2 (12).



125LCR8TM78

10) Disassemble M10 bolt (6).(4 pcs)



125LCR8TM79

11) Disassemble thrust washer No.2 (11).(4 pcs)



125LCR8TM80

12) Disassemble planetary gear No.2 (8).(4 pcs)



125LCR8TM81



13) Disassemble needle bearing No.2 (9).(4 pcs)



125LCR8TM82

14) Disassemble thrust plate No.2 (7).(4 pcs)

※ Do not disassemble inner race in the absence of abnormalities.



125LCR8TM83

15) Disassemble M10 bolt (6) and M8 screw bolt (19).



125LCR8TM84

16) Disassemble lock plate (5).



125LCR8TM85

17) Disassemble nut ring (4) by using the jig.



125LCR8TM86

18) Disassemble ring gear sub assembly from motor assembly.



125LCR8TM87


19) Disassemble rotating seal assembly (3) from ring gear sub assembly and motor assembly.



125LCR8TM88

20) Disassemble bearing (2) (2EA) from ring gear assembly.

※ Do not disassemble bearing in the absence of abnormalities.



125LCR8TM89



#### 4. TRAVEL REDUCTION GEAR ASSEMBLY

※ Even though assembly is accomplished by reversing disassembly steps, be careful of the following.

- ① Repair the damaged part when disassembling and prepare parts for exchange in advance.
- ② All parts should be cleaned with cleaner, dried with compressed air.
- ③ Sliding surface, O-ring, bearing and oil seal should be lubricated with clean hydraulic oil, prior to final assembly.
- ④ Replacement of O-ring and oil seal with new parts is generally recommended.
- ⑤ Use a torque wrench to make sure that assembly fasteners are tightened to specified values.
- ⑥ When assembling bolt, spread loctite.

1) Put carrier No.1 (13) on the jig, and shrink-fit inner race No.1 (16) to carrier pin.(3 places)

※ Do not tilt inner race to one side.

※ Match inner race and end of carrier pin.



125LCR8TM90

2) Assemble needle bearing No.1 (15).(3 pcs)



125LCR8TM91

3) Assemble planetary gear No.1 (14) of which groove is faced downward. (3 places)



125LCR8TM92

4) Assemble thrust plate No.1 (17).



125LCR8TM93

5) After spreading loctite #242, assemble the M8 bolt (18).(3 pcs)

※ Tightening torque :  $2.7 \pm 0.3 \text{ kgf} \cdot \text{m}$   
( $19.5 \pm 2.2 \text{ lbf} \cdot \text{ft}$ )

※ After the assembly, instantly check the noise and interference by rotatong the gear.



125LCR8TM94

6) First, place bearing (2) on the ring gear (1), then put jig on it, then press it with press machine.



125LCR8TM95

- 7) After turning ring gear over, assemble bearing the same way.  
※ Be care of nick and safety when turn ring gear over.



125LCR8TM96

- 8) Assemble floating seal assembly (3) by using the jig.  
※ After assembling, wipe steel-lined section with alcohol.  
※ Flatness deviation has to be less than 1 mm.



125LCR8TM97

- 9) Place floating seal assembly on the motor assembly, then assemble it.  
※ After assembling, wipe steel-lined section with alcohol.  
※ Flatness deviation has to be less than 1 mm.



125LCR8TM98

- 10) After arriving safely ring gear sub assembly in the motor assembly, press it with press machine.  
※ After press-fitting, clamp ring gear to fix it.  
※ When using the press pay attention to bearing damage.



125LCR8TM99

11) After assembling nut ring (4) by using the jig, disassemble the clamping.

※ Tightening torque : 60 kgf · m (434 lbf · ft)



125LCR8TM100

12) Place lock plate (5) on the nut ring groove.

※ Select best position from one of 4 casing hole to assemble lock plate.



125LCR8TM101

13) Place lock plate in the direction which nut ring is loosened and then assemble M10 bolt (6) with M8 screw (19) after spreading loctite #242.(Refer to assembly detail drawing)

※ Tightening torque (M10) :  $5.5 \pm 0.6$  kgf · m  
( $39.8 \pm 4.3$  lbf · ft)


※ Tightening torque (M8) :  $2.7 \pm 0.3$  kgf · m  
( $19.5 \pm 2.2$  lbf · ft)

※ Make sure that M8 bolt doesn't stick out of lock plate.



125LCR8TM102

※ Assembly detail drawing lock plate.



125LCR8TM103



14) Shrink fit the inner race No.2 (10).(4 pcs)



125LCR8TM104

15) Assemble thrust plate No.2 (7).(4 pcs)



125LCR8TM105

16) Assemble needle bearing No.2 (9).(4 pcs)



125LCR8TM106

17) Assemble planetary gear No.2 (8).(4 pcs)  
※ Grooves of planetary gear will be facing up.



125LCR8TM107



18) Assemble thrust washer No.2 (11).(4 pcs)



125LCR8TM108

19) After spreading loctite #242, assemble the M10 bolt (6).(4 pcs)

※ Tightening torque :  $5.5 \pm 0.6 \text{ kgf} \cdot \text{m}$   
( $39.8 \pm 4.3 \text{ lbf} \cdot \text{ft}$ )



125LCR8TM109

20) Assemble sun gear No.2 (12).



125LCR8TM110

21) Assemble carrier No.1 assembly.



125LCR8TM111

22) Assemble sun gear No.1 (20).




125LCR8TM112

23) Place steel ball (21) on the sun gear No.1.



125LCR8TM113

24) Spread the loctite #515 on the cover (22) with reference to the right detail view.



125LCR8TM114

25) Place cover (22) to fit the bolt holes.



125LCR8TM115

26) After spreading loctite #242, assemble the M10 bolt (23).(12 pcs)

※ Tightening torque :  $6.3 \pm 0.7 \text{ kgf} \cdot \text{m}$   
( $45.6 \pm 5.1 \text{ lbf} \cdot \text{ft}$ )



125LCR8TM116

27) Inject the  $2.5 \pm 0.3$  liter gear oil to PF3/8 tap section.



125LCR8TM117

28) After assembling the O-ring (25) to the plug (24), assemble it to the cover.(3 pcs)

※ Tightening torque :  $5 \pm 0.5 \text{ kgf} \cdot \text{m}$   
( $36.2 \pm 3.6 \text{ lbf} \cdot \text{ft}$ )



125LCR8TM118

## GROUP 7 RCV LEVER


### 1. REMOVAL AND INSTALL

#### 1) REMOVAL

- (1) Lower the work equipment to the ground and stop the engine.
- (2) Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping.
- (3) Loosen the breather slowly to release the pressure inside the hydraulic tank.

**▲ Escaping fluid under pressure can penetrate the skin causing serious injury.**

- (4) Loosen the socket bolt (1).
  - (5) Remove the cover of the console box.
  - (6) Disconnect pilot line hoses (3).
  - (7) Remove the pilot valve assembly (2).
- ※ When removing the pilot valve assembly, check that all the hoses have been disconnected.




#### 2) INSTALL

- (1) Carry out installation in the reverse order to removal.
- (2) Confirm the hydraulic oil level and check the hydraulic oil leak or not.

## 2. DISASSEMBLY AND ASSEMBLY

### 1) STRUCTURE




1409S2RL02

1	Case	8	Stopper	15	O-ring	22	Lock nut
2	Plug	9	Push rod	16	Rod seal	23	Handle assembly
3	Bushing	10	Spring	17	Plate	24	Handle bar
4	Spool	11	Push rod	18	Boot	25	Nut
5	Shim	12	Spring	19	Joint assembly	26	Boot
6	Spring	13	Spring seat	20	Swash plate	27	Spring pin
7	Spring seat	14	Plug	21	Adjusting nut	28	Bushing



## 2) TOOLS AND TIGHTENING TORQUE

### (1) Tools


Tool name	Remark	
Allen wrench	6	
Spanner	22	
	27	
(+) Driver	Length 150	
(-) Driver	Width 4~5	
Torque wrench	Capable of tightening with the specified torques	

### (2) Tightening torque


Part name	Item	Size	Torque	
			kgf · m	lbf · ft
Plug	2	PT 1/8	3.0	21.7
Joint	19	M14	3.5	25.3
Swash plate	20	M14	5.0±0.35	36.2±2.5
Adjusting nut	21	M14	5.0±0.35	36.2±2.5
Lock nut	22	M14	5.0±0.35	36.2±2.5

### 3) DISASSEMBLY


- (1) Clean pilot valve with kerosene.
  - ※ Put blind plugs into all ports
- (2) Fix pilot valve in a vise with copper (or lead) sheets.
- (3) Remove end of boot (26) from case (1) and take it out upwards.




- ※ For valve with switch, remove cord also through hole of casing.





- (4) Loosen lock nut (22) and adjusting nut (21) with spanners on them respectively, and take out handle section as one body.



- (5) Remove the boot (18).





- (6) Loosen adjusting nut (21) and swash plate (20) with spanners on them respectively, and remove them.




- (7) Turn joint anticlockwise to loosen it, utilizing jig (special tool).

- ※ When return spring (10) is strong in force, plate (17), plug (14) and push rod (11) will come up on loosening joint. Pay attention to this.




(8) Remove plate (17).




(9) When return spring (10) is weak in force, plug (14) stays in casing because of sliding resistance of O-ring.

- ※ Take it out with minus screwdriver. Take it out, utilizing external periphery groove of plug and paying attention not to damage it by partial loading.
- ※ During taking out, plug may jump up due to return spring (10) force. Pay attention to this.




(10) Remove reducing valve subassembly and return spring (10) out of casing.

- ※ Record relative position of reducing valve subassembly and return springs.




(11) Loosen hexagon socket head plug (2) with hexagon socket screw key.




(12) For disassembling reducing valve section, stand it vertically with spool (4) bottom placed on flat workbench. Push down spring seat (7) and remove two pieces of semicircular stopper (8) with tip of small minus screwdriver.

- ※ Pay attention not to damage spool surface.
- ※ Record original position of spring seat (7).
- ※ Do not push down spring seat more than 6mm.




(13) Separate spool (4), spring seat (7), spring (6) and shim (5) individually.

- ※ Until being assembled, they should be handled as one subassembly group.




(14) Take push rod (11) out of plug (14).




(15) Remove O-ring (15) and rod seal (16) from plug (14).



Use small minus screwdriver or so on to remove this seal.







(16) Remove lock nut (22) and then boot (26).



### **(16) Cleaning of parts**

- ① Put all parts in rough cleaning vessel filled with kerosene and clean them (rough cleaning).
  - ※ If dirty part is cleaned with kerosene just after putting it in vessel, it may be damaged. Leave it in kerosene for a while to loosen dust and dirty oil.
  - ※ If this kerosene is polluted, parts will be damaged and functions of reassembled valve will be degraded.  
Therefore, control cleanliness of kerosene fully.
- ② Put parts in final cleaning vessel filled with kerosene, turning it slowly to clean them even to their insides (finish cleaning).
  - ※ Do not dry parts with compressed air, since they will be damaged and/or rusted by dust and moisture in air.


### **(17) Rust prevention of parts**

- Apply rust-preventives to all parts.
- ※ If left as they are after being cleaned, they will be rusted and will not display their functions fully after being reassembled.


#### 4) ASSEMBLY

(1) Tighten hexagon socket head plug (2) to the specified torque.

※ Tighten two bolts alternately and slowly.




(2) Put shim (5), springs (6) and spring seat (7) onto spool (4) in this order.




(3) Stand spool vertically with its bottom placed on flat workbench, and with spring seat pushed down, put two pieces of semicircular stopper (8) on spring seat without piling them on.

※ Assemble stopper (8) so that its sharp edge side will be caught by head of spool. Do not push down spring seat more than 6mm.




(4) Assemble spring (10) into casing (1). Assemble reducing valve subassembly into casing.

※ Assemble them to their original positions.




(5) Assemble O-ring (15) onto plug (14).




(6) Assemble rod seal (16) to plug (14).

※ Assemble seal in such lip direction as shown below.




(7) Assemble push rod (11) to plug (14).

※ Apply working oil on push-rod surface.




(8) Assemble plug subassembly to casing.

※ When return spring is weak in force, subassembly stops due to resistance of O-ring.




(9) When return spring is strong in force, assemble 4 sets at the same time, utilizing plate (17), and tighten joint (19) temporarily.




(10) Fit plate (17).

(11) Tighten joint (19) with the specified torque to casing, utilizing jig.




(12) Assemble swash plate (20) to joint (19).

- ※ Screw it to position that it contacts with 4 push rods evenly.
- ※ Do not screw it over.




(13) Assemble adjusting nut (21), apply spanner to width across flat of plate (20) to fix it, and tighten adjusting nut to the specified torque.

- ※ During tightening, do not change position of disk.








(14) Fit boot (18) to plate.




(15) Fit boot (26) and lock nut (22), and handle subassembly is assembled completely.




(16) Pull out cord and tube through adjusting nut hole provided in direction 60° to 120° from casing hole.




- (17) Assemble bushing (28) to plate and pass cord and tube through it.  
※ Provide margin necessary to operation.




- (18) Determine handle direction, tighten lock nut (22) to specified torque to fix handle.



- (19) Apply grease to rotating section of joint and contacting faces of disk and push rod.



- (20) Assemble lower end of bellows to casing.  
(21) Inject volatile rust-preventives through all ports and then put blind plugs in ports.



## GROUP 8 TURNING JOINT

### 1. REMOVAL AND INSTALL

#### 1) REMOVAL

- (1) Lower the work equipment to the ground and stop the engine.
- (2) Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping.
- (3) Loosen the breather slowly to release the pressure inside the hydraulic tank.

**▲ Escaping fluid under pressure can penetrate the skin causing serious injury.**



※ When pipes and hoses are disconnected, the oil inside the piping will flow out, so catch it in oil pan.

- (4) Disconnect all hoses.
- (5) Sling the turning joint assembly (1) and remove the mounting bolt (2).
  - Weight : 50 kg (110 lb)
  - Tightening torque :  $12.3 \pm 1.3 \text{ kgf} \cdot \text{m}$   
( $88.9 \pm 9.4 \text{ lbf} \cdot \text{ft}$ )
- (6) Remove the turning joint assembly.

※ When removing the turning joint, check that all the hoses have been disconnected.


#### 2) INSTALL

- (1) Carry out installation in the reverse order to removal.
  - ※ Take care of turning joint direction.
  - ※ Assemble hoses to their original positions.
  - ※ Confirm the hydraulic oil level and check the hydraulic oil leak or not.



## 2. DISASSEMBLY AND ASSEMBLY

### 1) STRUCTURE




14098TJ03

- |   |        |    |              |    |               |
|---|--------|----|--------------|----|---------------|
| 1 | Hub    | 6  | Shim         | 11 | Wear ring     |
| 2 | Shaft  | 7  | Slipper seal | 12 | Retainer ring |
| 3 | Cover  | 8  | O-ring       | 13 | Plug          |
| 4 | Spacer | 9  | O-ring       | 14 | Hexagon bolt  |
| 5 | Shim   | 10 | O-ring       | 15 | Spring washer |

## 2) DISASSEMBLY


※ Before the disassembly, clean the turning joint.

- (1) Remove bolts (14), washer (15) and cover (3).



- (2) Remove shim (6) and O-ring (10).


- (3) Remove retainer ring (12), spacer (4) and shim (5).




- (4) Place hub (1) on a V-block and by using a wood buffer at the shaft end, hit out shaft (2) to about 1/2 from the body with a hammer.

※ Take care not to damage the shaft (2) when remove hub (1) or rest it sideways.

※ Put a fitting mark on hub (1) and shaft (2).



- (5) Remove six slipper seals (7) and O-ring (9), two wear ring (11) from hub (1).




### 3) ASSEMBLY


- ※ Clean all parts.
- ※ As a general rule, replace oil seals and O-ring.
- ※ Coat the sliding surfaces of all parts with engine oil or grease before installing.

(1) Fix seven slipper seal (7) and O-ring (9), two wear ring (11) to hub (1).

(2) Fit O-ring (8) to shaft (2).




(3) Set shaft (2) on block, tap hub (1) with a plastic hammer to install.



(4) Fit shim (5), spacer (4) and retainer ring (12) to shaft (2).


(5) Fit O-ring (10) to hub (1).

(6) Fit shim (6) to shaft (2).





- (7) Install cover (3) to body (1) and tighten bolts (14).
- Torque : 10~12.5 kgf · m  
(72.3~90.4 lbf · ft)



## GROUP 9 BOOM, ARM AND BUCKET CYLINDERS

### 1. REMOVAL AND INSTALL

#### 1) BUCKET CYLINDER


##### (1) Removal

- ※ Expand the arm and bucket fully, lower the work equipment to the ground and stop the engine.
- ※ Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping.
- ※ Loosen the breather slowly to release the pressure inside the hydraulic tank.

**▲ Escaping fluid under pressure can penetrate the skin causing serious injury.**


- ※ Fit blind plugs in the hoses after disconnecting them, to prevent dirt or dust from entering.

① Set block between bucket cylinder and arm.




② Remove bolt (2), nut (3) and pull out pin (1).


- ※ Tie the rod with wire to prevent it from coming out.



③ Disconnect bucket cylinder hoses (4) and put plugs (5) on cylinder pipe.



- ④ Sling bucket cylinder assembly (8) and remove bolt (6) then pull out pin (5).
- ⑤ Remove bucket cylinder assembly (8).
  - Weight : 78 kg (172 lb)



## (2) Install

- ① Carry out installation in the reverse order to removal.
- ▲ When aligning the mounting position of the pin, do not insert your fingers in the pin hole.**
- ※ Bleed the air from the bucket cylinder.
  - ※ Confirm the hydraulic oil level and check the hydraulic oil leak or not.


## 2) ARM CYLINDER

### (1) Removal

- ※ Expand the arm and bucket fully, lower the work equipment to the ground and stop the engine.
- ※ Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping.
- ※ Loosen the breather slowly to release the pressure inside the hydraulic tank.


**▲ Escaping fluid under pressure can penetrate the skin causing serious injury. Fit blind plugs in the hoses after disconnecting them, to prevent dirt or dust from entering.**

- ① Set block between arm cylinder and boom.




- ② Remove bolt (2) and pull out pin (1).

- ※ Tie the rod with wire to prevent it from coming out.




- ③ Disconnect arm cylinder hoses (4) and put plugs on cylinder pipe.

- ④ Disconnect greasing pipings (5).



- ⑤ Sling arm cylinder assembly(8) and remove bolt (7) then pull out pin (6).
- ⑥ Remove arm cylinder assembly (8).
  - Weight : 118 kg (260 lb)



## (2) Install

- ① Carry out installation in the reverse order to removal.
- ▲ When aligning the mounting position of the pin, do not insert your fingers in the pin hole.**
- ※ Bleed the air from the arm cylinder.
  - ※ Confirm the hydraulic oil level and check the hydraulic oil leak or not.


### 3) BOOM CYLINDER

#### (1) Removal


- ※ Expand the arm and bucket fully, lower the work equipment to the ground and stop the engine.
- ※ Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping.
- ※ Loosen the breather slowly to release the pressure inside the hydraulic tank.

**▲ Escaping fluid under pressure can penetrate the skin causing serious injury.**


- ※ Fit blind plugs in the hoses after disconnecting them, to prevent dirt or dust from entering.
- ① Disconnect greasing hoses (1).
  - ② Sling boom cylinder assembly.



- ③ Remove bolt (4), stopper (5) and pull out pin (2).
- ※ Tie the rod with wire to prevent it from coming out.




- ④ Lower the boom cylinder assembly (6) on a stand.






- ⑤ Disconnect boom cylinder hoses (7) and put plugs on cylinder pipe.



- ⑥ Remove bolt (9) and pull out pin (8).  
⑦ Remove boom cylinder assembly (6).  
· Weight : 96 kg (212 lb)




## (2) Install

- ① Carry out installation in the reverse order to removal.
- ▲ When aligning the mounting position of the pin, do not insert your fingers in the pin hole.**
- ※ Bleed the air from the boom cylinder.
  - ※ Confirmed the hydraulic oil level and check the hydraulic oil leak or not.

## 2. DISASSEMBLY AND ASSEMBLY

### 1) STRUCTURE


#### (1) Bucket cylinder



125LCR8CY01

- |    |                |    |                     |    |                     |
|----|----------------|----|---------------------|----|---------------------|
| 1  | Tube assembly  | 15 | O-ring              | 29 | O-ring              |
| 2  | Pin bushing    | 16 | Cushion ring        | 30 | Pipe assembly       |
| 3  | Rod assembly   | 17 | Piston              | 31 | Spring washer       |
| 4  | Pin bushing    | 18 | Piston seal         | 32 | Hexagon socket bolt |
| 5  | Rod cover      | 19 | Wear ring           | 33 | O-ring              |
| 6  | Rod bushing    | 20 | Dust ring           | 34 | Pipe assembly       |
| 7  | Retaining ring | 21 | O-ring              | 35 | Spring washer       |
| 8  | Buffer seal    | 22 | Back up ring        | 36 | Hexagon socket bolt |
| 9  | U-packing      | 23 | Set screw           | 37 | Clamp               |
| 10 | Back up ring   | 24 | Hexagon socket bolt | 38 | Spring washer       |
| 11 | Dust wiper     | 25 | Pipe band assembly  | 39 | Hexagon bolt        |
| 12 | Retaining ring | 26 | Pipe band           | 40 | Pin wiper           |
| 13 | O-ring         | 27 | Spring washer       | 41 | Grease nipple       |
| 14 | Back up ring   | 28 | Hexagon bolt        | 42 | O-ring              |


## (2) Arm cylinder



125LCR8CY02

- |    |                |    |                     |    |                     |
|----|----------------|----|---------------------|----|---------------------|
| 1  | Tube assembly  | 16 | Cushion ring        | 31 | O-ring              |
| 2  | Pin bushing    | 17 | Piston              | 32 | Plug                |
| 3  | Rod assembly   | 18 | Piston seal         | 33 | Pipe band assembly  |
| 4  | Pin bushing    | 19 | Wear ring           | 34 | Pipe band           |
| 5  | Rod cover      | 20 | Dust ring           | 35 | Spring washer       |
| 6  | Rod bushing    | 21 | O-ring              | 36 | Hexagon bolt        |
| 7  | Retaining ring | 22 | Back up ring        | 37 | Pipe assembly       |
| 8  | Buffer seal    | 23 | Piston nut          | 38 | O-ring              |
| 9  | U-packing      | 24 | Set screw           | 39 | Spring washer       |
| 10 | Back up ring   | 25 | Cushion plunger     | 40 | Hexagon socket bolt |
| 11 | Dust wiper     | 26 | Stop ring           | 41 | Clamp               |
| 12 | Retaining ring | 27 | Hexagon socket bolt | 42 | Spring washer       |
| 13 | O-ring         | 28 | Check               | 43 | Hexagon bolt        |
| 14 | Back up ring   | 29 | Spring              | 44 | Pin wiper           |
| 15 | O-ring         | 30 | Bracket             | 45 | O-ring              |


(3) Boom cylinder



125LCR8CY03

- |    |                |    |                     |    |                     |
|----|----------------|----|---------------------|----|---------------------|
| 1  | Tube assembly  | 16 | Cushion ring        | 31 | O-ring              |
| 2  | Pin bushing    | 17 | Piston              | 32 | Spring washer       |
| 3  | Rod assembly   | 18 | Piston seal         | 33 | Hexagon socket bolt |
| 4  | Pin bushing    | 19 | Wear ring           | 34 | Pipe assembly       |
| 5  | Rod cover      | 20 | Dust ring           | 35 | O-ring              |
| 6  | Rod bushing    | 21 | O-ring              | 36 | Spring washer       |
| 7  | Retaining ring | 22 | Back up ring        | 37 | Hexagon socket bolt |
| 8  | Buffer seal    | 23 | Piston nut          | 38 | Hexagon nut         |
| 9  | U-packing      | 24 | Set screw           | 39 | Clamp               |
| 10 | Back up ring   | 25 | Hexagon socket bolt | 40 | Spring washer       |
| 11 | Dust wiper     | 26 | Pipe band assembly  | 41 | Hexagon bolt        |
| 12 | Retaining ring | 27 | Pipe band           | 42 | Pin wiper           |
| 13 | O-ring         | 28 | Spring washer       | 43 | O-ring              |
| 14 | Back up ring   | 29 | Hexagon bolt        |    |                     |
| 15 | O-ring         | 30 | Pipe assembly       |    |                     |

#### (4) Dozer cylinder




125LCR8CY05

- |    |                |    |                |    |                     |
|----|----------------|----|----------------|----|---------------------|
| 1  | Tube assembly  | 12 | Retaining ring | 23 | Hexagon socket bolt |
| 2  | Pin bushing    | 13 | O-ring         | 24 | Check valve         |
| 3  | Rod assembly   | 14 | Back up ring   | 25 | Hexagon socket bolt |
| 4  | Pin bushing    | 15 | O-ring         | 26 | Pipe assembly       |
| 5  | Rod cover      | 16 | Piston         | 27 | O-ring              |
| 6  | Rod bushing    | 17 | Piston seal    | 28 | Spring washer       |
| 7  | Retaining ring | 18 | Wear ring      | 29 | Hexagon socket bolt |
| 8  | Buffer seal    | 19 | Dust ring      | 30 | Pin wiper           |
| 9  | U-packing      | 20 | O-ring         | 31 | Grease nipple       |
| 10 | Back up ring   | 21 | Back up ring   |    |                     |
| 11 | Dust wiper     | 22 | Set screw      |    |                     |

## 2) TOOLS AND TIGHTENING TORQUE

### (1) Tools

Tool name	Remark		
Allen wrench	6		
	8		
	14		
	17		
Spanner	7		
	8		
(-) Driver	Small and large sizes		
Torque wrench	Capable of tightening with the specified torques		

### (2) Tightening torque

Part name	Item	Size	Torque		
			kgf · m	lbf · ft	
Socket head bolt	Bucket cylinder	24	M14	23.5 ± 0.5	170 ± 3.6
	Boom cylinder	25	M14	23.5 ± 0.5	170 ± 3.6
	Arm cylinder	27	M14	23.5 ± 0.5	170 ± 3.6
	Dozer cylinder	29	M8	3.25 ± 0.25	23.5 ± 1.8
		23	M14	23.5 ± 0.5	170 ± 3.6
Pipe mounting socket head bolt	Bucket cylinder	32, 36	M10	5.75 ± 0.25	41.6 ± 1.8
	Boom cylinder	33, 37	M8	3.25 ± 0.25	23.5 ± 1.8
	Arm cylinder	40	M10	5.75 ± 0.25	41.6 ± 1.8
Piston nut	Boom cylinder	23	M48	130 ± 13	940 ± 94
	Arm cylinder	23	M55	130 ± 13	940 ± 94
Piston	Bucket cylinder	17	M48	130 ± 13	940 ± 94
	Boom cylinder	17	M60	75 ± 7.5	542 ± 54.2
	Arm cylinder	17	M65	75 ± 7.5	542 ± 54.2
	Dozer cylinder - Rear	16	M58	130 ± 13	940 ± 94



### 3) DISASSEMBLY


#### (1) Remove cylinder head and piston rod

※ Procedures are based on the boom cylinder.

① Hold the clevis section of the tube in a vise.


※ Use mouth pieces so as not to damage the machined surface of the cylinder tube. Do not make use of the outside piping as a locking means.

② Pull out rod assembly (3) about 200 mm (7.1in). Because the rod assembly is rather heavy, finish extending it with air pressure after the oil draining operation.




③ Loosen and remove socket bolts (25) of the gland in sequence.

※ Cover the extracted rod assembly (3) with rag to prevent it from being accidentally damaged during operation.




④ Draw out cylinder head and rod assembly together from tube assembly (1).

※ Since the rod assembly is heavy in this case, lift the tip of the rod assembly (3) with a crane or some means and draw it out. However, when rod assembly (3) has been drawn out to approximately two thirds of its length, lift it in its center to draw it completely.




Note that the plated surface of rod assembly (3) is to be lifted. For this reason, do not use a wire sling and others that may damage it, but use a strong cloth belt or a rope.

- ⑤ Place the removed rod assembly on a wooden V-block that is set level.
- ※ Cover a V-block with soft rag.




## (2) Remove piston and cylinder head

- ① Remove set screw (24) and piston nut (23).
- ※ Since set screw (24) and piston nut (23) is tightened to a high torque, use a hydraulic and power wrench that utilizes a hydraulic cylinder, to remove the lock set screw (24) and piston nut (23).
- ② Remove piston assembly (17), back up ring (22), and O-ring (21).




- ③ Remove the cylinder head assembly from rod assembly (3).
  - ※ If it is too heavy to move, move it by striking the flanged part of cylinder head with a plastic hammer.
  - ※ Pull it straight with cylinder head assembly lifted with a crane.
- Exercise care so as not to damage the lip of pin bushing (4) and packing (8,9,10,11,12) by the threads of rod assembly (3).




### (3) Disassemble the piston assembly

- ① Remove wear ring (19).
  - ② Remove dust ring (20) and piston seal (18).
- ※ Exercise care in this operation not to damage the grooves.



### (4) Disassemble cylinder head assembly

- ① Remove back up ring (14) and O-ring (13).
  - ② Remove retaining ring (12), dust wiper (11).
  - ③ (11).  
Remove back up ring (10), U-packing (9) and buffer seal (8).
- ※ Exercise care in this operation not to damage the grooves.  
Do not remove seal and ring, if does not  
※ damaged.  
Do not remove bushing (6).




### 3) ASSEMBLY

#### (1) Assemble cylinder head assembly

※ Check for scratches or rough surfaces if found smooth with an oil stone.


- ① Coat the inner face of rod cover (5) with hydraulic oil.



- ② Coat dust wiper (11) with grease and fit dust wiper (11) to the bottom of the hole of dust seal.

At this time, press a pad metal to the metal ring of dust seal.


- ③ Fit retaining ring (12) to the stop face.



- ④ Fit back up ring (10), U-packing (9) and buffer seal (8) to corresponding grooves, in that order.


※ Coat each packing with hydraulic oil before fitting it.

※ Insert the backup ring until one side of it is inserted into groove.




※ U-packing (9) has its own fitting direction. Therefore, confirm it before fitting them.

※ Fitting U-packing (9) upside down may damage its lip. Therefore check the correct direction that is shown in fig.




- ⑤ Fit back up ring (14) to rod cover (5).
- ※ Put the backup ring in the warm water of 30~50°C.
- ⑥ Fit O-ring (13) to rod cover (5).




## (2) Assemble piston assembly


- ※ Check for scratches or rough surfaces. If found smooth with an oil stone.
- ① Coat the outer face of piston (17) with hydraulic oil.



- ② Fit piston seal (18) to piston.
- ※ Put the piston seal in the warm water of 60~100°C for more than 5 minutes.
- ※ After assembling the piston seal, press its outer diameter to fit in.




- ③ Fit wear ring (19) and dust ring (20) to piston (17).




**(3) Install piston and cylinder head**

- ① Fix the rod assembly to the work bench.
- ② Apply hydraulic oil to the outer surface of rod assembly (3), the inner surface of piston and cylinder head.
- ③ Insert cylinder head assembly to rod assembly.




- ④ Insert cushion ring (16) to rod assembly.
- ※ Note that cushion ring (16) has a direction in which it should be fitted.




- ⑤ Fit piston assembly to rod assembly.
- Tightening torque :

Item		kgf · m	lbf · ft
17	Bucket	130 ± 13	940 ± 94
	Boom	75 ± 7.5	542 ± 54.2
	Arm	75 ± 7.5	542 ± 54.2



- ⑥ Fit piston nut (23) and tighten the set screw (24).
- Tightening torque :



Item		kgf · m	lbf · ft
23	Boom	130 ± 13	940 ± 94
	Arm		
24		1.5	10.8





### (3) Overall assemble

- ① Place a V-block on a rigid work bench.  
Mount the tube assembly (1) on it and fix the assembly by passing a bar through the clevis pin hole to lock the assembly.
- ② Insert the rod assembly in to the tube assembly, while lifting and moving the rod assembly with a crane.
  - ※ Be careful not to damage piston seal by thread of tube assembly.
- ③ Match the bolt holes in the cylinder head flange to the tapped holes in the tube assembly and tighten socket bolts to a specified torque.
  - ※ Refer to the table of tightening torque.



## GROUP 10 UNDERCARRIAGE

### 1. TRACK LINK

#### 1) REMOVAL

(1) Move track link until master pin is over front idler in the position put wooden block as shown.

(2) Loosen tension of the track link.

※ If track tension is not relieved when the grease valve is loosened, move the machine backwards and forwards.

※ Unscrew the grease nipple after release the tension by pushing the poppet only when necessarily required.



Grease leaking hole is not existing. So, while unscrew the grease nipple, grease is not leaking until the grease nipple is completely coming out. If the tension is not released in advance, the grease nipple can be suddenly popped out by pressurized grease.

(3) Push out master pin by using a suitable tool.

(4) Move the machine slowly in reverse, and lay out track link assembly (1).

※ Jack up the machine and put wooden block under the machine.


※ Don't get close to the sprocket side as the track shoe plate may fall down on your feet.



#### 2) INSTALL

(1) Carry out installation in the reverse order to removal.


Adjust the tension of the track link.




## 2. CARRIER ROLLER

### 1) REMOVAL


- (1) Loosen tension of the track link.



- (2) Jack up the track link height enough to permit carrier roller removal.



- (3) Loosen the lock nut (1).
- (4) Open bracket(2) with a screwdriver, push out from inside, and remove carrier roller assembly.
  - Weight : 13 kg (29 lb)




### 2) INSTALL

- (1) Carry out installation in the reverse order to removal.


### 3. TRACK ROLLER

#### 1) REMOVAL


- (1) Loosen tension of the track link.



- (2) Using the work equipment, push up track frame on side which is to be removed.  
※ After jack up the machine, set a block under the unit.



- (3) Remove the mounting bolt (1) and draw out the track roller (2).  
· Weight : 24.6 kg (54.2 lb)




#### 2) INSTALL

- (1) Carry out installation in the reverse order to removal.


## 4. IDLER AND RECOIL SPRING

### 1) REMOVAL


- (1) Remove the track link.  
For detail, see removal of track link.



- (2) Sling the recoil spring (1) and pull out idler and recoil spring assembly from track frame, using a pry.
  - Weight : 215 kg (474 lb)




- (3) Remove the bolts (2), washers (3) and separate idler from recoil spring.




### 2) INSTALL

- (1) Carry out installation in the reverse order to removal.
  - ※ Make sure that the boss on the end face of the recoil cylinder rod is in the hole of the track frame.



### 3) DISASSEMBLY AND ASSEMBLY OF IDLER

#### (1) Structure



21078DA43

- 1 Shell
- 2 Shaft
- 3 Seal assembly


- 4 Bushing
- 5 Bracket
- 6 O-ring

- 7 Spring pin
- 8 Plug




**(2) Disassembly**


- ① Remove plug and drain oil.
- ② Draw out the spring pin (7), using a press.



- ③ Pull out the shaft (2) with a press.
- ④ Remove seal (3) from idler (1) and bracket (5).
- ⑤ Remove O-ring (6) from shaft.



- ⑥ Remove the bushing (4) from idler, using a special tool. Only remove bushing if replacement is necessary.




### (3) Assembly

- ※ Before assembly, clean the parts.
- ※ Coat the sliding surfaces of all parts with oil.


① Cool up bushing (4) fully by some dry ice and press it into shell (1).

Do not press it at the normal temperature, or not knock in with a hammer even after the cooling.




② Coat O-ring (6) with grease thinly, and install it to shaft (2).


③ Insert shaft (2) into bracket (5) and drive in the spring pin (7).




④ Install seal (3) to shell (1) and bracket (5).




⑤ Install shaft (2) to shell (1).




⑥ Install bracket (5) attached with seal (3).



⑦ Knock in the spring pin (7) with a hammer.




⑧ Lay bracket (5) on its side.  
Supply engine oil to the specified level,  
and tighten plug.



#### 4) DISASSEMBLY AND ASSEMBLY OF RECOIL SPRING

##### (1) Structure




R210UCG01

- |   |          |    |               |    |              |
|---|----------|----|---------------|----|--------------|
| 1 | Body     | 6  | Lock plate    | 11 | Dust seal    |
| 2 | Tie bar  | 7  | Bolt          | 12 | Rod assembly |
| 3 | Spring   | 8  | Spring washer | 13 | Grease valve |
| 4 | Bracket  | 9  | Rod seal      |    |              |
| 5 | Lock nut | 10 | Back up ring  |    |              |


## (2) Disassembly

- ① Apply pressure on spring (3) with a press.
  - ※ The spring is under a large installed load. This is dangerous, so be sure to set properly.
    - Spring set load : 8497 kg (18733 lb)
- ② Remove bolt (7), spring washer (8) and lock plate (6).
- ③ Remove lock nut (5).


Take enough notice so that the press which pushes down the spring, should not be slipped out in its operation.
- ④ Lighten the press load slowly and remove bracket (4) and spring (3).



- ⑤ Remove rod (12) from body (1).
- ⑥ Remove grease valve (13) from rod (12).




- ⑦ Remove rod seal (9), back up ring (10) and dust seal (11).



### (3) Assembly

Install dust seal (11), back up ring (10) and rod seal (9) to body (1).

- ※ When installing dust seal (11) and rod seal (9), take full care so as not to damage the lip.




- ② Pour grease into body (1), then push in rod (12) by hand.

After take grease out of grease valve mounting hole, let air out.

- ※ If air letting is not sufficient, it may be difficult to adjust the tension of crawler.

- ③ Fit grease valve (13) to rod (12).

·Tightening torque :  $13 \pm 1.0$  kgf·m  
( $94 \pm 7.2$  lbf·ft)




- ④ Install spring (3) and bracket (4) to body (1).

- ⑤ Apply pressure to spring (3) with a press and tighten lock nut (5).


- ※ Apply sealant before assembling.

- ※ During the operation, pay attention specially to prevent the press from slipping out.







- ⑥ Lighten the press load and confirm the set length of spring (3).
- ⑦ After the setting of spring (3), install lock plate (6), spring washer (8) and bolt (7).




# GROUP 11 WORK EQUIPMENT


## 1. STRUCTURE



SECTION A



SECTION B



SECTION C


21078DA44

## 2. REMOVAL AND INSTALL


### 1) BUCKET ASSEMBLY

#### (1) Removal


- ① Lower the work equipment completely to ground with back of bucket facing down.



- ② Remove nut (1), bolt (2) and draw out the pin (B).



- ③ Remove nut (3), bolt (4) and draw out the pin (A) then remove the bucket assembly.  
· Weight (0.40 m<sup>3</sup>) : 410 kg (910 lb)




#### (2) Install

- ① Carry out installation in the reverse order to removal.

**▲** When aligning the mounting position of the pin, do not insert your fingers in the pin hole.

※ Adjust the bucket clearance.  
For detail, see operation manual.



## 2) ARM ASSEMBLY

### (1) Removal

※ Loosen the breather slowly to release the pressure inside the hydraulic tank.

**▲ Escaping fluid under pressure can penetrate the skin causing serious injury.**

① Remove bucket assembly.

For details, see removal of bucket assembly.

② Disconnect bucket cylinder hose (1).

**▲ Fit blind plugs (5) in the piping at the chassis end securely to prevent oil from spurting out when the engine is started.**

③ Sling arm cylinder assembly, remove spring, pin stopper and pull out pin.

※ Tie the rod with wire to prevent it from coming out.




④ For details, see removal of arm cylinder assembly.

Place a wooden block under the cylinder and bring the cylinder down to it.

⑤ Remove bolt (2), plate (3) and pull out the pin (4) then remove the arm assembly.

· Weight (2.26 m) : 340 kg (750 lb)

※ When lifting the arm assembly, always lift the center of gravity.



### (2) Install

① Carry out installation in the reverse order to removal.


**▲ When lifting the arm assembly, always lift the center of gravity.**

※ Bleed the air from the cylinder.


### 3) BOOM CYLINDER

#### (1) Removal


- ① Remove arm and bucket assembly.  
For details, see removal of arm and bucket assembly.
- ② Remove boom cylinder assembly from boom.  
For details, see removal of arm cylinder assembly.



- ③ Disconnect head lamp wiring.
- ④ Disconnect bucket cylinder hose (2) and arm cylinder hose (1).
- ※ When the hose are disconnected, oil may spurt out.
- ⑤ Sling boom assembly (3).



- ⑥ Remove bolt (4), plate (5) and pull out the pin (6) then remove boom assembly.  
· Weight (4.30 m) : 710 kg (1570 lb)
- ※ When lifting the boom assembly always lift the center of gravity.



#### (2) Install

- ① Carry out installation in the reverse order to removal.

**▲ When lifting the arm assembly, always lift the center of gravity.**

- ※ Bleed the air from the cylinder.

