


SECTION 3 HYDRAULIC SYSTEM

Group 1 Hydraulic Circuit	3-1
Group 2 Main Circuit	3-2
Group 3 Pilot Circuit	3-5
Group 4 Single Operation	3-13
Group 5 Combined Operation	3-25

SECTION 3 HYDRAULIC SYSTEM

GROUP 1 HYDRAULIC CIRCUIT



- | | |
|----|--|
| 1 | Main pump |
| 2 | Main control valve |
| 3 | Swing motor |
| 4 | Travel motor |
| 5 | RCV lever(LH) |
| 6 | RCV lever(RH) |
| 7 | RCV pedal |
| 8 | Boom cylinder(LH) |
| 9 | Boom cylinder(RH) |
| 10 | Arm cylinder |
| 11 | Bucket cylinder |
| 12 | Turning joint |
| 13 | Check valve |
| 14 | Check valve |
| 15 | Hydraulic tank |
| 16 | Oil cooler |
| 17 | Air breather |
| 18 | Bypass valve |
| 19 | Strainer |
| 20 | Drain filter |
| 21 | 5 cartridge valve |
| 22 | Pressure sensor |
| 24 | Pressure sensor |
| 25 | Terminal block |
| 26 | Last guard filter |
| 28 | Shuttle valve(option) |
| 30 | Boom safety valve(option) |
| 31 | Arm safety valve(option) |
| 32 | RCV dozer lever(option) |
| 33 | EPPR valve(option) |
| 34 | Breaker pedal(option) |
| 35 | Accumulator(option) |
| 36 | Accumulator(option) |
| 37 | Stop valve(option) |
| 40 | Selector valve(option) |
| 41 | Solenoid valve(option) |
| 42 | Selector valve(option) |
| 47 | Quick clamp solenoid valve(option) |
| 49 | Pressure switch(option) |
| 50 | Adjust boom cylinder(option) |
| 51 | Adjust boom safety lock valve(option) |
| 52 | Port relief valve(option) |
| 53 | Dozer cylinder(option) |
| 54 | Double pressure check(opt, dozer) |
| 55 | Solenoid valve(option, dozer & adjust) |
| 56 | Selector valve(option, dozer & adjust) |
| 57 | Line filter |

1409SB3HC01