


# GROUP 6 MECHATRONICS SYSTEM BY HYPER DAT


## 1. ALL ACTUATORS SPEED ARE SLOW

- Before using the HYPER DAT make sure you understand the user's guide of HYPER DAT.
  - Before mounting or dismounting the HYPER DAT, always turn the starting switch OFF.
  - Before starting switch turn ON or OFF, check all related connectors are properly inserted.
- ※ Confirm the engine speed is normal. If not, fix the engine speed to each mode specification.

Spec : H-mode	2250 +50rpm	S-mode	2250 +50rpm
L-mode	2000 +50rpm	F-mode	1650 +50rpm



### Wiring diagram




## 2. CLUSTER LAMPS ARE OFF IMMEDIATELY AFTER KEY SWITCH OFF

- Before using the HYPER DAT make sure you understand the user's guide of HYPER DAT.
- Before mounting or dismounting the HYPER DAT, always turn the starting switch OFF.
- Before starting switch turn ON or OFF, check all related connectors are properly inserted.




### Wiring diagram




### 3. CLUSTER LAMPS ARE STILL ON AFTER STARTING KEY OFF

- Before using the HYPER DAT make sure you understand the user's guide of HYPER DAT.
- Before mounting or dismounting the HYPER DAT, always turn the starting switch OFF.
- Before starting switch turn ON or OFF, check all related connectors are properly inserted.




#### Wiring diagram




#### 4. CLUSTER LAMPS ARE NOT CHANGING OR FUNCTION IS ABNORMAL WHEN THE RELATED SWITCH ARE PUSHED

- Before using the HYPER DAT make sure you understand the user's guide of HYPER DAT.
- Before mounting or dismounting the HYPER DAT, always turn the starting switch OFF.
- Before starting switch turn ON or OFF, check all related connectors are properly inserted.




#### Wiring diagram




## 5. AUTO DECEL SYSTEM DOES NOT WORK

- Before using the HYPER DAT make sure you understand the user's guide of HYPER DAT.
- Before mounting or dismounting the HYPER DAT, always turn the starting switch OFF.
- Before starting switch turn ON or OFF, check all related connectors are properly inserted.




### Wiring diagram




## 6. ENGINE SPEED IS NOT CHANGING WHEN CHANGE THE MODE

- Before using the HYPER DAT make sure you understand the user's guide of HYPER DAT.
- Before mounting or dismounting the HYPER DAT, always turn the starting switch OFF.
- Before starting switch turn ON or OFF, check all related connectors are properly inserted.




### Wiring diagram

#### CPU CONTROLLER




## 7. MALFUNCTION OF POWER MAX

- Before using the HYPER DAT make sure you understand the user's guide of HYPER DAT.
- Before mounting or dismounting the HYPER DAT, always turn the starting switch OFF.
- Before starting switch turn ON or OFF, check all related connectors are properly inserted.




### Wiring diagram



## 8. EXCESSIVE DROP IN ENGINE SPEED OR ENGINE STALLS, WHEN A LOAD IS APPLIED

- Before using the HYPER DAT make sure you understand the user's guide of HYPER DAT.
- Before mounting or dismounting the HYPER DAT, always turn the starting switch OFF.
- Before starting switch turn ON or OFF, check all related connectors are properly inserted.



### Wiring diagram

