

GROUP 8 TURNING JOINT

1. REMOVAL AND INSTALL



1) REMOVAL

- (1) Lower the work equipment to the ground and stop the engine.
- (2) Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping.
- (3) Loosen the breather slowly to release the pressure inside the hydraulic tank.
⚠ Escaping fluid under pressure can penetrate the skin causing serious injury.
※ When pipes and hoses are disconnected, the oil inside the piping will flow out, so catch it in oil pan.
- (4) Disconnect all hoses .
- (5) Sling the turning joint assembly(1) and remove the mounting bolt(2).
 - Weight : 50kg(110lb)
 - Tightening torque : $29.7 \pm 45\text{kgf} \cdot \text{m}$
($215 \pm 32.5\text{lbf} \cdot \text{ft}$)

- (6) Remove the turning joint assembly.
※ When removing the turning joint, check that all the hoses have been disconnected.


2) INSTALL

- (1) Carry out installation in the reverse order to removal.
※ Take care of turning joint direction.
※ Assemble hoses to their original positions.
※ Confirm the hydraulic oil level and check the hydraulic oil leak or not.



2. DISASSEMBLY AND ASSEMBLY

1) STRUCTURE




R210TJT2

1 Hub	6 Shim	11 Plug
2 Shaft assembly	7 Slipper seal	12 Plug
3 Cover	8 O-ring	13 Retaining ring
4 Spacer	9 O-ring	14 Hexagon bolt
5 Shim	10 O-ring	15 Spring washer

2) DISASSEMBLY

※ Before the disassembly, clean the turning joint.


- (1) Remove bolts(14), washer(15) and cover(3).



21078DA10

- (2) Remove shim(6) and O-ring(10).

- (3) Remove retainer ring(13), spacer(4) and shim(5).




45078DA11

- (4) Place body(1) on a V-block and by using a wood buffer at the shaft end, hit out shaft(2) to about 1/2 from the body with a hammer.


※ Take care not to damage the shaft(2) when remove body(1) or rest it sideway.

※ Put a fitting mark on body(1) and shaft(2).



8-141(3) 210-7

- (5) Remove six slipper seals(7) and O-ring(9), from body(1).




45078DA12

3) ASSEMBLY


- ※ Clean all parts.
- ※ As a general rule, replace oil seals and O-ring.
- ※ Coat the sliding surfaces of all parts with engine oil or grease before installing.

(1) Fix seven slipper seal(7) and O-ring(9), to body(1).

(2) Fit O-ring(8) to shaft(2).




(3) Set shaft(2) on block, tap body(1) with a plastic hammer to install.



(4) Fit shim(5), spacer(4) and retainer ring (13) to shaft(2).


(5) Fit O-ring(10) to body(1).

(6) Fit shim(6) to shaft(2).



(7) Install cover(3) to body(1) and tighten bolts(14).

· Torque : 10~12.5kgf · m(72.3~90.4lbf · ft)



21078DA10