

GROUP 2 TRANSMISSION

1. TECHNICAL DATA

Rated input power	162 kW
Rated input speed	2000 rpm
Torque converter type	Single-stage, two-phase, four-element
Torque ratio when zero speed	4 ± 0.20
Transmission Type	Two forward and one reverse gears, power shift, planetary structure
Mechanical Gear Ratio; Gear I	2.155
Gear II	0.578
Reverse	1.577
I/O gear ratio of P.T.O	P.T.O. 1 1.0
	P.T.O. 2 1.167
Hydraulic oil pressure	1.10 ~ 1.40 MPa
Inlet oil pressure, torque converter	0.30 ~ 0.45 MPa
Outlet oil pressure, torque converter	0.20 ~ 0.30 MPa
Lubricating oil pressure	0.10 ~ 0.20 MPa
Max. permissible tempeture at outlet of torque converter	120°C

2. STRUCTURAL PRINCIPLE

Hydraulic transmission consists of hydraulic torque converter and power-shifting mechanical transmission. The transmission diagram is as shown as figure 3.





Figure 3 Structural diagram of hydraulic transmission.




3. STRUCTURE



850KTM100


- | | | |
|------------------------------------|--|-----------------------------------|
| 1 Working pump | 14 Large overrunning clutch cam | 26 Direct gear input shaft |
| 2 Variable speed pump | 15 Outer-ring gear, large overrunning clutch | 28 Direct gear cylinder |
| 3 First-stage input gear | 16 Sun gear | 30 Direct gear piston |
| 4 Input second-stage gear | 17 Reverse planet wheel | 31 Direct gear frictional plate |
| 5 Shaft gear | 18 Reverse pinion carrier | 32 Direct gear thrust plate |
| 6 Guide pulley seat | 19 Gear I planet gear | 33 Reverse-gear I connection disc |
| 7 Second-stage turbine | 20 Reverse inner toothed annulus | 34 Gear I pinion carrier |
| 8 First-stage turbine | 21 Rear axle output shaft | 35 Gear I cylinder |
| 9 Guide pulley | 22 Front back release sliding sleeve | 36 Gear I piston |
| 10 Pump pulley | 23 Output gear, transmission | 37 Gear I inner toothed annulus |
| 11 Transfer gear | 24 Front axle output shaft | 38 Gear I frictional plate |
| 12 Intermediate input shaft | 25 Output gear | 39 Reverse frictional plate |
| 13 Large overrunning clutch roller | | 40 Reverse piston |

4. OUTSIDE VIEW







VIEW A

P.T.O.1 Connection seat for Working pump



P.T.O.2 Connection seat for steering pump



V. Interface for oil thermometer M14×1.5 Depth 20

5. OPERATION

1) HYDRAULIC TORQUE CONVERTER

Torque converter is designed as single-stage, two-phase and four elements. Its construction is as shown in figure 2 (page 2-3).

Torque converter consists mainly of pump pulley (10), first-stage turbine (8), second-stage turbine (7) and guide pulley (9). The pump pulley connects to engine flywheel by a flexible steel board. When the pump pulley turns, oil in torus is driven and has certain kinetic energy. Then the oil drives the first- and second-stage turbines, and drives the transmission running. Since turbines' torque and speed would change by variation of load, the torque converter possesses the functions of automatic torque- and speed-changing. The guide pulley is fixed on housing of torque converter by a guide pulley seat (6).

When hydraulic transmission has a small load or high speed, the second-stage turbine works individually; however, when the load increases and the speed decreases (at the moment the speed of motor is basically unchanged), two turbines automatically work together.

2) MECHANICAL TRANSMISSION

Power of the second-stage turbine (7) is transferred to intermediate input shaft (12) via input second-stage gear (4), and that of the first-stage turbine to input first-stage gear (3), then to outer-ring gear of large overrunning clutch (15). When external load is comparatively small, speed of intermediate input shaft (12) is higher than that of outer-ring gear of large overrunning clutch (15), thus making large overrunning clutch roller (13) racing. At this time the second-stage turbine works individually.

When external load is increasing, speed of intermediate input shaft (12) is caused to descend gradually. If speed of the intermediate input shaft (12) is lower than that of outer-ring gear of large overrunning clutch (15), the roller (13) is to be wedged. Power from the first-stage turbine is transferred to large overrunning clutch cam (14) via the roller (13). Since the cam (14) and the intermediate input shaft (12) are connected with bolts, the first- and the second-stage turbines work together at the time. Mechanical transmission has two forward gears and one reverse gear. Transmission route and power flow chart of each gear are as shown in figure 4, 5 and 6.




Figure 4 Power flow chart of forward gear I




Figure 5 Power flow chart of forward gear II

At the bottom of the transmission, there is a front and rear axle release device (see to figure 2), which can control single- or dual-axle drive. Pull the control rod outward for single-axle drive and push inside for dual-axle drive. Generally, use single-axle drive in long-distance transport with light load to reduce loss from power recycling; and use dual-axle drive when operating under heavy load on slushy roads or crossing bridges.




Figure 6 Diagram of reverse gear power flow chart

3) HYDRAULIC SYSTEM




Diagram of hydraulic system of hydraulic transmission

850KPT51

6. APPLICATION AND INSTALLATION

1) INSTALLATION AND CONNECTION

(1) Connection to engine

Surface of torque converter casing is directly connected to that of engine flywheel casing by bolts. Through the connection between flexible steel board of converter and engine flywheel by stud bolts and nuts, power is transferred. Head of centering shaft at front end of pump pulley cover inserts flywheel centering hole as centering.

When installing, screw stud bolts into flywheel, open a chock on torque converter, lift the transmission and make hole on flexible steel board and centering hole lining up, screw end-face bolts and tighten the nuts through square holes at lower side of the chock, at last, cover the chock.

※ Difference between the plane of flywheel casing and that of flywheel ≤ 0.50 mm.

(2) Connection to oil pump

Working oil pump and steering oil pump are directly mounted onto PTO1 and PTO2 of transmission. (Shaft head length 60~65 mm, key connection useful length ≥ 40 mm).

※ Connection parameter must be correct.

(3) Installation on vehicle

Had better apply three- or four-point flexible supporting installation. There is each one V-block at both sides of transmission for installation and it's required to weld corresponding V-blocks on the vehicle body, too. Between two V-blocks insert a rubber plate of 10~12 mm as elastic layer, avoiding stress from vehicle chassis being transmitted to transmission housing directly.

(4) Selection and assembly of filter

Select filter meeting parameter as follows : Min. filter flow: 120 ℓ/min

Filter accuracy not less than 150 mesh/inch. Use sintered filter as far as possible.

The installation height of filter and oil pipes must not be higher than that of the oil pipe connector of housing.

(5) Selection and assembly of cooler

Calculate cooling capacity required on the basis of an ambient temperature 30, which should be 35~40% of the rated power of engine. Normal flow must be assured.

Cooler for transmission should be located at cool water end of the cooling system.

Diameter of oil pipe and thread connector for cooler and filter should be more than 20, and when oil pipe exceeds 1m in length, the value increases by 20%.

※ The system maker is liable for correct installation.

2) APPLICATION REQUIREMENTS

(1) After installation of hydraulic transmission, fill in about AFT (DEXRON III) from the oil hole. Check the oil level again after 5min running from starting engine, which should reach the height of oil-level plug. During checking, be sure to take safety measures to avoid vehicle moving or rolling.

(2) Oil level should be checked before each shift operating.

(3) When the transmission works, the hydraulic oil pressure should be kept within 1.1~1.4 MPa. In case of the value is lower than 1 MPa or higher than 1.6 MPa, stop and check to avoid damaging the parts inside.

- (4) The oil temperature should be lower than 120°C. When it exceeds, keep the engine speed within 1200~1500 rpm and make the transmission at neutral, then the oil temperature should decrease to a normal value in 2~3 min. If not, it shows there are problems in the system, which must be resolved before operation.
- (5) Reduce machine speed before transmission changing down. And stop before reversing.
- (6) The shifting lever should be at neutral position when starting the engine.
- (7) Stop when control by using the axle releasing device.
After installation of a new T/M, keep running in for twelve hours under a load less than 70%, four hours for each of three gears. Check the oil temperature, oil pressure and the tightness of bolts. After running in, clean the sump strainer of transmission and then renew oil.

3) MAINTENANCE

Maintenance is carried out after running for 50, 250, 1000 and 2000 hours.

- (1) 50 hours maintenance : ① check oil level ② Inspect the control system.
- (2) 250 hours maintenance : Clean filter and clean sump.
- (3) 500 hours maintenance : Change oil.
- (4) 1000 hours maintenance : Replace filter.
- (5) 2000 hours maintenance : Dismantle and inspect the transmission and the torque converter, replace easily-worn parts, regulate or replace parts when necessary.


7. MAIN FAILURES AND REMEDIES

Main Failures	Remedies
The engine rotating, but machine can not run	
<ol style="list-style-type: none"> 1. Did not in any gears 2. Hydraulic oil level too low 3. Brake rod of shift valve can not return 4. Insufficient oil supply due to shifting oil pump damaged or oil seals broken 	<ol style="list-style-type: none"> 1. Put into gear or check if it correct 2. Add oil 3. Dismantle and check the brake rod 4. Replace oil pump or oil seals
Insufficient driving force	
<ol style="list-style-type: none"> 1. Low oil pressure at inlet of torque converter 2. Clutch sliding 3. Insufficient engine speed 	<ol style="list-style-type: none"> 1. Check oil level; clean sump strainer and filter; check the pressure regulating valve of torque converter 2. Inspect clutch oil pressure and piston oil seal 3. Inspect the engine
Variable speed oil pressure too low	
<ol style="list-style-type: none"> 1. Misalignment of reducing valve 2. Obstructed oil filter 3. Damaged oil pump 4. Serious oil leakage in clutch oil seal 	<ol style="list-style-type: none"> 1. Realignment 2. Clean oil filter 3. Replace oil pump 4. Replace oil seals
Oil temperature in torque converter too high	
<ol style="list-style-type: none"> 1. Oil level in transmission too low or too high 2. Clutch sliding 3. Long-time, heavy load operation 	<ol style="list-style-type: none"> 1. Fill oil acc. to specified 2. Check oil pressure of clutch 3. Stop to cool
Can not put into gear after emergent braking	
<ol style="list-style-type: none"> 1. Misalignment limit screws of air brake valve pedal 2. Choked piston of air brake valve. Return is unavailable after release of brake. 3. Choked brake valve rod 	<ol style="list-style-type: none"> 1. Realign the limit screws of pedal so that air brake valve can return completely. 2. Clean and repair the piston 3. Dismantle and check brake valve rod

8. DISASSEMBLY AND ASSEMBLY

1) DISASSEMBLY

- (1) Remove the bolts 6-M10×55, 2-M10×80 for connecting oil pumps and housing, then take down the oil pump by knocking at the outside of the pump with copper rod.



7653TM01

- (2) Unscrew the bolts 13-M10×70 with socket M16 and remove the valve.



7653TM02

- (3) Unscrew the bolts 26-M10×30 and 5-M10×70 with sockets M16 and separate the housing and the torque converter through screwing the bolts 3-M10×70.




7653TM03




7653TM04

- (4) Remove the 1st stage gear, 2nd stage gear, bearings, pump, drive shaft assembly and gear assembly.



7653TM05



7653TM06

- (5) Remove the two shaft assembly.



7653TM07



7653TM08

- (6) Lay the transmission flat, and unscrew the bolts 8-M10×30, then remove the cover with lift-ring.




7653TM09

- (7) Remove the direction shift assembly with lift-ring.



7653TM10

- (8) Unscrew the bolts 8-M14×40 in the cover, and remove the cover.




7653TM11

- (9) Remove the parts inside planetary row, cylinder assembly, 15 spring pins, 15 springs, plate, 4 discs, 1st planetary carrier, bracket assembly, 4 discs, 3 plates, ring, 1 disc, reverse shift planetary carrier assembly and reverse piston.



7653TM12


- (10) Remove 2 washers 130 from both side of the housing then remove the output shaft through knocking at it from behind to front.



7653TM13

2) ASSEMBLY

- (1) Clean the housing and lay it flat, then install the reverse shift piston.



7653TM14

- (2) Install the reverse shift planetary row assembly.



7653TM15

- (3) Install the 5 plates, and 4 discs in proper order.




7653TM16

(4) Install the bracket assembly.



7653TM17

(5) Install 1st shift carrier assembly : put the 1 plate, 1 disc then gear-ring in proper order. Next put the plate and disc again, finally we should totally put 5 plates and 4 discs.



7653TM18

(6) Put 15 springs and 15 spring pins into 1st shift cylinder assembly.




7653TM19




7653TM20

- (7) Install the cover and tighten the bolts 8-M14 × 10 with socket M22.



7653TM21

- (8) Install the direction shift assembly and cover, then tighten the bolts 8-M10 × 30 with the socket M16.



7653TM22




7653TM23

- (9) Install the two shaft assembly.




7653TM24

- (10) Install the 2nd, 1st stage gear, bearing, pump, drive shaft assembly and gear assembly in torque converter.




7653TM25

- (11) Attach the torque converter to transmission and insert the pin 2-M10×30. Finally tighten the bolts 26-M10×30 and 5-M10×70.




7653TM26

- (12) Install the valve and pump.



7653TM27



7653TM28

3) TROUBLESHOOTING

Fault	Feature	Reason
The engine runs but can't move.	<ul style="list-style-type: none"> · Fail to put into gear. · The oil level of the transmission is too low. · The braking valve stem of the transmission can't return. · Variable-speed oil pump damaged or oil seal leakage results in oil shortage. · Hand braking is stuck. 	<ul style="list-style-type: none"> · Re-push it to the gear or check the location accuracy of the gears. · Add new oil. · Dismantle and check the braking valve stem and find out reasons. · Replace the oil pump or the oil seal. · Check the hand braking; adjust and in gear it again.
The drive force is not sufficient.	<ul style="list-style-type: none"> · The inlet oil pressure of the torque converter is low. · The clutch slips. · The rotational speed of the engine is not enough. 	<ul style="list-style-type: none"> · Check the oil level of the transmission; clean the oil pan filter and the fuel filter; and check whether the pressure regulation valve of the torque converter is normal. · Check the oil pressure of the clutch and the oil seal of the piston seal. · Check the engine.
The oil pressure of the transmission is too low.	<ul style="list-style-type: none"> · The pressure reducing valve is not adjusted properly. · The oil filter is blocked. · The oil pump fails. · The oil seal of the clutch has a serious oil. 	<ul style="list-style-type: none"> · Adjust it again. · Clean the oil filter. · Replace the oil pump. · Replace the oil seal.
The oil temperature of the torque converter is too high.	<ul style="list-style-type: none"> · The oil level of the transmission is too high or too low. · The clutch is too slippery. · Long-term heavy-load work. · The oil is dirty or bad. 	<ul style="list-style-type: none"> · Fill the oil as required. · Check the oil pressure of the clutch. · Stop the machine for cooling. · Check the oil pan shell, clean corresponding system components and replace with new oil.
It fails to put into gear after emergency braking.	<ul style="list-style-type: none"> · The pedal limit screw of the pneumatic valve pedal is not adjusted properly; the pneumatic valve can't return completely. · The piston of the pneumatic brake valve is stuck and can't return after braking release. · The braking valve stem is stuck. 	<ul style="list-style-type: none"> · Re-adjust the pedal limit screw so that the pneumatic valve can return completely. · Clean and check the piston. · Dismantle and check the braking valve stem.