

GROUP 4 CONNECTOR DESTINATION

| Connector number | Type | No. of pin | Destination | Connector part No. | |
|------------------|----------------|------------|-------------------------------------|--------------------|-------------|
| | | | | Female | Male |
| CN-1 | AMP | 15 | I/conn(Frame harness-Main harness) | 2-85262-1 | 368301-1 |
| CN-2 | AMP | 15 | I/conn(Frame harness-Main harness) | 2-85262-1 | 368301-1 |
| CN-4 | FASTEN | 15 | I/conn(Rops harness-Dash harness) | 2-85262-1 | 368301-1 |
| CN-7 | KET | 2 | I/conn(Main harness-Aircon harness) | MG652934-5 | MG642928-5 |
| CN-20 | - | 2 | Horn | 35825-0211 | - |
| CN-21 | FASTEN | 4 | Wiper motor | S810-004202 | - |
| CN-26 | 58-X | 2 | Warning buzzer | S814-002001 | - |
| CN-36 | FASTEN | 2 | Fuse box | S810-002202 | S810-102202 |
| CN-37 | SWP | 6 | Fuse box | S814-006100 | S814-106001 |
| CN-45 | RING TERM | 1 | Start motor | S820-308000 | - |
| | - | 1 | Start motor | 171809-2 | - |
| CN-48 | - | 1 | Hour meter | 171809-2 | - |
| CN-56 | SWP | 12 | Indicator panel | S816-012002 | S816-112002 |
| CN-58 | ECONO SEAL III | 36 | Control unit | 344111-1 | - |
| CN-65 | SHUR | 1 | Travel buzzer | S822-014000 | - |
| CN-68 | RING TERM | 1 | Safety solenoid | - | S820-105000 |
| CN-71 | SWP | 2 | Parking solenoid | S814-002001 | - |
| CN-74 | RING TERM | 1 | Alternator | - | S820-306000 |
| | FASTEM | 2 | Alternator | S810-002202 | - |
| CN-79 | SUMITOMO | 2 | Fuel stop solenoid | 6195-0003 | - |
| CN-106 | FASTEN | 3 | Fuel gauge | S810-003202 | - |
| | SHUR | 1 | Fuel gauge | S822-014000 | - |
| | SHUR | 1 | Fuel gauge | - | S822-114000 |
| · Switch | | | | | |
| CS-2 | AMP | 6 | Start switch | S814-006001 | - |
| CS-3 | SWF | 10 | Wiper switch | SWF593757 | - |
| CS-4 | SWP | 3 | Safety switch | S816-003002 | - |
| CS-21 | SWF | 10 | Light switch | SWF593757 | - |
| CS-23 | SWF | 10 | Beacon switch | SWF593757 | - |
| CS-52 | SWF | 10 | Safety reset switch | SWF593757 | - |
| CS-61 | - | 2 | Horn switch | DT04-6P | DT06-6S |
| CS-112 | SWF | 10 | High flow switch | SWF593757 | - |
| CS-114 | SWF | 10 | Self leveling switch | SWF593757 | - |

| Connector number | Type | No. of pin | Destination | Connector part No. | |
|-------------------------|---------|------------|------------------------------|--------------------|-------------|
| | | | | Female | Male |
| · Lamp | | | | | |
| CL-1 | KET | 2 | Room lamp | MG610070 | - |
| CL-2 | FASTEN | 3 | Cigar lighter lamp | S810-003202 | - |
| CL-5 | SHUR | 1 | Work lamp-LH | S822-014004 | S822-114004 |
| CL-6 | SHUR | 1 | Work lamp-RH | S822-014004 | S822-114004 |
| CL-7 | SHUR | 1 | Beacon lamp | S822-014004 | S822-114004 |
| · Relay | | | | | |
| CR-2 | FASTEN | 4 | Horn relay | S810-004202 | - |
| CR-5 | FASTEN | 5 | Anti-restart relay | S810-005203 | - |
| CR-23 | SWP | 2 | Start relay | S814-002001 | - |
| CR-35 | FASTEN | 4 | Power relay | S810-004202 | - |
| CR-48 | FASTEN | 4 | Safety relay | S810-004202 | - |
| CR-51 | FASTEN | 4 | Fuel cut-off relay | S810-004202 | - |
| · Sensor, sender | | | | | |
| CD-1 | AMP | 1 | Hydraulic temperature switch | 1-150656-1 | - |
| CD-2 | AMP | 3 | Fuel sender | S816-003002 | - |
| CD-8 | AMP | 2 | Water temperature switch | 368412-1 | - |
| CD-31 | DEUTSCH | 2 | Overload pressure switch | DT06-2S-EP06 | - |