

GROUP 4 CONNECTOR DESTINATION

Connector number	Type	No. of pin	Destination	Connector part No.	
				Female	Male
CN-1	SWP	12	l/conn(ROPS harness-frame harness)	S814-012000	S814-112000
CN-2	58-X	4	l/conn(ROPS harness-frame harness)	S813-060400	S813-160400
CN-3	58-X	2	l/conn(ROPS harness-frame harness)	S813-030200	S813-130200
CN-4	FASTEN	2	Fuse box	S810-002202	S810-102202
CN-5	SWP	6	Fuse box	S814-006100	S814-106100
CN-6	MOLEX	2	Horn	35215-0200	-
CN-7	FASTEN	2	Hour meter	S810-002202	S810-102202
CN-8	FASTEN	3	Fuel gauge	S810-003202	S810-103202
CN-9	SHUR	1	Fuel gauge	S822-014002	S822-114002
	SHUR	1	Fuel gauge	S822-014002	S822-114002
CN-10	SWF	2	Charge indicator	SWF913328	-
CN-11	SWF	2	Engine oil pressure indicator	SWF913328	-
CN-12	SWF	2	Not applied	SWF913328	-
CN-13	SWF	2	Air heater indicator	SWF913328	-
CN-14	SWF	2	Hydraulic oil temperature indicator	SWF913328	-
CN-15	SWF	2	Water temperature indicator	SWF913328	-
CN-16	YAZAKI	4	Air heater timer	Y7323-2249	-
CN-17	YAZAKI	4	Engine stop solenoid timer	Y7323-2249	-
CN-18	YAZAKI	2	Alternator	Y7323-2024	-
	RING TERM	1	Alternator	S820-405002	-
CN-19	SMITOMO	1	Start motor	S6411-1317	-
	RING TERM	1	Start motor	S820-308002	-
CN-20	58-X	2	Fusible link	S849-180000	-
CN-22	RING TERM	1	Safety solenoid valve	S820-105002	-
CN-23	RING TERM	1	Engine air heater	S820-206002	-
CN-24	FASTEN	2	Diode	S810-002202	-
CN-25	YAZAKI	3	Engine fuel stop solenoid	Y7123-2237	-
CN-26	58-X	2	Fusible link	S849-110000	-
. Switch					
CS-1	YAZAKI	4	Start switch	Y7322-2446	-
	YAZAKI	1	Start switch	Y7323-3010	-
CS-2	SHUR	1	Monetary switch	S822-014002	S822-114002
CS-3	RING TERM	1	Limit switch	-	S821-104002
CS-4	SWF	1	Beacon switch	SWF593757	-
CS-5	SWF	1	Lamp switch	SWF593757	-
CS-6	SHUR	1	Horn switch	S822-014002	S822-114042

Connector number	Type	No. of pin	Destination	Connector part No.	
				Female	Male
· Lamp					
CL-1	SHUR	1	Rear lamp	S822-014004	S822-104004
CL-2	AMP	1	Beacon lamp	170183-2	-
CL-3	SHUR	1	Work lamp LH	S822-014004	S822-114004
CL-4	SHUR	1	Work lamp RH	S822-014004	S822-114004
CL-5	KET	1	Room lamp	MG610070	-
· Relay					
CR-1	FASTEN	2	Engine stop solenoid relay	S810-002202	-
CR-2	FASTEN	2	Engine stop solenoid relay	S810-002302	-
CR-3	FASTEN	2	Glow relay	S810-002202	-
CR-4	FASTEN	2	Glow relay	S810-002302	-
CR-5	FASTEN	4	Safety solenoid relay	S810-004202	-
CR-6	FASTEN	4	Horn relay	S810-004202	-
· Sensor, sender					
CD-1	AMP	1	Hydraulic temperature switch	1-150656	-
CD-2	AMP	1	Engine oil pressure switch	1-150656	-
CD-3	SWP	2	Fuel sender	S814-002100	S814-102100
CD-4	AMP	1	Water temperature switch	1-150656	-