


GROUP 8 VARIABLE POWER CONTROL SYSTEM (CLUSTER TYPE 1)



1409S5MS11

- The variable power control system controls the engine and pump mutual power according to RCV lever stroke and pump load. It makes fuel saving and smooth control at precise work.

| Description | Working condition |
|-----------------|-------------------|
| Power mode | E |
| Work mode | General (bucket) |
| Pressure sensor | Normal |

※ The variable power control function can be activated when the power mode is set to E mode.