


GROUP 8 VARIABLE POWER CONTROL SYSTEM (CLUSTER TYPE 1)



3809SH5MS08

- The variable power control system controls the engine and pump mutual power according to RCV lever stroke and pump load. It makes fuel saving and smooth control at precise work.

Description	Working condition
Power mode	E
Work mode	General (bucket)
Pressure sensor	Normal

※ The variable power control function can be activated when the power mode is set to E mode.