


## GROUP 2 AIR BRAKE CIRCUIT



830KBS01A

- |   |                         |   |                                |
|---|-------------------------|---|--------------------------------|
| 1 | Air brake valve         | 5 | Safety valve                   |
| 2 | Air tank                | 6 | Auto water drain               |
| 3 | Air booster             | 7 | Brake lamp air pressure switch |
| 4 | Oil and water separator | 8 | Pressure switch and sensor     |