


GROUP 2 MODE SELECTION SYSTEM

1. POWER MODE SELECTION SYSTEM



21095MS02


Mode selection system (micro computer based electro-hydraulic pump and engine mutual control system) optimizes the engine and pump performance.

The combination of 3 power modes (P, S, E) and accel dial position (10 set) makes it possible to use the engine and pump power more effectively corresponding to the work conditions from a heavy and great power requesting work to a light and precise work.

Power mode	Application	Engine rpm				Power shift by EPPR valve			
		Standard		Option		Standard		Option	
		Unload	Load	Unload	Load	Current (mA)	Pressure (kgf/cm ²)	Current (mA)	Pressure (kgf/cm ²)
P	Heavy duty power	1850±50	1800±50	1850±50	1800±50	250±30	5	160±30	0
S	Standard power	1750±50	1700±50	1750±50	1700±50	335±30	10±3	225±30	4±3
E	Economy operation	1600±50	1700±50	1600±50	1700±50	400±30	15±3	330±30	9±3
AUTO DECEL	Engine deceleration	1050±100	-	1050±100	-	700±30	35±3	700±30	35±3
One touch decel	Engine quick deceleration	800±100	-	800±100	-	700±30	35±3	700±30	35±3
KEY START	Key switch start position	800±100	-	800±100	-	700±30	35±3	700±30	35±3

* Power shift (Standard/Option) can be changed by "Service menu" in "Management" on the cluster.

2. WORK MODE SELECTION SYSTEM




2909MH5MS02

1) GENERAL WORK MODE (grapple)

This mode is used to material (waste) handling work.

2) ATT WORK MODE (Not installed)

3. USER MODE SELECTION SYSTEM



21095MS03A

1) High idle rpm, auto idle rpm and EPPR pressure can be adjusted and memorized in the U-mode.

2) LCD segment vs parameter setting

Step (■)	Engine speed (rpm)	Idle speed (rpm)	Power shift (bar)
1	1400	700	0
2	1450	750	2
3	1500	800 (low idle)	4
4	1550	850	7
5	1600	900	12
6	1650	950	15
7	1700	1000	20
8	1750	1050 (decel rpm)	24
9	1800	1100	28
10	1850	1150	33