






























GROUP 3 ELECTRICAL COMPONENT SPECIFICATION







Part name	Symbol	Specifications	Check
Battery		12V × 160Ah (2EA)	Check specific gravity 1.280 over : Over charged 1.280 ~ 1.250 : Normal 1.250 below : Recharging
Battery relay	 CR-1	Rated load : 24V 100A(continuity) 1000A(30seconds)	Check coil resistance(M4 to M4) Normal : About 50 Check contact Normal :
Start key	 CS-2	B-BR : 24V 1A B-ACC : 24V 10A B-ST : 24V 40A	Check contact OFF : (For each terminal) ON : 0 (For terminal 1-3 and 1-2) START : 0 (For terminal 1-5)
Pressure switch (travel, working)	 CD-6 CD-7 CD-37	10kgf/cm ² (N.C TYPE)	Check contact Normal : 0.1
Pressure switch (For overload)	 CD-31	3~6kgf/cm ² (N.O TYPE)	Check contact Normal :







Part name	Symbol	Specifications	Check
Pressure switch (For engine oil)	 CD-18	0.5kgf/cm ² (N.C TYPE)	Check resistance Normal : (CLOSE)
Temperature sensor (Coolant Hydraulic)	 CD-1 CD-8	-	Check resistance 50,C : 804 80,C : 310 100,C : 180
Air cleaner pressure switch	 CD-10	-	Check contact High level : Low level : 0
Fuel sender	 CD-2	-	Check resistance Full : 50 6/12 : 350 11/12 : 100 5/12 : 400 10/12 : 150 4/12 : 450 9/12 : 200 3/12 : 500 8/12 : 250 2/12 : 550 7/12 : 300 1/12 : 600 Empty warning : 700
Tacho sensor	 CD-17	-	Check resistance Normal : 300 (For terminal 1-2)
Relay	 CR-2 CR-5 CR-7 CR-35 CR-36	24V 16A	Check resistance Normal : About 160 (For terminal 85-86) 0 (For terminal 30-87a) (For terminal 30-87)







Part name	Symbol	Specifications	Check
Accel actuator	 <p>CN-76</p>	-	<p>Check resistance Normal : 1~2 (For terminal 5-6) 0.8~1.2k (For terminal 1-3)</p>
Solenoid valve	 <p>CN-66 CN-68 CN-70 CN-88 CN-133 CN-137 CN-140</p>	24V 1A	<p>Check resistance Normal : 15~25 (For terminal 1-2)</p>
EPPR valve	 <p>CN-75</p>	700mA	<p>Check resistance Normal : 15~25 (For terminal 1-2)</p>
Resistor	 <p>CN-47</p>	45 20W ± 5%	<p>Check resistance Normal : 45</p>
Speaker	 <p>CN-23(LH) CN-24(RH)</p>	200W	<p>Check disconnection Normal : A few</p>
Switch (Locking type)	 <p>CS-23 CS-27 CS-50 CS-52 CS-54</p>	24V 8A	<p>Check contact Normal ON : 0 (For terminal 1-5, 2-6) (For terminal 5-7, 6-8) OFF : (For terminal 1-5, 2-6) 0 (For terminal 5-7, 6-8)</p>

Part name	Symbol	Specifications	Check
Accel dial	 <p>CN-142</p>	-	<p>Check resist Normal : About 5k (For terminal A-C) Normal : About 5V (For terminal A-C) : 2~4.5V (For terminal C-B)</p>
Switch	 <p>CS-67</p>	24V 8A	<p>Check disconnection Normal : 1.0 ON : 0 (For terminal 1-5, 2-6) (For terminal 5-7, 6-8) OFF : (For terminal 1-5, 6-8) 0 (For terminal 5-7, 6-8)</p>
Head lamp, Work lamp, Room lamp, Cab lamp	 <p>CL-1 CL-4 CL-5 CL-6 CL-8 CL-9</p>	24V 70W (H3 Type) 24V 10W (Room lamp)	<p>Check disconnection Normal : A few</p>
Beacon lamp	 <p>CL-7</p>	21V 70A (H1 type)	<p>Check disconnection Normal : A few</p>
Fuel filler pump	 <p>CN-61</p>	24V 10A 35 /min	<p>Check resistance Normal : 1.0</p>
Hour meter	 <p>CN-48</p>	16~32V	<p>Check operation Supply power(24V) to terminal No.2 and connect terminal No.1 and ground</p>

Part name	Symbol	Specifications	Check
Horn	 <p>CN-20 CN-25</p>	DC22~28V 2A	Check operation Supply power(24V) to each terminal and connect ground.
Safety switch 1	 <p>CS-4</p>	24V 15A (N.C TYPE)	Check contact Normal : 0 (For terminal 1-2) (For terminal 1-3) Operating : (For terminal 1-2) 0 (For terminal 1-3)
Safety switch 2	 <p>CS-20 CS-53</p>	24V (N.C TYPE)	Check contact Normal : 0 (One pin to ground)
Receiver dryer	 <p>CN-29</p>	24V 2.5A	Check contact Normal :
Cassette radio	 <p>CN-27</p>	24V 2A	Check voltage 20~25V (For terminal 10-14, 11-14)
Washer pump	 <p>CN-22</p>	24V 3.8A	Check contact Normal : 10.7 (For terminal 1-2)

Part name	Symbol	Specifications	Check
Wiper motor	 <p>CN-21</p>	24V 2A	Check disconnection Normal : 7 (For terminal 2-6)
DC/DC Converter	 <p>CN-138</p>	12V 3A	24V(A-B) 12V (B-C)
Cigar lighter	 <p>CL-2</p>	24V 5A 1.4W	Check coil resistance Normal : About 1M Check contact Normal : Operating time : 5~15sec
Alternator	 <p>CN-74</p>	24V 55A	Check contact Normal : 0 (For terminal B+-I) Normal : 24~27.5V
Starter	 <p>CN-45</p>	Delco Remy 28MT 24V	Check contact Normal : 0.1
Travel alarm	 <p>CN-81</p>	24V 0.5A	Check contact Normal : 5.2

Part name	Symbol	Specifications	Check
Fuel cut-off	 CN-79	24V	Check resistance Normal : 15~25
Aircon Compressor	 CN-28	24V 79W	Check contact Normal : 13.4
Start relay	 CR-23	24V 300A	Check contact Normal : 0.94 (For terminal 1-2)
Blower		24V 9.5A	Check resistance Normal : 2.5 (For terminal 1-2)
Aircon resistor		-	Check resistance Normal : 1.12 (For terminal 4-2) 2.07 (For terminal 2-3) 3.17 (For terminal 3-1)
Duct sensor		1.C OFF 4.C ON	Check resistance Normal : 0 (For terminal 1-2), the atmosphere temp : Over 4.C

Part name	Symbol	Specifications	Check
Door switch	 <p>CS-1</p>	24V 2W	Check resistance Normal : About 5M
Switch (Power max, one touch decal, horn, braker)	 <p>CS-5 CS-19 CS-26 CS-29</p>	24V 6A	Check resistance Normal :
Transducer	 <p>CD-42 CD-43</p>	500bar	0bar : 1V(For terminal 1-2) 500bar : 5V(For terminal 1-2)
Transducer	 <p>CD-44</p>	50bar	0bar : 1V(For terminal 1-2) 50bar : 5V(For terminal 1-2)
Fusible link	 <p>CN-60 CN-95</p>	60A	Check disconnection Normal : 0 (Connect ring terminal and check resist between terminal 1 and 2)
Pre-heater		24V 200A	Check resistance : 0.25 - 0.12